

SINAMICS G150

Converter cabinet units 75 kW to 1500 kW

Operating Instructions · 05/2010

www.nicsanat.com

021-87700210



SINAMICS

SIEMENS

SIEMENS

SINAMICS

SINAMICS G150 Converter cabinet units

Operating Instructions

www.nicsanat.com

021-87700210



Control version V4.3 SP2




05/2010
A5E03263466A

Foreword

| | |
|---|----|
| Safety information | 1 |
| Device Overview | 2 |
| Mechanical installation | 3 |
| Electrical installation | 4 |
| Commissioning | 5 |
| Operation | 6 |
| Setpoint channel and closed-loop control | 7 |
| Output terminals | 8 |
| Functions, Monitoring, and Protective Functions | 9 |
| Diagnosis / faults and alarms | 10 |
| Maintenance and servicing | 11 |
| Technical specifications | 12 |
| Appendix | A |

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

| |
|--|
|  DANGER |
| indicates that death or severe personal injury will result if proper precautions are not taken. |
|  WARNING |
| indicates that death or severe personal injury may result if proper precautions are not taken. |
|  CAUTION |
| with a safety alert symbol, indicates that minor personal injury can result if proper precautions are not taken. |
| CAUTION |
| without a safety alert symbol, indicates that property damage can result if proper precautions are not taken. |
| NOTICE |
| indicates that an unintended result or situation can occur if the corresponding information is not taken into account. |


If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation for the specific task, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

| |
|---|
|  WARNING |
| Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be adhered to. The information in the relevant documentation must be observed. |

Trademarks


All names identified by ® are registered trademarks of the Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Foreword

User documentation

| |
|--|
|  WARNING |
| Before installing and commissioning the converter, make sure that you read all the safety notes and warnings carefully, including the warning labels on the equipment itself. The warning labels must always be legible. Missing or damaged labels must be replaced. |

Structure of this documentation

The customer documentation comprises general and individual documentation.

The general documentation describes the topics that apply to all cabinet units:

- **Operating Instructions**

The Operating Instructions consist of the following sections:

- Device description
- Mechanical installation
- Electrical installation
- Commissioning guide
- Description of function
- Maintenance instructions
- Technical specifications

- **Overview diagrams**

These provide a general overview of the functionality of the cabinet units.

- **Basic function diagrams**

These provide an overview of the basic functions of the cabinet unit for simple applications.

- **List Manual**

The List Manual consists of the following sections:

- Parameter list
- Function diagrams
- Fault / warning list

- **Documentation for Drive Control Chart (DCC)**

- Programming and Operating Manual: DCC Editor description
- Function Manual: Description of the standard DCC blocks

The individual documentation describes precisely one customized cabinet unit and contains the following:

- **Dimension drawing**
The dimension drawing documents the dimensions of the ordered cabinet unit.
- **Layout diagram**
The layout diagram shows the components installed in the ordered cabinet unit.
- **Circuit diagram**
The circuit diagram shows the electrical components installed in the ordered cabinet unit, their interconnections and the customer interfaces.
- **Terminal diagram**
The terminal diagram shows all the customer terminals in the ordered cabinet unit, and the associated internal wiring in the cabinet unit. This diagram documents the line-side target wiring.
- **Spare parts list**
The spare parts list contains all the available spare parts for the ordered cabinet unit.
- **Additional operating instructions**
The instructions for OEM components installed in the ordered cabinet unit are supplied as OEM documentation.

Technical support

| Time zone Europe/Africa | |
|-------------------------|---|
| Phone | +49 (0) 911 895 7222 |
| Fax | +49 (0) 911 895 7223 |
| Internet | http://www.siemens.com/automation/support-request |

| Time zone America | |
|-------------------|--|
| Phone | +1 423 262 2522 |
| Fax | +1 423 262 2200 |
| Internet | techsupport.sea@siemens.com |

| Time zone Asia/Pacific | |
|------------------------|--|
| Phone | +86 1064 757 575 |
| Fax | +86 1064 747 474 |
| Internet | support.asia.automation@siemens.com |

Spare parts

You will find spare parts on the Internet at:
<http://support.automation.siemens.com/WW/view/en/16612315>.

Internet address

Information about SINAMICS can be found on the Internet at the following address:
<http://www.siemens.com/sinamics>

Table of contents

| | | |
|----------|---|-----------|
| | Foreword | 5 |
| 1 | Safety information..... | 15 |
| 1.1 | Warnings..... | 15 |
| 1.2 | Safety and operating instructions..... | 16 |
| 1.3 | Components that can be destroyed by electrostatic discharge (ESD) | 17 |
| 2 | Device Overview..... | 21 |
| 2.1 | Chapter content | 21 |
| 2.2 | Applications, features, and design..... | 21 |
| 2.2.1 | Field of applications | 21 |
| 2.2.2 | Characteristics, quality, service | 21 |
| 2.3 | Design | 23 |
| 2.3.1 | Version A..... | 23 |
| 2.3.2 | Version C | 26 |
| 2.4 | Wiring Principle | 27 |
| 2.5 | Type plate | 32 |
| 3 | Mechanical installation..... | 37 |
| 3.1 | Chapter content | 37 |
| 3.2 | Transportation and storage..... | 37 |
| 3.3 | Assembly..... | 39 |
| 3.3.1 | Mechanical installation: checklist..... | 40 |
| 3.3.2 | Preparatory steps..... | 41 |
| 3.3.3 | Shipping and handling monitors..... | 42 |
| 3.3.4 | Installation..... | 44 |
| 3.3.5 | Mechanical connection of units that are connected in parallel | 45 |
| 3.3.6 | Fitting additional canopies (option M21) or hoods (option M23, M43, M54) | 45 |
| 3.3.7 | Line connection from above (option M13), motor connection from above (option M78) | 49 |
| 4 | Electrical installation | 51 |
| 4.1 | Chapter content | 51 |
| 4.2 | Checklist for electrical installation | 52 |
| 4.3 | Important safety precautions..... | 58 |
| 4.4 | Introduction to EMC | 59 |
| 4.5 | EMC compliant design | 61 |
| 4.6 | Electrical connection of units that are connected in parallel..... | 63 |
| 4.6.1 | Connecting the PE busbars | 63 |
| 4.6.2 | Establishing the DC link connections..... | 64 |
| 4.6.3 | Connecting the power supply and signal cables..... | 64 |
| 4.6.4 | Connecting the DRIVE-CLiQ topology..... | 65 |

| | | |
|-----------|---|------------|
| 4.7 | Power connections | 65 |
| 4.7.1 | Connection cross-sections and cable lengths..... | 65 |
| 4.7.2 | Connecting the motor and power cables | 67 |
| 4.7.3 | Adjusting the fan voltage (-T1-T10) | 68 |
| 4.7.4 | Adjusting the internal power supply (-A1 -T10, version A only) | 71 |
| 4.7.5 | Removing the connection bracket for the interference-suppression capacitor with operation from an ungrounded supply | 72 |
| 4.8 | External Supply of the Auxiliary Supply from a Secure Line..... | 76 |
| 4.8.1 | 230 V AC auxiliary supply | 77 |
| 4.8.2 | 24 V DC auxiliary supply | 77 |
| 4.9 | Signal connections | 78 |
| 4.9.1 | Customer terminal module TM31 (-A60) (option G60) | 78 |
| 4.10 | Other connections | 85 |
| 4.10.1 | Clean Power version with integrated Line Harmonics Filter compact (Option L01) | 86 |
| 4.10.2 | dV/dt filter compact plus Voltage Peak Limiter (option L07) | 89 |
| 4.10.3 | dv/dt filter plus Voltage Peak Limiter (option L10) | 92 |
| 4.10.4 | Main Contactor (Option L13)..... | 96 |
| 4.10.5 | Sinusoidal Filter (Option L15)..... | 96 |
| 4.10.6 | Connection for External Auxiliary Equipment (Option L19) | 98 |
| 4.10.7 | Main switch incl. fuses or circuit breaker (option L26) | 99 |
| 4.10.8 | EMERGENCY OFF pushbutton installed in the cabinet door (option L45) | 101 |
| 4.10.9 | Cabinet illumination with service socket (option L50) | 102 |
| 4.10.10 | Cabinet anti-condensation heating (option L55) | 102 |
| 4.10.11 | EMERGENCY OFF category 0; 230 V AC or 24 V DC (option L57) | 103 |
| 4.10.12 | EMERGENCY STOP category 1; 230 V AC (option L59) | 105 |
| 4.10.13 | EMERGENCY STOP category 1; 24 V DC (option L60) | 106 |
| 4.10.14 | 25 kW Braking Unit (Option L61); 50 kW Braking Unit (Option L62) | 107 |
| 4.10.14.1 | Commissioning..... | 110 |
| 4.10.14.2 | Diagnosis and duty cycles | 111 |
| 4.10.14.3 | Threshold switch | 112 |
| 4.10.15 | Thermistor Motor Protection Unit (Option L83/L84) | 115 |
| 4.10.16 | PT100 Evaluation Unit (Option L86) | 116 |
| 4.10.17 | Insulation Monitor (Option L87)..... | 117 |
| 4.10.18 | Communication Board Ethernet CBE20 (Option G33) | 119 |
| 4.10.19 | CBC10 CAN Communication Board (option G20) | 121 |
| 4.10.20 | SMC30 Sensor Module Cabinet-Mounted (option K50) | 124 |
| 4.10.20.1 | Description | 124 |
| 4.10.20.2 | Connection..... | 128 |
| 4.10.20.3 | Connection examples | 130 |
| 4.10.21 | Voltage Sensing Module for determining the actual motor speed and the phase angle (option K51)..... | 131 |
| 4.10.22 | Customer terminal block (option G60) | 131 |
| 4.10.23 | Customer terminal block extension (option G61)..... | 132 |
| 4.10.24 | Terminal module for activation of "Safe Torque Off" and "Safe STOP 1" (option K82)..... | 132 |
| 4.10.25 | NAMUR terminal block (option B00) | 133 |
| 4.10.26 | Separate 24 V DC power supply for NAMUR (option B02) | 135 |
| 4.10.27 | Outgoing section for external auxiliary equipment for NAMUR (option B03)..... | 135 |
| 5 | Commissioning | 137 |
| 5.1 | Chapter content..... | 137 |
| 5.2 | STARTER commissioning tool..... | 138 |
| 5.2.1 | Installing the STARTER commissioning tool | 139 |
| 5.2.2 | Layout of the STARTER user interface..... | 140 |

| | | |
|----------|---|------------|
| 5.3 | Procedure for commissioning via STARTER..... | 141 |
| 5.3.1 | Creating the project..... | 141 |
| 5.3.2 | Configure the drive unit..... | 148 |
| 5.3.3 | Additional settings required for units that are connected in parallel | 168 |
| 5.3.4 | Starting the drive project | 169 |
| 5.3.5 | Commissioning with STARTER via Ethernet..... | 170 |
| 5.3.6 | Connection via serial interface..... | 174 |
| 5.4 | The AOP30 operator panel..... | 176 |
| 5.5 | First commissioning with the AOP30..... | 177 |
| 5.5.1 | Initial ramp-up | 177 |
| 5.5.2 | Basic Commissioning..... | 179 |
| 5.5.3 | Additional settings required for units that are connected in parallel | 185 |
| 5.6 | Status after commissioning..... | 187 |
| 5.7 | Parameter reset to factory settings..... | 188 |
| 6 | Operation..... | 191 |
| 6.1 | Chapter content | 191 |
| 6.2 | General information about command and setpoint sources | 192 |
| 6.3 | Basic information about the drive system | 193 |
| 6.3.1 | Parameters..... | 193 |
| 6.3.2 | Drive objects | 196 |
| 6.3.3 | Data Sets | 198 |
| 6.3.4 | BICO technology: interconnecting signals | 203 |
| 6.4 | Command sources..... | 209 |
| 6.4.1 | "PROFIdrive" default setting | 209 |
| 6.4.2 | "TM31 terminals" default setting | 211 |
| 6.4.3 | "NAMUR" default setting..... | 213 |
| 6.4.4 | "PROFIdrive NAMUR" default setting..... | 215 |
| 6.5 | Setpoint sources | 217 |
| 6.5.1 | Analog inputs | 217 |
| 6.5.2 | Motorized potentiometer | 219 |
| 6.5.3 | Fixed speed setpoints..... | 220 |
| 6.6 | PROFIBUS..... | 222 |
| 6.6.1 | PROFIBUS connection | 222 |
| 6.6.2 | Control via PROFIBUS | 226 |
| 6.6.3 | Monitoring: Telegram failure | 227 |
| 6.6.4 | Telegrams and process data | 228 |
| 6.6.5 | Structure of the telegrams..... | 230 |
| 6.6.5.1 | Overview of control words and setpoints | 231 |
| 6.6.5.2 | Overview of status words and actual values..... | 232 |
| 6.6.6 | Further information about communication via PROFINET | 232 |
| 6.7 | Control via the operator panel..... | 233 |
| 6.7.1 | Operator panel (AOP30) overview and menu structure | 233 |
| 6.7.2 | Operation screen menu | 235 |
| 6.7.3 | Parameterization menu..... | 235 |
| 6.7.4 | Menu: Fault/alarm memory | 238 |
| 6.7.5 | Menu commissioning / service..... | 239 |
| 6.7.5.1 | Drive commissioning..... | 239 |
| 6.7.5.2 | Device commissioning | 239 |
| 6.7.5.3 | AOP settings | 239 |

| | | |
|----------|--|------------|
| 6.7.5.4 | Lists of signals for the operation screen | 240 |
| 6.7.5.5 | AOP30 diagnosis | 244 |
| 6.7.6 | Language/Sprache/Langue/Idioma/Lingua | 245 |
| 6.7.7 | Operation via the operator panel (LOCAL mode) | 245 |
| 6.7.7.1 | LOCAL/REMOTE key | 245 |
| 6.7.7.2 | ON key / OFF key | 246 |
| 6.7.7.3 | Switching between clockwise and counter-clockwise rotation | 246 |
| 6.7.7.4 | Jog | 247 |
| 6.7.7.5 | Increase setpoint / decrease setpoint | 247 |
| 6.7.7.6 | AOP setpoint | 247 |
| 6.7.7.7 | Timeout monitoring | 248 |
| 6.7.7.8 | Operator input inhibit / parameterization inhibit | 248 |
| 6.7.8 | Faults and alarms | 250 |
| 6.7.9 | Saving the parameters permanently | 251 |
| 6.7.10 | Parameterization errors | 252 |
| 6.8 | PROFINET IO | 253 |
| 6.8.1 | Activating online operation: STARTER via PROFINET IO | 253 |
| 6.8.2 | General information about PROFINET IO | 257 |
| 6.8.2.1 | General information about PROFINET IO for SINAMICS | 257 |
| 6.8.2.2 | Real-time (RT) and isochronous real-time (IRT) communication | 259 |
| 6.8.2.3 | Addresses | 260 |
| 6.8.2.4 | Data transmission | 261 |
| 6.8.3 | Further information about communication via PROFINET IO | 262 |
| 6.9 | SINAMICS Link | 263 |
| 6.9.1 | Basic principles of SINAMICS Link | 263 |
| 6.9.2 | Topology | 264 |
| 6.9.3 | Configuring and commissioning | 264 |
| 6.9.4 | Example | 266 |
| 6.9.5 | Diagnostics | 268 |
| 6.9.6 | Parameter | 268 |
| 6.10 | Engineering Software Drive Control Chart (DCC) | 269 |
| 7 | Setpoint channel and closed-loop control | 271 |
| 7.1 | Chapter content | 271 |
| 7.2 | Setpoint channel | 272 |
| 7.2.1 | Setpoint addition | 272 |
| 7.2.2 | Direction reversal | 273 |
| 7.2.3 | Suppression bandwidths and minimum speeds | 274 |
| 7.2.4 | Speed limitation | 275 |
| 7.2.5 | Ramp-function generator | 276 |
| 7.3 | V/f control | 279 |
| 7.3.1 | Voltage Boost | 282 |
| 7.3.2 | Resonance damping | 285 |
| 7.3.3 | Slip compensation | 286 |
| 7.4 | Vector speed/torque control with/without encoder | 288 |
| 7.4.1 | Vector control without encoder | 289 |
| 7.4.2 | Vector control with encoder | 294 |
| 7.4.3 | Speed controller | 295 |
| 7.4.3.1 | Speed controller pre-control (integrated pre-control with balancing) | 298 |
| 7.4.3.2 | Reference model | 301 |
| 7.4.3.3 | Speed controller adaptation | 302 |
| 7.4.3.4 | Droop Function | 304 |

| | | |
|----------|---|------------|
| 7.4.3.5 | Open actual speed value | 305 |
| 7.4.4 | Closed-loop torque control | 307 |
| 7.4.5 | Torque limiting..... | 310 |
| 7.4.6 | Permanent-magnet synchronous motors..... | 311 |
| 8 | Output terminals | 315 |
| 8.1 | Chapter content | 315 |
| 8.2 | Analog outputs | 316 |
| 8.2.1 | List of signals for the analog signals | 317 |
| 8.3 | Digital outputs | 319 |
| 9 | Functions, Monitoring, and Protective Functions | 321 |
| 9.1 | Chapter content | 321 |
| 9.2 | Drive Functions | 322 |
| 9.2.1 | Motor identification and automatic speed controller optimization | 322 |
| 9.2.1.1 | Standstill measurement | 323 |
| 9.2.1.2 | Rotating measurement and speed controller optimization | 326 |
| 9.2.2 | Efficiency optimization | 329 |
| 9.2.3 | Fast magnetization for induction motors | 330 |
| 9.2.4 | Vdc control | 332 |
| 9.2.5 | Automatic restart function | 336 |
| 9.2.6 | Flying restart | 339 |
| 9.2.6.1 | Flying restart without encoder..... | 340 |
| 9.2.6.2 | Flying restart with encoder..... | 342 |
| 9.2.6.3 | Parameters..... | 342 |
| 9.2.7 | Motor changeover/selection..... | 343 |
| 9.2.7.1 | Description | 343 |
| 9.2.7.2 | Example of changing over between two motors | 343 |
| 9.2.7.3 | Function diagram | 344 |
| 9.2.7.4 | Parameters..... | 345 |
| 9.2.8 | Friction characteristic curve | 345 |
| 9.2.9 | Armature short-circuit brake, internal voltage protection, DC brake..... | 347 |
| 9.2.9.1 | General | 347 |
| 9.2.9.2 | External armature short-circuit brake..... | 347 |
| 9.2.9.3 | Internal armature short-circuit brake | 349 |
| 9.2.9.4 | Internal voltage protection..... | 350 |
| 9.2.9.5 | DC brake | 351 |
| 9.2.10 | Increasing the output frequency..... | 353 |
| 9.2.10.1 | Description | 353 |
| 9.2.10.2 | Default pulse frequencies | 353 |
| 9.2.10.3 | Increasing the pulse frequency | 353 |
| 9.2.10.4 | Maximum output frequency achieved by increasing the pulse frequency | 354 |
| 9.2.10.5 | Parameters..... | 355 |
| 9.2.11 | Pulse frequency wobbling | 356 |
| 9.2.12 | Runtime (operating hours counter) | 357 |
| 9.2.13 | Simulation operation | 358 |
| 9.2.14 | Direction reversal | 359 |
| 9.2.15 | Unit changeover | 360 |
| 9.2.16 | Derating behavior at increased pulse frequency | 362 |
| 9.3 | Extended functions | 364 |
| 9.3.1 | Technology controller..... | 364 |
| 9.3.2 | Bypass function..... | 367 |
| 9.3.2.1 | Bypass with synchronizer with degree of overlapping (p1260 = 1) | 368 |

| | | |
|-----------|---|------------|
| 9.3.2.2 | Bypass with synchronizer without degree of overlapping (p1260 = 2) | 371 |
| 9.3.2.3 | Bypass without synchronizer (p1260 = 3) | 373 |
| 9.3.2.4 | Function diagram | 374 |
| 9.3.2.5 | Parameters | 375 |
| 9.3.3 | Extended braking control | 376 |
| 9.3.4 | Extended monitoring functions | 378 |
| 9.4 | Monitoring and protective functions | 380 |
| 9.4.1 | Protecting power components | 380 |
| 9.4.2 | Thermal monitoring and overload responses | 381 |
| 9.4.3 | Block protection | 383 |
| 9.4.4 | Stall protection (only for vector control) | 384 |
| 9.4.5 | Thermal motor protection | 385 |
| 9.4.5.1 | Description | 385 |
| 9.4.5.2 | Temperature connection at the customer terminal block TM31 (option G60) | 385 |
| 9.4.5.3 | Temperature connection to a Sensor Module (option K50) | 386 |
| 9.4.5.4 | Temperature connection directly to the Control Interface Module | 386 |
| 9.4.5.5 | Temperature sensor evaluation | 387 |
| 9.4.5.6 | Function diagram | 387 |
| 9.4.5.7 | Parameters | 388 |
| 10 | Diagnosis / faults and alarms | 389 |
| 10.1 | Chapter content | 389 |
| 10.2 | Diagnosis | 390 |
| 10.2.1 | Diagnostics using LEDs | 391 |
| 10.2.2 | Diagnostics via parameters | 396 |
| 10.2.3 | Indicating and rectifying faults | 399 |
| 10.3 | Overview of warnings and faults | 400 |
| 10.3.1 | "External alarm 1" | 400 |
| 10.3.2 | "External fault 1" | 401 |
| 10.3.3 | "External fault 2" | 401 |
| 10.3.4 | "External fault 3" | 402 |
| 10.4 | Service and Support | 402 |
| 10.4.1 | Spare parts | 402 |
| 11 | Maintenance and servicing | 403 |
| 11.1 | Chapter content | 403 |
| 11.2 | Maintenance | 404 |
| 11.2.1 | Cleaning | 404 |
| 11.3 | Maintenance | 405 |
| 11.3.1 | Installation device | 406 |
| 11.3.2 | Using crane lifting lugs to transport power blocks | 407 |
| 11.4 | Replacing components | 409 |
| 11.4.1 | Replacing the filter mats | 410 |
| 11.4.2 | Replacing the Control Interface Module, frame size FX | 411 |
| 11.4.3 | Replacing the Control Interface Module, frame size GX | 413 |
| 11.4.4 | Replacing the Control Interface Module, frame size HX | 415 |
| 11.4.5 | Replacing the Control Interface Module, frame size JX | 417 |
| 11.4.6 | Replacing the power block (type FX) | 419 |
| 11.4.7 | Replacing the power block (type GX) | 421 |
| 11.4.8 | Replacing the power block (type HX) | 423 |
| 11.4.9 | Replacing the power block (type JX) | 427 |
| 11.4.10 | Replacing the fan (type FX) | 431 |

| | | |
|-----------|---|------------|
| 11.4.11 | Replacing the fan (type GX)..... | 433 |
| 11.4.12 | Replacing the fan (type HX)..... | 435 |
| 11.4.13 | Replacing the fan (type JX)..... | 439 |
| 11.4.14 | Replacing the fan fuse (-T1 -F10 / -T1 -F11)..... | 443 |
| 11.4.15 | Replacing the fuses for the auxiliary power supply (-A1 -F11 / -A1 -F12)..... | 443 |
| 11.4.16 | Replacing the fuse -A1 -F21..... | 443 |
| 11.4.17 | Replacing the cabinet operator panel..... | 444 |
| 11.4.18 | Replacing the Backup Battery for the Cabinet Operator Panel..... | 444 |
| 11.5 | Forming the DC link capacitors..... | 446 |
| 11.6 | Messages after replacing DRIVE-CLiQ components..... | 447 |
| 11.7 | Upgrading the cabinet unit firmware..... | 448 |
| 11.8 | Load the new operator panel firmware from the PC..... | 449 |
| 12 | Technical specifications..... | 451 |
| 12.1 | Chapter content..... | 451 |
| 12.2 | General data..... | 452 |
| 12.2.1 | Derating data..... | 453 |
| 12.2.2 | Overload capability..... | 458 |
| 12.3 | Technical specifications..... | 459 |
| 12.3.1 | Cabinet unit version A, 380 V - 480 V 3 AC..... | 460 |
| 12.3.2 | Cabinet unit version C, 380 V - 480 V 3 AC..... | 468 |
| 12.3.3 | Cabinet unit version A, 500 V - 600 V 3 AC..... | 473 |
| 12.3.4 | Cabinet unit version C, 500 V - 600 V 3 AC..... | 482 |
| 12.3.5 | Cabinet unit version A, 660 V - 690 V 3 AC..... | 488 |
| 12.3.6 | Cabinet unit version C, 660 V - 690 V 3 AC..... | 500 |
| A | Appendix..... | 511 |
| A.1 | List of abbreviations..... | 511 |
| A.2 | Parameter macros..... | 513 |
| | INDEX..... | 525 |

Safety information

1.1 Warnings



WARNING

Hazardous voltages are present when electrical equipment is in operation. Severe personal injury or substantial material damage may result if these warnings are not observed.

Only qualified personnel are permitted to work on or around the equipment. This personnel must be thoroughly familiar with all warning and maintenance procedures described in these operating instructions.

The successful and safe operation of this device is dependent on correct transport, proper storage and installation, as well as careful operation and maintenance. National safety guidelines must be observed.



DANGER

Five safety rules

When carrying out any kind of work on electrical devices, the "five safety rules" according to EN 50110 must always be observed:

1. Disconnect the system.
2. Protect against reconnection.
3. Make sure that the equipment is de-energized.
4. Ground and short-circuit.
5. Cover or enclose adjacent components that are still live.

Certification

The following certificates:

- EC declaration of conformity
- Certificate of compliance with order

can be found under "Safety and Operating Instructions" in the documentation folder.

1.2 Safety and operating instructions



DANGER

This equipment is used in industrial high-voltage installations. During operation, this equipment contains rotating and live, bare parts. For this reason, they could cause severe injury or significant material damage if the required covers are removed, if they are used or operated incorrectly, or have not been properly maintained.
When the machines are used in non-industrial areas, the installation location must be protected against unauthorized access (protective fencing, appropriate signs).

Prerequisites

Those responsible for protecting the plant must ensure the following:

- The basic planning work for the plant and the transport, assembly, installation, commissioning, maintenance, and repair work is carried out by qualified personnel and/or checked by experts responsible.
- The operating manual and machine documentation are always available.
- The technical specifications regarding the applicable installation, connection, environmental, and operating conditions are always observed.
- The plant-specific assembly and safety guidelines are observed and personal protection equipment is used.
- Unqualified personnel are forbidden from using these machines and working near them.

This operating manual is intended for qualified personnel and only contain information and notes relating to the intended purpose of the machines.

The operating manual and machine documentation are written in different languages as specified in the delivery contracts.

Note

We recommend engaging the support and services of your local Siemens service center for all planning, installation, commissioning and maintenance work.

1.3 Components that can be destroyed by electrostatic discharge (ESD)

CAUTION

The board contains components that can be destroyed by electrostatic discharge. These components can be easily destroyed if not handled properly. If you do have to use electronic boards, however, please observe the following:

- You should only touch electronic boards if absolutely necessary.
- When you touch boards, however, your body must be electrically discharged beforehand.
- Boards must not come into contact with highly insulating materials (such as plastic parts, insulated desktops, articles of clothing manufactured from man-made fibers).
- Boards must only be placed on conductive surfaces.
- Boards and components should only be stored and transported in conductive packaging (such as metalized plastic boxes or metal containers).
- If the packaging material is not conductive, the boards must be wrapped with a conductive packaging material (such as conductive foam rubber or household aluminum foil).

The necessary ESD protective measures are clearly illustrated in the following diagram:

- a = conductive floor surface
- b = ESD table
- c = ESD shoes
- d = ESD overall
- e = ESD wristband
- f = cabinet ground connection
- g = contact with conductive flooring




Figure 1-1 ESD protective measures

1.3 Components that can be destroyed by electrostatic discharge (ESD)

Residual risks of power drive systems

When carrying out a risk assessment of the machine/plant in accordance with the EU Machinery Directive, the machine manufacturer/plant operator must consider the following residual risks associated with the control and drive components of a power drive system (PDS).

1. Unintentional movements of driven machine components during commissioning, operation, maintenance, and repairs caused by, for example:
 - Hardware defects and/or software errors in the sensors, controllers, actuators, and connection technology
 - Response times of the controller and drive
 - Operating and/or ambient conditions not within the scope of the specification
 - Parameterization, programming, cabling, and installation errors
 - Use of radio devices / cellular phones in the immediate vicinity of the controller
 - External influences / damage
2. Exceptional temperatures as well as emissions of light, noise, particles, or gas caused by, for example:
 - Component malfunctions
 - Software errors
 - Operating and/or ambient conditions not within the scope of the specification
 - External influences / damage
3. Hazardous shock voltages caused by, for example:
 - Component malfunctions
 - Influence of electrostatic charging
 - Induction of voltages in moving motors
 - Operating and/or ambient conditions not within the scope of the specification
 - Condensation / conductive contamination
 - External influences / damage
4. Electrical, magnetic and electromagnetic fields generated in operation that can pose a risk to people with a pacemaker, implants or metal replacement joints, etc. if they are too close.
5. Release of environmental pollutants or emissions as a result of improper operation of the system and/or failure to dispose of components safely and correctly.

For more information about residual risks of the Power Drive System components, see the relevant chapters in the technical user documentation.

1.3 Components that can be destroyed by electrostatic discharge (ESD)

 **WARNING**

Electromagnetic fields "electro smog"

Electromagnetic fields are generated by the operation of electrical power engineering installations such as transformers, converters or motors.

Electromagnetic fields can interfere with electronic devices, which could cause them to malfunction. For example, the operation of heart pacemakers can be impaired, potentially leading to damage to a person's health or even death. It is therefore forbidden for persons with heart pacemakers to enter these areas.

The plant operator is responsible for taking appropriate measures (labels and hazard warnings) to adequately protect operating personnel and others against any possible risk.

- Observe the relevant nationally applicable health and safety regulations. In Germany, "electromagnetic fields" are subject to regulations BGV B11 and BGR B11 stipulated by the German statutory industrial accident insurance institution.
- Display adequate hazard warning notices.



- Place barriers around hazardous areas.
- Take measures, e.g. using shields, to reduce electromagnetic fields at their source.
- Make sure that personnel are wearing the appropriate protective gear.

1.3 Components that can be destroyed by electrostatic discharge (ESD)

2

Device Overview

2.1 Chapter content

This chapter provides information on the following:

- Introduction to the cabinet units
- The main components and features of the cabinet unit
- The cabinet unit wiring
- Explanation of the type plate

2.2 Applications, features, and design

2.2.1 Field of applications

SINAMICS G150 drive converter cabinet units are specially designed to meet the requirements of drives with a quadratic and constant load characteristic, medium performance requirements, and no regenerative feedback. Applications include:

- Pumps and fans
- Compressors
- Extruders and mixers
- Mills

2.2.2 Characteristics, quality, service

Features

The accuracy of sensorless vector control ensures that the system can be used for a wide variety of applications and, as a result, an additional speed sensor is not required.

Optionally, applications with system-specific requirements for an encoder can use an encoder evaluator.

SINAMICS G150 takes this into account and, as a result, offers a low-cost drive solution tailored to actual requirements.

2.2 Applications, features, and design

In addition, factors have been considered to ensure easy handling of the drive from the planning and design phase through to operation. These factors include:

- Compact, modular, service-friendly design
- Straightforward planning and design thanks to the Sizer and Starter tools
- Ready to connect to facilitate the installation process
- Quick, menu-driven commissioning with no complex parameterization
- Clear and convenient operation via a user-friendly graphical operator panel with measured values displayed in plain text or in a quasi-analog bar display.
- SINAMICS is an integral part of Totally Integrated Automation (TIA). The TIA concept offers an optimized range of products for automation and drive technology. This concept is characterized by planning / design, communication, and data management procedures that are consistent throughout the product range. SINAMICS is totally integrated in the TIA concept.
Separate S7/PCS7 blocks and faceplates for WinCC are available.
- Integration in SIMATIC H systems is possible via a Y link.
- Drive Control Chart (DCC)
Drive Control Chart (DCC) expands the facility for the simplest possible configuring of technological functions for the SINAMICS drive system.
The block library encompasses a large selection of closed-loop, arithmetic and logic function blocks, as well as more comprehensive open-loop and closed-loop control functions. The user-friendly DCC editor enables easy graphical configuration and a clear representation of control loop structures as well as a high degree of reusability of existing diagrams. DCC is an add-on to the STARTER commissioning tool.

Quality

The SINAMICS G150 drive converter cabinet units are manufactured to meet high standards of quality and exacting demands.

This results in a high level of reliability, availability, and functionality for our products.

The development, design, and manufacturing processes, as well as order processing and the logistics supply center have been certified to DIN ISO 9001 by an independent authority.

Service

Our worldwide sales and service network offers our customers consulting services tailored to their needs, provides support with planning and design, and offers a range of training courses.

For detailed contact information and the current link to our Internet pages, refer to chapter "Diagnosis / faults and alarms", section "Service and Support".

2.3 Design

The SINAMICS G150 cabinet units are characterized by their compact, modular, and service-friendly design.

A wide range of electrical and mechanical components enable the drive system to be optimized for the appropriate requirements.

Two cabinet unit versions are available depending on the options that are chosen.

2.3.1 Version A

All the required power supply connection components, such as the main circuit breaker, circuit breakers, main contactor, line fuses, radio interference suppression filter, motor components, and additional protection and monitoring devices, can be installed as required.

The cabinet unit comprises up to two cabinet panels with a total width of between 800 and 1600 mm, depending on the output, and 3200 mm for units connected in parallel.




Figure 2-1 Example of the cabinet unit, version A (e.g., 132 kW, 400 V 3 AC) (layout and components shown may vary according to version)

2.3 Design

Version A, units connected in parallel

For very high power ratings, the cabinet drive comprises two cabinet units that combined drive a motor in a parallel connection:

- For 380 V – 480 V 3 AC:
6SL3710-2GE41-1AAx, 6SL3710-2GE41-4AAx, 6SL3710-2GE41-6AAx
- For 500 V – 600 V 3 AC:
6SL3710-2GF38-6AAx, 6SL3710-2GF41-1AAx, 6SL3710-2GF41-4AAx
- For 660 V – 690 V 3 AC:
6SL3710-2GH41-1AAx, 6SL3710-2GH41-4AAx, 6SL3710-2GH41-5AAx




Figure 2-2 Example of the cabinet drive, version A (e.g., 1500 kW, 690 V 3 AC) (layout and components shown may vary according to version)

Special features when connecting-up and operating units connected in parallel

The DC links of the sub-cabinets connected in parallel must always be interconnected and the connecting cables between the two sub-cabinets (cable numbers -W001 and -W002) must be connected.

The cabinet drive units can be connected to the line supply in either a 6-pulse or 12-pulse connection.

For a 12-pulse connection, the following special considerations must be taken into account:

- The 12-pulse connection to the line supply is only possible using a double-tier transformer with three winding systems. Transformer vector groups Dy5d0 or Dy11d0 should preferably be selected. When using sub-windings that are electrically offset with respect to one another, the line harmonics are reduced with respect to the 6-pulse infeed.

Requirements for the transformer:

- The no-load voltages of both secondary windings must not differ from each other by more than 0.5% (with reference to the rated voltage).
- The differences between the short-circuit voltages of the two secondary windings must be less than 5% of the rated value.
- The minimum short-circuit voltage of the transformer should be 4%.
- The checkback contacts of the main contactors and the circuit breakers are connected in series in the factory and wired to digital input 5 of the Control Unit. When the drive unit is being commissioned, the checkback signal monitoring function must be activated. This is realized using parameter $p0860\{\text{VECTOR}\} = 722.5\{\text{CONTROL_UNIT}\}$.

Motors with two electrically isolated winding systems and also motors with one winding system can be used.

- When connecting a motor with one winding system, the following special considerations must be taken into account:
 - The motor connections of the Power Modules can be connected to one another at the motor per phase. Parameter p7003 (winding system) must be set to "0" (one winding system).
 - If a motor reactor is not being used (option L08), observation of the minimum cable lengths is mandatory (refer to the section titled "Electrical installation").
- When connecting a motor with separate winding systems, the following special considerations must be taken into account:
 - Every Power Module motor connection must be connected to its own winding system. Parameter p7003 (winding system) must be set to "1" (multiple separate winding systems or motors).
 - Motors with 30 ° offset windings cannot be operated



DANGER

During connection, installation and repair work on units connected in parallel, it must be ensured that both sub-cabinets are electrically disconnected from the power supply.

2.3 Design

2.3.2 Version C

This version is particularly compact in design with an in-built line reactor.

It can be used, for example, when the power supply connection components, such as the main contactor and main circuit-breaker with fuses for conductor protection and semi-conductor protection, are installed in an existing central low-voltage distribution unit.

Line fuses are required for conductor protection (VDE 636, Part 10). Line fuses can also be used to protect the semi-conductors of the line-commutated converter (VDE 636, Part 40/ EN 60 269-4).

The cabinet unit simply comprises a single cabinet with a width of 400 mm, 600 mm, or 1000 mm.





Figure 2-3 Example of the cabinet drive, version C (e.g., 315 kW, 690 V 3 AC) (layout and components shown may vary according to version)

2.4 Wiring Principle

Wiring principle: versions A and C




1) The main switch, fuse and main contactor functions are performed by a circuit breaker for output currents $> 800\text{ A}$.

Figure 2-4 Wiring principle: versions A and C

2.4 Wiring Principle


Circuit principle for version A, units that are connected in parallel with 6-pulse infeed, motor with one winding system



1) The functions mains switch, fuses and line contactor are implemented by means of a circuit breaker for output current of > 800 A.

Figure 2-5 Circuit principle for version A, units that are connected in parallel, 6-pulse infeed, connected to one motor with one winding system

Circuit principle for version A, units that are connected in parallel with 6-pulse infeed, motor with separate winding systems




1) The main switch, fuse and main contactor functions are performed by a circuit breaker for circuit breaker for output currents ≥ 1500 A.

Figure 2-6 Circuit principle for version A, units that are connected in parallel, 6-pulse infeed, connected to one motor with separate winding systems

2.4 Wiring Principle


Circuit principle for version A, units that are connected in parallel with 12-pulse infeed, motor with one winding system



1) The main switch, fuse and main contactor functions are performed by a circuit breaker for circuit breaker for output currents ≥ 1500 A.

Figure 2-7 Circuit principle for version A, units that are connected in parallel, 12-pulse infeed, connected to one motor with one winding system

Circuit principle for version A, units that are connected in parallel with 12-pulse infeed, motor with separate winding systems



1) The main switch, fuse and main contactor functions are performed by a circuit breaker for circuit breaker for output currents ≥ 1500 A.

Figure 2-8 Circuit principle for version A, units that are connected in parallel, 12-pulse infeed, connected to one motor with separate winding systems

NOTICE

The PE connection at the motor must be fed back directly to the cabinet unit.

2.5 Type plate

2.5 Type plate

Specifications on the type plate

SIEMENS

FREQUENZUMRICHTER / AC DRIVE
SINAMICS G150 ← Device designation

| | | | | | | | | |
|---|--|-----|------|---|------|----|-----|---------------------------------|
| ① | Input: Eingang: | 3AC | 380 | - | 480 | V | 519 | A |
| ② | Output: Ausgang: | 3AC | 0 | - | 480 | V | 490 | A |
| ③ | Temperature range : Temperaturbereich : | | + 0 | - | + 40 | °C | ⑤ | Duty class: I Bel. - Klasse: |
| ④ | Degree of protection : Schutzart: | | IP21 | | | | ⑥ | Cooling method: AF Kühlart: |
| | | | | | | | ⑦ | Weight: 510 kg Gewicht: |

| | | |
|---------------------------------|----|--------------------------------------|
| Order number: Bestellnummer: | 1P | 6SL3710-1GE35-0AA0-Z |
| | | L00+L26+M21 ← List of device options |

| | |
|------------------------------------|---------------------|
| Serial number: Fabrik - Nummer: | *SNV51205742010001* |
| | S N-V51205742010001 |

| | | | | | | | | |
|----------------------|-----|---|-----|--|--|--|--|---|
| Version: Version: | 2PE | D | *D* | | | | | ↑↑ Month of manufacture Year of manufacture |
|----------------------|-----|---|-----|--|--|--|--|---|

Made in EU (Germany)

Figure 2-9 Type plate for the cabinet unit

Type plate specifications (from type plate above)

| Position | Specification | Value | Description |
|----------|--------------------------|------------------------------|---|
| ① | Input | 3 AC 380 – 480 V 519 A | Three-phase connection Rated input voltage Rated input current |
| ② | Output | 3 AC 0 – 480 V 490 A | Three-phase connection Rated output voltage Rated output current |
| ③ | Temperature range | 0 – 40 °C | Ambient temperature range within which the enclosed drive can operate under 100 % load |
| ④ | Degree of protection | IP21 | Degree of protection |
| ⑤ | Duty class load class | I | I: Duty class I to EN 60146-1-1 = 100 % (continuously) (with the specified current values, the cabinet unit can operate continuously under 100 % load) |
| ⑥ | Cooling method | AF | A: Cooling medium: air F: Circulation method: forced cooling, drive unit (fan) in the device |
| ⑦ | Weight | 519 kg | Weight of the enclosed drive |

Date of manufacture

The date of manufacture can be determined as follows:

Table 2- 1 Production year and month

| Letter/number | Year of manufacture | Letter/number | Month of manufacture |
|---------------|---------------------|---------------|----------------------|
| S | 2004 | 1 to 9 | January to September |
| T | 2005 | O | October |
| U | 2006 | N | November |
| V | 2007 | D | December |
| W | 2008 | | |
| X | 2009 | | |
| A | 2010 | | |
| B | 2011 | | |
| C | 2012 | | |
| D | 2013 | | |
| E | 2014 | | |

2.5 Type plate

Explanation of the option short codes

Table 2- 2 Explanation of the option short codes

| | | Version A | Version C |
|--|---|-----------|-----------|
| Input options | | | |
| L00 | Line filter for use in the first environment to EN 61800-3, category C2 (TN/TT systems) | ✓ | - |
| L01 | Clean Power version with integrated Line Harmonics Filter compact | ✓ | - |
| L13 | Main contactor | ✓ | - |
| L22 | Line reactor not included in scope of delivery | ✓ | ✓ |
| L23 | Line reactor uk = 2% | ✓ | ✓ |
| L26 | Main circuit breaker (incl. fuses/circuit breakers) | ✓ | - |
| Output options | | | |
| L07 | dV/dt filter compact plus Voltage Peak Limiter | ✓ | - |
| L08 | Motor reactor | ✓ | - |
| L10 | dv/dt filter plus Voltage Peak Limiter | ✓ | - |
| L15 | Sine-wave filter (for 380 V – 480 V 3 AC up to 250 kW and for 500 V – 600 V 3 AC up to 132 kW only) | ✓ | - |
| Input and output options | | | |
| M70 | EMC shield bus | ✓ | ✓ |
| M75 | PE busbar | ✓ | ✓ |
| Motor protection and safety functions | | | |
| L45 | EMERGENCY OFF pushbutton installed in the cabinet door | ✓ | - |
| L57 | EMERGENCY OFF category 0, 230 V AC or 24 V DC | ✓ | - |
| L59 | EMERGENCY STOP category 1, 230 V AC | ✓ | - |
| L60 | EMERGENCY STOP category 1, 24 V AC | ✓ | - |
| L83 | Thermistor motor protection unit (alarm) | ✓ | - |
| L84 | Thermistor motor protection unit (shutdown) | ✓ | - |
| L86 | PT100 evaluation unit | ✓ | - |
| L87 | Insulation monitoring | ✓ | - |
| M60 | Additional shock protection | ✓ | ✓ |
| Increase in degree of protection | | | |
| M21 | Degree of protection IP21 | ✓ | ✓ |
| M23 | Degree of protection IP23 | ✓ | ✓ |
| M43 | Degree of protection IP43 | ✓ | ✓ |
| M54 | Degree of protection IP54 | ✓ | ✓ |
| Mechanical options | | | |
| M06 | Base 100 mm high, RAL 7022 | ✓ | ✓ |
| M07 | Cable compartment 200 mm high, RAL 7035 | ✓ | ✓ |
| M13 | Line connection from above | ✓ | - |
| M78 | Motor connection from above | ✓ | - |
| M90 | Crane transport assembly (top-mounted) | ✓ | ✓ |

| | | Version A | Version C |
|--|--|-----------|-----------|
| Other options | | | |
| G20 | CBC10 Communication Board | ✓ | ✓ |
| G33 | CBE20 Communication Board | ✓ | ✓ |
| G60 | TM31 customer terminal block | ✓ | ✓ |
| G61 | Customer terminal block extension TM31 | ✓ | - |
| K50 | Sensor Module Cabinet-Mounted SMC30 | ✓ | ✓ |
| K51 | VSM10 Voltage Sensing Module Cabinet-Mounted | ✓ | - |
| K82 | Terminal module for controlling the "Safe Torque Off" and "Safe Stop 1" safety functions | ✓ | - |
| L19 | Connection for external auxiliary equipment | ✓ | - |
| L50 | Cabinet illumination with service socket | ✓ | - |
| L55 | Cabinet anti-condensation heating | ✓ | ✓ |
| L61 | 25 kW / 125 kW braking unit | ✓ | - |
| L62 | 50 kW / 250 kW braking unit | ✓ | - |
| Y09 | Special paint finish for cabinet | ✓ | ✓ |
| Documentation (standard: English / German) | | | |
| D02 | Customer documentation (circuit diagram, terminal diagram, layout diagram) in DXF format | ✓ | ✓ |
| D04 | Customer documentation as hard copy | ✓ | ✓ |
| D14 | Draft of customer documentation | ✓ | ✓ |
| D58 | Documentation language: English / French | ✓ | ✓ |
| D60 | Documentation language: English / Spanish | ✓ | ✓ |
| D80 | Documentation language: English / Italian | ✓ | ✓ |
| Languages (standard: English / German) | | | |
| T58 | Rating plate data in English / French | ✓ | ✓ |
| T60 | Rating plate data in English / Spanish | ✓ | ✓ |
| T80 | Rating plate data in English / Italian | ✓ | ✓ |
| Industry-specific options (chemicals) | | | |
| B00 | NAMUR terminal block | ✓ | - |
| B02 | Electrically separated 24 V power supply (PELV) | ✓ | - |
| B03 | Outgoing section for external auxiliary equipment (uncontrolled) | ✓ | - |
| Options specific to the shipbuilding industry | | | |
| M66 | Marine version | ✓ | ✓ |
| E11 | Individual certificate from Germanischer Lloyd (GL) | ✓ | ✓ |
| E21 | Individual certificate from Lloyds Register (LR) | ✓ | ✓ |
| E31 | Individual certificate from Bureau Veritas (BV) | ✓ | ✓ |
| E51 | Individual certificate from Det Norske Veritas (DNV) | ✓ | ✓ |
| E61 | Individual certificate from American Bureau of Shipping (ABS) | ✓ | ✓ |

2.5 Type plate

| | | Version A | Version C |
|---|---|-----------|-----------|
| Converter acceptance on customer absence (not shown on the type plate) | | | |
| F03 | Visual acceptance | ✓ | ✓ |
| F71 | Function test of the converter without motor connected | ✓ | ✓ |
| F75 | Function test of the converter with test bay motor (no load) | ✓ | ✓ |
| F77 | Insulation test on converter | ✓ | ✓ |
| F97 | Customer-specific converter acceptance inspections (on request) | ✓ | ✓ |

✓ indicates that this option is available for that version.

– indicates that this option is not available for that version.

Mechanical installation

3.1 Chapter content

This chapter provides information on the following:

- The conditions for transporting, storing, and installing the cabinet unit
- Preparing and installing the cabinet unit

3.2 Transportation and storage

Transportation

WARNING

The following must be taken into account when the devices are transported:

- The devices are heavy. Their center of gravity is displaced and they can be top heavy.
- Suitable hoisting gear operated by trained personnel is essential due to the weight of the devices.
- The devices must only be transported in the upright position indicated. The devices must not be transported upside down or horizontally.
- Serious injury or even death and substantial material damage can occur if the devices are not lifted or transported properly.

Note

Notes regarding transportation

- The devices are packaged by the manufacturer in accordance with the climatic conditions and stress encountered during transit and in the recipient country.
- The notes on the packaging for transportation, storage, and proper handling must be observed.
- For transportation using forklifts, the devices must be set down on a wooden pallet.
- When the devices are unpacked, they can be transported using the optional transport eyebolts (option M90) or rails on the cabinet unit. The load must be distributed evenly. Heavy blows or impacts must be avoided during transit and when the devices are being set down, for example.
- Shock / tilt indicators are affixed to the packaging to detect unacceptable impact or tilting of the cabinet unit during transport (see Chapter "Transport Indicators").
- Permissible ambient temperatures:
Ventilation: -25°C to +70°C, class 2K3 to IEC 60 721-3-2
Down to -40°C for max. 24 hours

3.2 Transportation and storage

Note

Notes regarding damage in transit

- Carry out a thorough visual inspection of the device before accepting the delivery from the transportation company.
- Ensure that you have received all the items specified on the delivery note.
- Notify the transportation company immediately of any missing components or damage.
- If you identify any hidden defects or damage, contact the transportation company immediately and ask them to examine the device.
- If you fail to contact them immediately, you may lose your right to claim compensation for the defects and damage.
- If necessary, you can request the support of your local Siemens office.

WARNING

Damage in transit indicates that the device was subject to unreasonable stress. The electrical safety of the device can no longer be ensured.

Non-observance can result in death, severe personal injury or substantial property damage.

Storage

The devices must be stored in clean, dry rooms. Temperatures between -25°C and $+70^{\circ}\text{C}$ are permissible. Temperature variations greater than 20 K per hour are not permitted.

If the cabinet is stored for a prolonged period once it has been unpacked, cover it or take other appropriate measures to ensure that it does not become dirty and that it is protected against environmental influences. If such measures are not taken, the warranty becomes invalid in the event of a claim for damages.

WARNING

The device should not be stored for more than two years. If the device is stored for more than two years, the DC link capacitors of the devices must be reformed during commissioning.

The reforming procedure is described in "Maintenance and servicing".

CAUTION

Do not apply mechanical loads to the hoods!

The hoods are delivered separately and must be installed on site.

The hoods must not be subjected to mechanical loads; otherwise they could be destroyed.

3.3 Assembly

 **WARNING**

To ensure that the devices operate safely and reliably, they must be properly installed and commissioned by qualified personnel, taking into account the warnings provided in these operating instructions.

In particular, the general and national installation and safety guidelines for high-voltage installations (e.g. VDE – the Union of German Technical Engineers) as well as the guidelines relating to the proper use of tools and personal protective equipment must be observed.

Death, serious injury, or substantial material damage can result if these factors are not taken into account.

3.3 Assembly

3.3.1 Mechanical installation: checklist

Use the following checklist to guide you through the mechanical installation procedure for the cabinet unit. Read the "Safety instructions" section at the start of these Operating Instructions before you start working on the device.

Note

Check the boxes accordingly in the right-hand column if the activity applies to the cabinet unit in your scope of supply. In the same way, check the boxes once you have finished the installation procedure to confirm that the activities are complete.

| Item | Activity | Yes | Completed |
|------|---|--------------------------|--------------------------|
| 1 | Check the shipping and handling monitors prior to assembly. See "Mechanical installation / Shipping and handling monitors". | <input type="checkbox"/> | <input type="checkbox"/> |
| 2 | The ambient conditions must be permissible. See "Technical specifications/General technical specifications". The cabinet unit must be firmly attached to the fixing points provided. With version C with a width of 400 mm, the cabinet unit can, if required, be secured to a non-flammable vertical surface by means of the wall support supplied (see "Mechanical installation/preparation"). The cooling air can flow unobstructed. | <input type="checkbox"/> | <input type="checkbox"/> |
| 3 | The minimum ceiling height (for unhindered air outlet) specified in the Operating Instructions must be observed. The cooling air supply must be not be obstructed (see "Mechanical installation/preparation"). | <input type="checkbox"/> | <input type="checkbox"/> |
| 4 | Transport units separately shipped must be connected to one another (refer to Chapter "Mechanical installation / Mechanically connecting separately shipped transport units"). | <input type="checkbox"/> | <input type="checkbox"/> |
| 5 | Components that are supplied separately for transport reasons (canopy or hood) must be fitted (see "Mechanical installation/Fitting additional canopies (option M21) or hoods (option M23/M43/M54)"). | <input type="checkbox"/> | <input type="checkbox"/> |
| 6 | The clearance around an open door (escape route) specified in the applicable accident prevention guidelines must be observed. | <input type="checkbox"/> | <input type="checkbox"/> |
| 7 | With option M13/M78: Choose the required metric screw connections or conduit thread connections on the basis of the cable cross-section and drill the required holes in the blanking plates. When the cable is fed in from above, ensure that enough room is available if the cable has to be bent because of the cable feeder and cross-sections. The cable entries should be fed in vertically to minimize transverse forces on the entries (see "Mechanical installation / line connection from above (option M13), motor connection from above (option M78)"). | <input type="checkbox"/> | <input type="checkbox"/> |

3.3.2 Preparatory steps

On-site requirements

The cabinet units are designed for installation in closed, electrical operating areas in compliance with EN 61800-5-1. A closed electrical operating area is a room or area containing electrical equipment which can be accessed by trained personnel only. Access is controlled by a door or other form of barricade which can be opened only by means of a key or other tool. The room or area is also clearly signed with appropriate warning notices.

The operating areas must be dry and free of dust. The air supplied must not contain any electrically conductive gas, vapors, or dust, which could impair operation. It may be necessary to filter the air supplied to the installation room. If the air contains dust, filter mats (option M54) can be installed in front of the ventilation grilles in the cabinet doors and also in front of the hoods, if necessary. Option M54 offers additional protection against water sprayed against the housing from any direction and corresponds to degree of protection IP54.

The permissible values for climatic ambient conditions must be taken into account.

At temperatures > 40°C (104°F) and altitudes > 2000 m, the devices must be derated.

The basic version of the cabinet units complies with the IP20 degree of protection in accordance with EN 60529.

The built-in units are installed in accordance with the dimension drawings supplied. The clearance between the top of the cabinet unit and the ceiling is also specified on the dimension drawings.

The cooling air for the power unit is drawn in from the front through the ventilation grilles in the lower part of the cabinet doors. The warmed air is expelled through the perforated top cover or the ventilation grilles in the top cover (with option M13/M23/M43/M54/M78). Cooling air can also be supplied from below through raised floors or air ducts, for example. To allow this, openings must be made in the 3-section bottom plate or plates must be removed.

According to EN 61800-3, the cabinet units are not suitable for use in low-voltage public networks that supply residential buildings. High-frequency interference may occur if it is used in this type of network.

Additional measures (e.g. line filter, option L00) can be fitted for use in the first environment to EN 61800-3 category C2.

Unpacking the cabinets

Check the delivery against the delivery note to ensure that all the items have been delivered. Check that the cabinet is intact.

The packaging material must be discarded in accordance with the applicable country-specific guidelines and rules.

3.3 Assembly

Required tools

To install the connections, you will require:

- Spanner or socket spanner (w/f 10)
- Spanner or socket spanner (w/f 13)
- Spanner or socket spanner (w/f 16/17)
- Spanner or socket spanner (w/f 18/19)
- Hexagon-socket spanner (size 8)
- Torque wrench from 5 Nm to 50 Nm
- Screwdriver, size 2
- Screwdriver Torx T20
- Screwdriver Torx T30

3.3.3 Shipping and handling monitors

The cabinet units are equipped with tilt and shock indicators to monitor for damage during transit.



Figure 3-1 Tilt indicator



Figure 3-2 Shock indicator

Position of the shipping and handling monitors

The tilt indicators are affixed to the top of the cabinet unit inside the doors.

The shock indicators are affixed to the bottom of the cabinet unit inside the doors.

Checking the shipping and handling monitors prior to commissioning

It is essential to check the shipping and handling monitors prior to commissioning the converter.



Figure 3-3 Tilt indicator tripped

The tilt indicator provides immediate visible evidence of whether the cabinet units have been handled and stored upright. Blue-colored quartz sand begins to flow into the arrow-shaped indicator area. The tilt indicator has tripped when the blue color extends beyond the middle line of the arrowhead.



Figure 3-4 Shock indicator tripped

The shock indicator shows if an acceleration has exceeded 98.1 m/s^2 ($10 \times g$) and indicates the direction of acceleration. The black color of the arrows indicates that an impermissible shock load has occurred in the direction of the arrow.

3.3 Assembly

 **WARNING**

Inform Technical Support (hotline)

Commissioning must not be carried out, if an indicator has tripped. Contact Technical Support immediately.

The contact data are provided in the preface to this document.

If commissioning is carried out without prior inspection of the indicators, safe operation of the converter cannot be guaranteed. This can result in death, serious personal injury or material damage.

Removing the shipping and handling monitors prior to commissioning

CAUTION

The shipping and handling monitors must be removed before commissioning the converter.

Failure to observe the transport indicators during operation of the converter may cause damage to the equipment.

3.3.4 Installation

Lifting the cabinet off the transport pallet

The applicable local guidelines regarding the transportation of the cabinet from the transport palette to the installation location must be observed.

A crane transport assembly (option M90) can also be fitted on the top of the cabinet.

The fixing screws on the transport pallet can be removed from the pallet base without having to raise the cabinet unit. The positions of the fixing screws are indicated by red markings on the outside of the pallets.

Installation

Four holes for M12 screws are provided on each cabinet panel to secure the cabinet to the ground. The fixing dimensions are specified on the dimension drawings enclosed.

Two wall supports for attaching the top of the cabinet to the wall are also supplied for 400 mm-wide cabinets to provide extra security.

3.3.5 Mechanical connection of units that are connected in parallel

The following cabinet units (units connected in parallel) are supplied in two separate transport units:

- 380 V – 480 V 3 AC:
6SL3710-2GE41-1AAx, 6SL3710-2GE41-4AAx, 6SL3710-2GE41-6AAx
- 500 V – 600 V 3 AC:
6SL3710-2GF38-6AAx, 6SL3710-2GF41-1AAx, 6SL3710-2GF41-4AAx
- 660 V – 690 V 3 AC:
6SL3710-2GH41-1AAx, 6SL3710-2GH41-4AAx, 6SL3710-2GH41-5AAx

The left-hand sub-cabinet has the locator code "+H.A24" and "+H.A49" and the right-hand sub-cabinet has the locator code "+H.A25" and "+H.A50". The cabinet operator panel is also mounted here.

Numerous connectors are provided attached loose with the equipment to mechanically connect the two sub-cabinets. These connectors should be attached and as far as possible evenly distributed.

3.3.6 Fitting additional canopies (option M21) or hoods (option M23, M43, M54)

To increase the degree of protection of the cabinets from IP20 (standard) to IP21, IP23, IP43, or IP54, additional canopies or hoods are supplied. These must be fitted once the cabinets have been installed.

Description

The degree of protection can be increased to IP21 by fitting an additional canopy. The canopy is mounted protruding above the cabinet on spacers, 250 mm above the top cover of the cabinet. As a result, cabinets with a canopy are 250 mm higher.

Cabinet units with degree of protection IP23 are supplied with additional hoods, as well as plastic ventilation grilles and braided plastic in the air inlet (doors) and outlet (hoods). The hoods are flush with the cabinets at the side and front and have a recess at the rear so that air can escape even if the cabinet is wall mounted. Air escapes from the front and back. The hood is secured via the four crane hook holes in the cabinet. Hoods increase the height of the cabinet by 400 mm.

Cabinet units with degree of protection IP43 are supplied with additional hoods, as well as plastic ventilation grilles and close-meshed braided plastic in the air inlet (doors) and outlet (hoods). The hoods are flush with the cabinets at the side and front and have a recess at the rear so that air can escape even if the cabinet is wall mounted. Air escapes from the front and back. The hood is secured via the four crane hook holes in the cabinet. Attaching the hoods increases the height of the cabinet units by 400 mm.

Compliance with degree of protection IP43 requires an intact filter medium, which must be serviced on a regular basis according to the prevailing ambient conditions.

3.3 Assembly

Cabinet units with degree of protection IP54 are supplied with additional hoods, plastic ventilation grilles, and a filter medium in the air inlet (doors) and outlet (hoods). The hoods are flush with the cabinets at the side and front and have a recess at the rear so that air can escape even if the cabinet is wall mounted. Air escapes from the front and back. The hood is secured via the four crane hook holes in the cabinet. Hoods increase the height of the cabinet by 400 mm.

Compliance with degree of protection IP54 requires an intact filter medium, which must be replaced on a regular basis according to the prevailing ambient conditions. Filters can be fitted and replaced from outside the cabinet relatively easily.

Attaching a canopy to increase the degree of protection to IP21 (option M21)




Figure 3-5 Fitting a canopy

The canopy ② can be mounted variably in both directions (on the side and, to the front and back) on the top of the cabinet.

The arrangement can be adapted to the various installation conditions for the cabinets. This produces an adjustable protrusion of the canopy at the front ① and back ③.

In this way, it is possible to have a circumferential protrusion of the canopy, or direct contact with the wall or between the canopies in back-to-back installation. If necessary, the contact point with the wall or back-to-back installation must be sealed.

- Remove any existing crane transport assemblies.
- Attach the spacers (A) to the roof of the cabinet at the positions specified.
Tighten the screws ④ with contact discs applied from the bottom through the protective guard (tightening torque: 13 Nm for M6).

Note

The protective guard is fastened to the cabinet unit from the top using four screws. To facilitate assembly, it may be necessary to remove the protective guard, which must be reattached on completion of assembly work.

- Attach the canopy (B) to the spacers.
Tighten the screws ⑤ with contact discs applied from the top through the canopy (tightening torque: 13 Nm for M6).

NOTICE

There are overlaps on the sides of the canopies to prevent water dripping into the spaces between cabinet units connected in series. When fitting the canopies, make sure these overlaps interlock.

3.3 Assembly

Fitting a hood to increase the degree of protection to IP23/IP43/IP54 (option M23/M43/M54)




Figure 3-6 Attaching a hood

1. Remove the crane transport assembly (if fitted).
2. Make sure that a perforated top cover is not fitted on the top of the cabinet (depending on production requirements, this can be fitted at a later stage).
3. Options M43 and M54 only:
Use the sealing tape provided to attach the contact surfaces of the hood to the top of the cabinet.
4. Fit the hood to the roof of the cabinet at the positions specified (fixing points for the crane transport assembly).
5. Assemble original roof screws M12 ① from above.
6. M6 screw and washers (order: Attach the screw, spring-lock element, small washer, large washer) ② from below.
7. If the hood is very wide, use additional screws ③.

3.3.7 Line connection from above (option M13), motor connection from above (option M78)

Description

With options M13 and M78, the cabinet unit is equipped with an additional hood. The connection straps for the power cables, the clamping bar for mechanically securing the cables, an EMC shield bus, and a PE busbar are located within the hood.

The hood adds an extra 405 mm to the cabinet height. The busbars for connection from above are fully mounted when the system is delivered. For transport reasons, the hoods are delivered separately and must be mounted on site. With options M23, M43 and M54, plastic ventilation grilles and filter mats are also supplied.

A 5 mm aluminum mounting plate (with no holes) is fitted in the roof of the cover for feeding in the cables. Depending on the number of cables and the cross-sections used, holes for attaching cable glands for feeding in the cables must be drilled in this mounting plate on site.

Note

The control cables and optional brake resistors are connected as before from below.

3.3 Assembly

Attaching the Hood

1. Remove the crane transport assembly (if fitted).
2. Options M43 and M54 only:
Use the sealing tape provided to attach the contact surfaces of the hood to the top of the cabinet.
3. Fit the hood to the roof of the cabinet at the positions specified (fixing points for the crane transport assembly).
4. To secure the power cables, remove the front panel of the hood.




Figure 3-7 Attaching the hood with M13 / M78

4

Electrical installation

4.1 Chapter content

This chapter provides information on the following:

- Establishing the electrical connections for the cabinet unit
- Adjusting the fan voltage and the internal power supply to local conditions (supply voltage)
- The customer terminal block and its interfaces
- The interfaces for additional options

4.2 Checklist for electrical installation

4.2 Checklist for electrical installation

Use the following checklist to guide you through the electrical installation procedure for the cabinet unit. Read the "Safety instructions" section at the start of these Operating Instructions before you start working on the device.

Note

Check the boxes accordingly in the right-hand column if the activity applies to the cabinet unit in your scope of supply. In the same way, check the boxes once you have finished the installation procedure to confirm that the activities are complete.

| Item | Activity | Yes | Completed |
|--------------------------|--|--------------------------|--------------------------|
| Power connections | | | |
| 1 | The electrical connections of the two sub-cabinets must be established for transport units that have been shipped separately (refer to "Electrical installation / Power connections / Electrical connection of separately shipped transport units"). | <input type="checkbox"/> | <input type="checkbox"/> |
| 2 | The line-side and motor-side power cables must be dimensioned and routed in accordance with the ambient and routing conditions. The maximum permissible cable lengths between the converter and motor must be observed depending on the type of cable used (see "Electrical installation / Power connections / Connection cross-sections and cable lengths"). The correct and uniform phase sequence must be observed in both sub-cabinets when connecting cabinet units in parallel. The PE ground at the motor must be fed back directly to the cabinet unit. The cables must be properly connected with a torque of 50 Nm to the cabinet unit terminals. The cables for the motor and low-voltage switchgear must also be connected with the required torques. | <input type="checkbox"/> | <input type="checkbox"/> |
| 3 | For units connected in parallel, the connecting cables (-W001, -W002) for the DC links on the two sub-cabinets must be closed (see "Electrical installation / Power connections / Connection of DC link connectors"). | <input type="checkbox"/> | <input type="checkbox"/> |
| 4 | The cables between the low-voltage switchgear and the cabinet unit must be protected with line fuses to provide adequate conductor protection (DIN VDE 100, Part 430 and/or IEC 60364-4-43) With version C, combined fuses must be used for conductor and semi-conductor protection (EN 60269-4). See "Technical specifications" for the appropriate fuses. | <input type="checkbox"/> | <input type="checkbox"/> |
| 5 | For strain relief, the cables must be clamped on the cable propping bar (C-type mounting bar). | <input type="checkbox"/> | <input type="checkbox"/> |
| 6 | When EMC-shielded cables are used, screwed glands that connect the shield to ground with the greatest possible surface area must be provided on the motor terminal box. On the cabinet, the cables must be grounded with the clips supplied with the EMC shield bus with the greatest possible surface area (shield bus supplied with option L00 or can be ordered separately with option M70 – see "Electrical installation / EMC-compliant installation"). | <input type="checkbox"/> | <input type="checkbox"/> |
| 7 | The cable shields must be properly applied and the cabinet properly grounded at the appropriate points (see "Electrical installation / EMC-compliant installation"). | <input type="checkbox"/> | <input type="checkbox"/> |

4.2 Checklist for electrical installation

| Item | Activity | Yes | Completed |
|------|---|---|--------------------------|
| 8 | The voltage for the fan transformer (-T1-T10) for versions A and C, and the internal power supply (-A1-T10) for version A (only with option L13, L26, L83, L84, L86, L87) must be adapted to the supply voltage for the cabinet unit. Larger cabinet units have 2 fan transformers (-T1 -T10/-T20), which must be set jointly. For units connected in parallel, the fan transformers must be set jointly in each sub-cabinet (see section "Electrical installation / Power connections / Adjusting the fan voltage (-T1 -T10)" and "Electrical installation / Power connections / Adjusting the internal power supply (-A1 -T10)"). | <input type="checkbox"/> | <input type="checkbox"/> |
| 9 | Before the cabinet is operated from a non-grounded supply/IT system, the connection bracket for the basic interference suppression device must be removed (see "Electrical installation / Power connections / Removing the connection bracket for the interference suppression capacitor with operation from a non-grounded supply"). | <input type="checkbox"/> | <input type="checkbox"/> |
| 10 | The type plate can be used to ascertain the date of manufacture. If the period from the date of manufacture to initial commissioning or the cabinet unit downtime is less than two years, the DC link capacitors do not have to be re-formed. If the downtime period is longer than two years, they must be reformed in accordance with the description found in the section "Maintenance and servicing / Reforming the DC link capacitors". | <input type="checkbox"/> | <input type="checkbox"/> |
| 11 | With an external auxiliary supply, the cable for the 230 V AC supply must be connected to terminal -X40, while the cable for the 24 V DC supply must be connected to terminal -X9 (see "Electrical installation / Power connections / External supply of the auxiliary supply from a secure line"). | <input type="checkbox"/> | <input type="checkbox"/> |
| 12 | Option L07 dv/dt filter compact plus Voltage Peak Limiter During commissioning, the filter must be selected via STARTER or AOP30. You are advised to check the selection by ensuring that p0230 is set to 2. The required parameters are set automatically (see "Electrical installation / Other connections / dv/dt filter compact plus Voltage Peak Limiter (option L07)"). | <input type="checkbox"/> | <input type="checkbox"/> |
| 13 | Option L10 dv/dt filter plus Voltage Peak Limiter During commissioning, the filter must be selected via STARTER or AOP30. You are advised to check the selection by ensuring that p0230 is set to 2. The required parameters are set automatically (see "Electrical installation / Other connections / dv/dt filter plus Voltage Peak Limiter (option L10)"). | <input type="checkbox"/> | <input type="checkbox"/> |
| 14 | Option L15 Sine-wave filter During commissioning, the filter must be selected via STARTER or AOP30. You are advised to check the selection by ensuring that p0230 is set to 3. The required parameters are set automatically (see "Electrical installation / Other connections / Sine-wave filter (option L15)"). | <input type="checkbox"/> | <input type="checkbox"/> |
| 15 | Option L19 Connection for external auxiliary equipment To supply auxiliary equipment (e.g. separately-driven fan for motor), the drive must be properly connected to terminals -X155:1 (L1) to -X155:3 (L3). The supply voltage of the auxiliary equipment must match the input voltage of the cabinet unit. The load current must not exceed 10 A and must be set at -Q155 in accordance with the load connected (see "Electrical installation / Other connections / Connection for external auxiliary equipment (option L19)"). | <input type="checkbox"/> Set value: _____ | <input type="checkbox"/> |

4.2 Checklist for electrical installation

| Item | Activity | Yes | Completed | |
|---------------------------|--|---|--------------------------|--------------------------|
| 16 | Option L26 Main circuit breaker (incl. fuses/circuit breakers) | In equipment with main circuit breaker, the release current must be set to match the installation requirements (see "Electrical Installation / Other connections / Main switch incl. fuses or main circuit breaker (option L26)"). | <input type="checkbox"/> | <input type="checkbox"/> |
| 17 | Option L50 Cabinet illumination with service socket | The 230 V auxiliary supply for the cabinet illumination with an integrated service socket must be connected to terminal -X390 and protected with a fuse (max. 10 A) on the line side (see "Electrical installation / Other connections / Cabinet illumination with service socket (option L50)"). | <input type="checkbox"/> | <input type="checkbox"/> |
| 18 | Option L55 Cabinet anti-condensation heating | The 230 V auxiliary supply for the anti-condensation heating for the cabinet (230 V / 50 Hz, 100 W / or 230 V / 50 Hz 2 x 100 W for cabinets with a width of 800 to 1200 mm) must be connected to terminals -X240: 1 to 3 and protected with fuses (max. 16 A) (see "Electrical installation / Other connections / Anti-condensation heating for cabinet (option L55)"). | <input type="checkbox"/> | <input type="checkbox"/> |
| Signal connections | | | | |
| 19 | Cabinet unit operation by higher-level controller / control room. The control cables must be connected in accordance with the interface assignment and the shield applied. Taking into account electrical interference and the distance from power cables, the digital and analog signals must be routed with separate cables. | <input type="checkbox"/> | <input type="checkbox"/> | |
| 20 | Option G60 TM31 customer terminal block | Terminal Module TM31 is used to extend the customer terminals. This provides the following additional interfaces: <ul style="list-style-type: none"> • 8 digital inputs • 4 bidirectional digital inputs/outputs • 2 relay outputs with changeover contact • 2 analog inputs • 2 analog outputs • 1 temperature sensor input (KTY84-130/PTC) Integration of the interfaces takes place using pre-interconnections prepared in the factory, which can be selected during commissioning. When the analog inputs on the TM31 are used as current or voltage inputs, selectors S5.0 and S5.1 must be set accordingly (see "Electrical installation / Signal connections / Customer terminal module (-A60)"). | <input type="checkbox"/> | <input type="checkbox"/> |

4.2 Checklist for electrical installation

| Item | Activity | | Yes | Completed |
|---|---|--|--------------------------|--------------------------|
| 21 | Option K50 Sensor Module Cabinet- Mounted SMC30 | <p>The SMC30 Sensor Module is used for determining the actual motor speed.</p> <p>In conjunction with SINAMICS G150, the following encoders are supported by the SMC30 Sensor Module:</p> <ul style="list-style-type: none"> • TTL encoder • HTL encoder <p>The motor temperature can also be detected using KTY84-130 or PTC thermistors.</p> <p>In the factory setting, an HTL encoder is bipolar with 1024 pulses per revolution (see "Electrical installation / Other connections / SMC30 Sensor Module Cabinet-Mounted (option K50)").</p> | <input type="checkbox"/> | <input type="checkbox"/> |
| Connecting protection and monitoring devices | | | | |
| 22 | Option L45 EMERGENCY OFF pushbutton installed in the cabinet door | <p>The contacts for the EMERGENCY OFF pushbutton are available at terminal -X120 and can be picked off so that they can be integrated in a higher-level line-side protection concept ("Electrical installation / Other connections / EMERGENCY OFF pushbutton, integrated in the door of the cabinet unit (option L45)").</p> | <input type="checkbox"/> | <input type="checkbox"/> |
| 23 | Option L57 EMERGENCY OFF category 0, 230 V AC or 24 V DC | <p>EMERGENCY OFF category 0 stops the drive in an uncontrolled manner. No additional wiring is necessary when implemented in conjunction with option L45.</p> <p>If the cabinet unit is integrated in an external safety circuit, however, the contact must be looped in via terminal block -X120 ("Electrical installation / Other connections / EMERGENCY OFF category 0, 230 V AC / 24 V DC (option L57)").</p> | <input type="checkbox"/> | <input type="checkbox"/> |
| 24 | Option L59 EMERGENCY STOP category 1, 230 V AC | <p>EMERGENCY STOP category 1 stops the drive in a controlled manner. With this option, braking units (brake chopper and external braking resistors) may need to be fitted due to the load characteristic and to achieve the required shutdown times. No additional wiring is necessary when implemented in conjunction with option L45.</p> <p>If the cabinet unit is integrated in an external safety circuit, however, the contact must be looped in via terminal block -X120. The timer relay at -K121 must be adapted to match system requirements (see "Electrical installation / Other connections / EMERGENCY STOP category 1, 230 V AC (option L59)").</p> | <input type="checkbox"/> | <input type="checkbox"/> |
| 25 | Option L60 EMERGENCY STOP category 1, 24 V AC | <p>EMERGENCY STOP category 1 stops the drive in a controlled manner. With this option, braking units (brake chopper and external braking resistors) may need to be fitted due to the load characteristic and to achieve the required shutdown times. No additional wiring is necessary when implemented in conjunction with option L45.</p> <p>If the cabinet unit is integrated in an external safety circuit, however, the contact must be looped in via terminal block -X120. The timer relay at -K120 must be adapted to match system requirements (see "Electrical installation / Other connections / EMERGENCY STOP category 1, 24 V AC (option L60)").</p> | <input type="checkbox"/> | <input type="checkbox"/> |

4.2 Checklist for electrical installation

| Item | Activity | | Yes | Completed |
|--------------------------|---|---|--------------------------|--------------------------|
| 26 | Option L61/L62 25 kW/125 kW 50 kW/250 kW braking unit | The connecting cables and ground for the braking resistor must be connected to terminal block –X5: 1/2. A connection must be established between the braking resistor thermostatic switch and customer terminal block –A60. When commissioning via AOP30, the settings for evaluating "external fault 3" must be made. The settings for evaluating the thermostatic switch as "external fault 2" must be made (see "Electrical installation / Other connections / Braking unit 25 kW / 125 kW (option L61); braking unit 50 kW / 250 kW (option L62)"). | <input type="checkbox"/> | <input type="checkbox"/> |
| 27 | Option L83 Thermistor motor protection device (alarm) | The PTC thermistor sensors (PTC resistor type A) must be connected to the thermistor motor protection unit -F127 at terminals T1 and T2 for alarms (see "Electrical installation / Other connections / Thermistor motor protection device (option L83/L84)"). | <input type="checkbox"/> | <input type="checkbox"/> |
| 28 | Option L84 Thermistor motor protection device (shutdown) | The PTC thermistor sensors (PTC resistor type A) must be connected to the thermistor motor protection unit -F125 at terminals T1 and T2 for shutdown (see "Electrical installation / Other connections / Thermistor motor protection device (option L83/L84)"). | <input type="checkbox"/> | <input type="checkbox"/> |
| 29 | Option L86 PT100 evaluation unit | The resistor thermometers must be connected to evaluation units -B140, -B141 for the PT100 evaluation. A two-wire or three-wire system can be used here to connect the PT100 sensors. The sensors are divided into two groups (see "Electrical installation / Other connections / PT100 evaluation unit (option L86)"). This must be taken into account for the evaluation (factory setting). | <input type="checkbox"/> | <input type="checkbox"/> |
| 30 | Option L87 Insulation monitoring | The insulation monitor can only be operated from an insulated network. Only one insulation monitor can be used in an electrically-connected network. For line-side control, the signaling relays must be connected accordingly or, with individual drives (the cabinet unit is fed via a converter transformer assigned to the cabinet unit), integrated in the cabinet unit alarm train (see "Electrical installation / Other connections / Insulation monitoring (option L87)"). Point 9 must also be taken into account: "Before the cabinet is operated from an ungrounded supply/IT system, the connection bracket for the basic interference suppression device must be removed" (see "Electrical installation / Power connections / Removing the connection bracket for the interference suppression capacitor with operation from an ungrounded supply"). | <input type="checkbox"/> | <input type="checkbox"/> |
| Safety Integrated | | | | |
| 31 | Option K82 "Safe Torque Off" and "Safe Stop 1" safety functions | The terminal block -X41 must be connected line-side, the safety functions must be activated prior to use via parameter assignment, in addition an acceptance test must be performed and an acceptance log must be created (see section "Electrical installation / Other connections / Terminal module for activating "Safe Torque Off" and "Safe Stop 1" (option K82)"). | <input type="checkbox"/> | <input type="checkbox"/> |



Required tools

To install the connections, you will require:

- Spanner or socket spanner (w/f 10)
- Spanner or socket spanner (w/f 13)
- Spanner or socket spanner (w/f 16/17)
- Spanner or socket spanner (w/f 18/19)
- Hexagon-socket spanner (size 8)
- Torque wrench up to 50 Nm
- Screwdriver, size 2
- Screwdriver Torx T20
- Screwdriver Torx T30

4.3 Important safety precautions

4.3 Important safety precautions



WARNING

The cabinet units are operated with high voltages.
All connection procedures must be carried out when the cabinet is de-energized.
All work on the device must be carried out by trained personnel only.
Non-observance of these warning notices can result in death, severe personal injury or substantial property damage.

Work on an open device must be carried out with extreme caution because external supply voltages may be present. The power and control terminals may be live even when the motor is not running.

Dangerously high voltage levels are still present in the device up to five minutes after it has been disconnected due to the DC link capacitors. For this reason, the unit should not be opened until a reasonable period of time has elapsed.

Reforming the DC link capacitors:

The storage period should not exceed two years. If the device is stored for more than two years, the DC link capacitors of the devices must be reformed during commissioning. The reforming procedure is described in "Maintenance and servicing".

The operator is responsible for ensuring that the motor, converter, and other devices are installed and connected in accordance with recognized engineering practice in the country of installation and in compliance with applicable regional regulations. Special attention should be paid to cable dimensioning, fuses, grounding, shutdown, disconnection, and overcurrent protection.

If an item of protective gear trips in a branch circuit, a fault current may have been disconnected. To reduce the risk of fire or an electric shock, the current-conducting parts and other components in the cabinet unit should be inspected and damaged parts replaced. When an item of protective gear trips, the cause of the trip must be identified and rectified.

Note

The standard version of the cabinet units includes touch protection according to BGV A3 in accordance with EN 50274.

The version with option M60 features additional protective covers that offer a higher level of touch protection for current-conducting parts when the cabinet doors are open. These protective covers may have to be removed during installation and connection procedures. Once work has been completed, the protective covers must be properly refitted.

Note

On systems with a grounded phase conductor and a line voltage >600 V AC, line-side components should be installed to limit overvoltages to overvoltage category II in accordance with IEC 61800-5-1.

CAUTION

Only original DRIVE-CLiQ cables may be used for wiring the DRIVE-CLiQ nodes.

4.4 Introduction to EMC

What is meant by EMC?

Electromagnetic compatibility (EMC) describes the capability of an electrical device to function satisfactorily in an electromagnetic environment without itself causing interference unacceptable for other devices in the environment.

EMC therefore represents a quality feature for the

- Internal noise immunity: Resistance to internal electrical disturbances
- External noise immunity: resistance against external electromagnetic disturbances
- Noise emission level: environmental effects caused by electromagnetic emissions

To ensure that the cabinet unit functions satisfactorily in the system, the environment subject to interference must not be neglected. For this reason, special requirements exist regarding the structure and the EMC of the system.

Operational reliability and noise immunity

In order to achieve the greatest possible operational reliability and immunity to noise of a complete system (converter, automation, drive machines etc.), measures must be taken by the converter manufacturer and the user. Only when all these measures are fulfilled can the faultless functioning of the converter be guaranteed and the specified legal requirements (2004/108/EC) be met.

Noise emissions

Product standard EN 61800 – 3 outlines the EMC requirements for variable-speed drive systems. It specifies requirements for converters with operating voltages of less than 1000 V. Different environments and categories are defined depending on where the drive system is installed.




Figure 4-1 Definition of the first and second environments

4.4 Introduction to EMC




Figure 4-2 Definition of categories C1 to C4

Table 4- 1 Definition of the first and second environments

| Definition of the first and second environments | |
|---|---|
| First environment | Residential buildings or locations at which the drive system is connected to a public low-voltage supply network without a transformer. |
| Second environment | Industrial locations supplied by a medium-voltage network via a separate transformer. |

Table 4- 2 Definition of categories C1 to C4

| Definition of categories C1 to C4 | |
|-----------------------------------|--|
| Category C1 | Rated voltage <1000 V; unrestricted use in the first environment. |
| Category C2 | Rated voltage for stationary drive systems <1000 V; for use in the second environment. For use in the first environment only when sold and installed by skilled personnel. |
| Category C3 | Rated voltage <1000 V; use in the second environment only. |
| Category C4 | Rated voltage ≥1000 V or for rated currents ≥ 400 A in complex systems in the second environment. |

4.5 EMC compliant design

The following section provides some basic information and guidelines that will help you comply with the EMC and CE guidelines.

cabinet assembly

- Connect painted or anodized metal components using toothed self-locking screws or remove the insulating layer.
- Use unpainted, de-oiled mounting plates.
- Establish a central connection between ground and the protective conductor system (ground).

Shield gaps

- Bridge shield gaps (at terminals, circuit-breakers, contactors, and so on) with minimum impedance and the greatest possible surface area.

Using large cross-sections

- Use underground and grounding cables with large cross-sections or, better still, with litz wires or flexible cables.

Laying the motor supply cable separately

- The distance between the motor supply cable and signal cable should be > 20 cm. Do not lay signal cables and motor cables in parallel to each other.

Use anti-interference elements

- Lay an equalizing cable parallel to the control cable (the cable cross-section must be at least 16 mm^2).
- If relays, contactors, and inductive or capacitive loads are connected, the switching relays or contactors must be provided with anti-interference elements.

Cable installation

- Cables that are subject to or sensitive to interference should be laid as far apart from each other as possible.
- All cables are to be laid as close as possible to grounded enclosure parts such as mounting plates or cabinet frames. This reduces both noise radiation and interference injection.
- Reserve cores of signal and data cables must be grounded at both ends to achieve an additional shielding effect.
- Long cables should be shortened or laid in noise resistant areas to avoid additional connecting points.

4.5 EMC compliant design

- If it is impossible to avoid crossing cables, conductors or cables that carry signals of different classes must cross at right angles, especially if they carry sensitive signals that are subject to interference.
 - Class 1:
 - unshielded cables for ≤ 60 V DC
 - unshielded cables for ≤ 25 V AC
 - shielded analog signal cables
 - shielded bus and data cables
 - operator panel interfaces, incremental/absolute encoder lines
 - Class 2:
 - unshielded cables for > 60 V DC and ≤ 230 V DC
 - unshielded cables for > 25 V AC and ≤ 230 V AC
 - Class 3:
 - unshielded cables for > 230 V AC/DC and ≤ 1000 V AC/DC

Shield connection

- Shields must not be used to conduct electricity. In other words, they must not simultaneously act as neutral or PE conductors.
- Apply the shield so that it covers the greatest possible surface area. You can use ground clamps, ground terminals, or ground screw connections.
- Avoid extending the shield to the grounding point using a wire (pigtail) because this will reduce the effectiveness of the shield by up to 90%.
- Attach the shield to a shield bar directly after the line inlet into the cabinet. Insulate the entire shielded cable and route the shield up to the device connection, but do not connect it again.

I/O interfacing

- Create a low-impedance ground connection for additional cabinets, system components, and distributed devices with the largest possible cross-section (at least 16 mm^2).
- Ground unused lines at one end in the cabinet.
- Choose the greatest possible clearance between the power and signal cables (at least 20 cm). The greater the distance over which the cables are routed in parallel, the greater the clearance must be. If a sufficient clearance cannot be maintained, you must install additional shields.
- Avoid unnecessarily long cable loops.

Filtering cables

- Line supply cables and power supply cables for devices and modules may have to be filtered in the cabinet to reduce incoming or outgoing disturbances.
- To reduce emissions, the device is equipped with a radio interference suppression filter as standard (in accordance with the limit values defined in category C3). Optional filters can be fitted for use in the first environment (category C2).

Protective ground conductors

- According to EN 61800-5-1, Section. 6.3.6.7, the minimum cross-section of the protective ground conductor must conform to the local safety regulations for protective ground conductors for equipment with a high leakage current.

4.6 Electrical connection of units that are connected in parallel

Description

After the mechanical installation has been completed, the following electrical connections must be established between the right-hand and left-hand sub-cabinets for units that are connected in parallel:

- The PE buses must be connected
- Connecting the DC link connections
- The 24 V DC, 230 V AC power supply and signal cables must be connected
- The DRIVE-CLiQ topology must be connected



DANGER

During connection, installation and repair work on units that are connected in parallel, it must be ensured that both sub-cabinets are electrically disconnected from the power supply.

4.6.1 Connecting the PE busbars

Connecting the PE buses

A connector jumper is provided loose to connect the PE buses of the two sub-cabinets.

Establishing the connection

1. At the right-hand side of the left sub-cabinet release 1 x M12 nut of the PE rail, remove the nut, washer and screw.
2. At the left-hand side of the right sub-cabinet release 1 x M12 nut of the PE rail, remove the nut, washer and screw.
3. Locate the connecting jumper at the PE rails of the sub-cabinets to be connected.
4. Insert the bolts from the front into the grounding lugs of the PE buses.
5. Re-locate the washers and nuts.
6. Tighten the nuts (tightening torque: 50 Nm).

4.6 Electrical connection of units that are connected in parallel

4.6.2 Establishing the DC link connections

Connecting the DC link connections

The DC link connection on the two sub-cabinets must be made using preassembled cables; these must be connected from the left-hand sub-cabinet (+H.A49) to the right-hand sub-cabinet (+H.A25/50).

 **WARNING**

Under no circumstances may the connections be interchanged or short-circuited!

The cabinet unit will be destroyed if the DC link connections are either interchanged or short-circuited!

The following connecting cables must be connected:

- DCPS (cable number -W001 in sub-cabinet +H.A49) to +H.A25/50 DCPS
- DCNS (cable number -W002 in sub-cabinet +H.A49) to +H.A25/50 DCNS

4.6.3 Connecting the power supply and signal cables

Connecting-up the power supply and the signal cables

The connecting cables for 24 V DC and 230 V AC to supply the left-hand sub-cabinet with power and for the signal cables must be connected. Depending on the installed options, this will involve up to 3 connecting cables that must be connected from the right-hand sub-cabinet (cabinet panel +H.A25) to the lower connector sections in the left-hand sub-cabinet (cabinet panel +H.A24):

1. Connecting cable with the connector designation –A1–X97 in the lower connector section –A1–X97.
2. Connecting cable with the connector designation –A1–X98 in the lower connector section –A1–X98.
3. Connecting cable with the connector designation –A1–X99 in the lower connector section –A1–X99.

The cables must be routed so that power cables cannot interfere with data and signals that are being transferred along the connecting cables.


4.6.4 Connecting the DRIVE-CLiQ topology

Connecting-up the DRIVE-CLiQ topology

The DRIVE-CLiQ connection from the Control Unit (cabinet field +H.A50) to the Power Module in the left-hand sub-cabinet (cabinet field +H.A49) must be established.

The connecting cable (cable number –W003) is inserted by default in the DRIVE-CLiQ socket –X100 of the Control Unit, and must be inserted in the DRIVE-CLiQ socket –X400 of the Power Module in the left-hand sub-cabinet (cabinet field +H.A49). The cables must be routed so that power cables cannot cause interference on the DRIVE-CLiQ connection.

4.7 Power connections

| |
|--|
|  WARNING |
| Swapping the input and output terminals can destroy the device! |
| Swapping or short-circuiting the DC link terminals can destroy the device! |
| The contactor and relay operating coils that are connected to the same supply network as the device or are located near the device must be connected to overvoltage limiters (e.g. RC elements). |
| The device must not be operated via a ground-fault circuit interrupter (EN 61800-5-1). |

4.7.1 Connection cross-sections and cable lengths

Connection cross-sections

The connection cross-sections for the line connection, motor connection, and ground connection for your device are specified in the tables provided in the "Technical specifications" section.

Cable lengths

The maximum permissible cable lengths are specified for standard cable types or cable types recommended by SIEMENS. Longer cables can only be used after consultation.

The listed cable length represents the actual distance between the converter and the motor, taking account factors such as parallel laying, current-carrying capacity, and the laying factor.

- Unshielded cable (e.g. Protodur NYY): max. 450 m
- Shielded cable (e.g., Protodur NYCWY, Protodur EMV 3 Plus): max. 300 m.

4.7 Power connections

Note

The cable lengths specified are also valid if a motor choke is in use (option L08).

Note

The PROTOFLEX-EMV-3 PLUS shielded cable recommended by Siemens is the protective conductor and comprises three symmetrically-arranged protective conductors. The individual protective conductors must each be provided with cable eyes and be connected to ground. The cable also has a concentric flexible braided copper shield. To comply with EN 61800-3 regarding radio interference suppression, the shield must be grounded at both ends with the greatest possible surface area.

On the motor side, cable glands that contact the shield with the greatest possible surface area are recommended for the terminal boxes.

Minimum cable lengths for motor connection to a motor with one-winding system for units connected in parallel

For units connected in parallel for connection to a motor with one-winding system, the following minimum cable lengths must be adhered to, if a motor reactor (option L08) is not being used.

Table 4- 3 Minimum cable lengths

| Order number | Unit rating [kW] | Minimum cable length [m] |
|---------------------------|------------------|--------------------------|
| 380 V – 480 V 3 AC | | |
| 6SL3710-2GE41-1AAx | 630 | 13 |
| 6SL3710-2GE41-4AAx | 710 | 10 |
| 6SL3710-2GE41-6AAx | 900 | 9 |
| 500 V – 600 V 3 AC | | |
| 6SL3710-2GF38-6AAx | 630 | 18 |
| 6SL3710-2GF41-1AAx | 710 | 15 |
| 6SL3710-2GF41-4AAx | 1000 | 13 |
| 660 V – 690 V 3 AC | | |
| 6SL3710-2GH41-1AAx | 1000 | 20 |
| 6SL3710-2GH41-4AAx | 1350 | 18 |
| 6SL3710-2GH41-5AAx | 1500 | 15 |

4.7.2 Connecting the motor and power cables

Connecting the motor and power cables on the cabinet unit

Note

For the location of the connections, see the layout diagrams.

1. Open the cabinet, remove the covers (if necessary) in front of the connection panel for motor cables (terminals U2/T1, V2/T2, W2/T3; X2) and power cables (terminals U1/L1, V1/L2, W1/L3; X1).
 2. Move or remove the bottom plate below the connection panel through which the motor cables are fed.
 3. Screw the protective earth (PE) into the appropriate terminal (with earth symbol) (50 Nm for M12) at the points provided in the cabinet.
-

Note

With version C, connect the power cables first and then the motor cables.

4. Connect the motor cables to the connections.
Make sure that you connect the conductors in the correct sequence: U2/T1, V2/T2, W2/T3 and U1/L1, V1/L2, W1/L3!

| |
|--|
| CAUTION |
| Tighten the screws with the appropriate torque (50 Nm for M12), otherwise the terminal contacts could catch fire during operation. |

Note

The PE connection on the motor must be guided back directly to the cabinet unit and connected there.

4.7 Power connections

Direction of motor rotation

With induction machines with a clockwise phase sequence (looking at the drive shaft), the motor must be connected to the cabinet unit as follows.

Table 4- 4 Cabinet unit and motor connection terminals

| Cabinet unit (connection terminals) | Motor (connection terminals) |
|-------------------------------------|------------------------------|
| U2/T1 | U |
| V2/T2 | V |
| W2/T3 | W |

In contrast to the connection for the clockwise phase sequence, two phases have to be reversed with a counter-clockwise phase sequence (looking at the drive shaft).

Note

If an incorrect rotating field was connected when the cables were installed, and the rotating field cannot be corrected by swapping the motor cables, it can be corrected when commissioning the drive via p1821 (rotating field direction reversal) by changing the rotating field and thus enabling a direction reversal (see section "Functions, Monitoring and protective functions / Direction reversal").

The correct phase sequence must be observed in both sub-cabinets when connecting cabinet units in parallel, since it is not possible to use converter functions to correct different connection sequences in the two sub-cabinets at a later stage.

With motors that can be operated in a star/delta configuration, the windings must be checked to ensure that they have been connected properly. Please refer to the relevant documentation for the motor and note the required insulation voltage for operating the cabinet unit.

4.7.3 Adjusting the fan voltage (-T1-T10)

The power supply for the device fan (230 V 1 AC) in the Power Module (-T1- T10) is taken from the main supply system using a transformer.

The location of the transformer is indicated in the layout diagrams supplied.

The transformer is fitted with primary taps so that it can be fine-tuned to the line voltage.

If necessary, the connection fitted in the factory, shown with a dashed line, must be reconnected to the actual line voltage.

Note

Two transformers (-T1, -T10, and -T20) are installed in the following cabinet units. The two primary terminals on these devices must be set together.

- With 380 V – 480 V 3 AC: 6SL3710-1GE41-0_Ax
- With 500 V – 600 V 3 AC: 6SL3710-1GF37-4_Ax, 6SL3710-1GF38-1_Ax
- With 660 V – 690 V 3 AC: 6SL3710-1GH37-4_Ax, 6SL3710-1GH38-1_Ax

Note

For units that are connected in parallel, the setting terminals must be set jointly in both sub-cabinets:

- With 380 V – 480 V 3 AC:
6SL3710-2GE41-1AAx, 6SL3710-2GE41-4AAx, 6SL3710-2GE41-6AAx
- With 500 V – 600 V 3 AC:
6SL3710-2GF38-6AAx, 6SL3710-2GF41-1AAx, 6SL3710-2GF41-4AAx
- With 660 V – 690 V 3 AC:
6SL3710-2GH41-1AAx, 6SL3710-2GH41-4AAx, 6SL3710-2GH41-5AAx




Figure 4-3 Setting terminals for the fan transformer
(380 V – 480 V 3 AC / 500 V – 600 V 3 AC / 660 V – 690 V 3 AC)

The line voltage assignments for making the appropriate setting on the fan transformer are indicated in the following tables.

Note

With the 660 V – 690 V 3 AC fan transformer, a jumper is inserted between the "600 V" terminal and "CON" terminal. The "600V" and "CON" terminals are for internal use.

CAUTION

If the terminals are not reconnected to the actual line voltage:

- The required cooling capacity cannot be provided because the fan rotates too slowly.
- The fan fuses may blow due to an overcurrent.

Note

The order numbers for fan fuses that have blown can be found in the spare parts list.

4.7 Power connections

Table 4- 5 Line voltage assignments for setting the fan transformer
(380 V – 480 V 3 AC)

| Line voltage | Taps of the fan transformer (-T1- T10) |
|-----------------|--|
| 380 V \pm 10% | 380 V |
| 400 V \pm 10% | 400 V |
| 440 V \pm 10% | 440 V |
| 480 V \pm 10% | 480 V |

Table 4- 6 Line voltage assignments for setting the fan transformer
(500 V – 600 V 3 AC)

| Line voltage | Taps of the fan transformer (-T1- T10) |
|-----------------|--|
| 500 V \pm 10% | 500 V |
| 525 V \pm 10% | 525 V |
| 575 V \pm 10% | 575 V |
| 600 V \pm 10% | 600 V |

Table 4- 7 Line voltage assignments for setting the fan transformer
(660 V – 690 V 3 AC)

| Line voltage | Taps of the fan transformer (-T1- T10) |
|-----------------|--|
| 660 V \pm 10% | 660 V |
| 690 V \pm 10% | 690 V |

4.7.4 Adjusting the internal power supply (-A1 -T10, version A only)

A transformer (-A1-T10) is installed for the internal 230 V AC power supply for the cabinet unit. The location of the transformer is indicated in the layout diagrams supplied.

When delivered, the taps are always set to the highest level. The line-side terminals of the transformer may need to be reconnected to the existing line voltage.

The line voltage assignments for making the appropriate setting on the transformer for the internal power supply are indicated in the following tables.

| NOTICE | |
|---|--|
| If the terminals are not reconnected to the actual line voltage, the internal power supply will not be correct. | |

Table 4- 8 Line voltage assignments for the internal power supply
(380 V – 480 V 3 AC)

| Line voltage range | Tap | Taps of voltage adaptation transformer (-A1-T10) LH1 – LH2 |
|--------------------|-------|--|
| 342 V – 390 V | 380 V | 1 - 2 |
| 391 V – 410 V | 400 V | 1 – 3 |
| 411 V – 430 V | 415 V | 1 – 4 |
| 431 V – 450 V | 440 V | 1 – 5 |
| 451 V – 470 V | 460 V | 1 – 6 |
| 471 V – 528 V | 480 V | 1 – 7 |

Table 4- 9 Line voltage assignments for the internal power supply
(500 V – 600 V 3 AC)

| Line voltage range | Tap | Taps of voltage adaptation transformer (-A1-T10) LH1 – LH2 |
|--------------------|-------|--|
| 450 V – 515 V | 500 V | 1 - 8 |
| 516 V – 540 V | 525 V | 1 – 9 |
| 541 V – 560 V | 550 V | 1 – 10 |
| 561 V – 590 V | 575 V | 1 – 11 |
| 591 V – 670 V | 600 V | 1 – 12 |


Table 4- 10 Line voltage assignments for the internal power supply
(660 V – 690 V 3 AC)

| Line voltage range | Tap | Taps of voltage adaptation transformer (-A1-T10) LH1 – LH2 |
|--------------------|-------|--|
| 591 V – 630 V | 600 V | 1 – 12 |
| 631 V – 680 V | 660 V | 1 – 14, terminals 12 and 13 are jumpered |
| 681 V – 759 V | 690 V | 1 – 15, terminals 12 and 13 are jumpered |

4.7 Power connections


4.7.5 Removing the connection bracket for the interference-suppression capacitor with operation from an ungrounded supply

If the cabinet unit is operated on a non-grounded system/IT system, the connection bracket for the converter's interference suppression capacitor (-T1) must be removed.



Loosen the M4 (Torx 20) screws remove the connection bracket.

Figure 4-4 Removing the connection bracket to the noise suppression capacitor for frame size FX



Loosen the M4 (Torx 20) screws remove the connection bracket.

Figure 4-5 Removing the connection bracket to the noise suppression capacitor for frame size GX

4.7 Power connections




Figure 4-6 Removing the connection bracket to the noise suppression capacitor for frame size HX




Figure 4-7 Removing the connection bracket to the noise suppression capacitor for frame size JX

⚠ WARNING
Failing to remove the connection bracket for the interference suppression capacitor on a non-grounded system/IT system can cause significant damage to the cabinet unit.

Note

For units that are connected in parallel, the connection bracket must be removed in both sub-cabinets:

- With 380 V – 480 V 3 AC:
6SL3710-2GE41-1AAx, 6SL3710-2GE41-4AAx, 6SL3710-2GE41-6AAx
- For 500 V – 600 V 3 AC:
6SL3710-2GF38-6AAx, 6SL3710-2GF41-1AAx, 6SL3710-2GF41-4AAx
- For 660 V – 690 V 3 AC:
6SL3710-2GH41-1AAx, 6SL3710-2GH41-4AAx, 6SL3710-2GH41-5AAx

4.8 External Supply of the Auxiliary Supply from a Secure Line

4.8 External Supply of the Auxiliary Supply from a Secure Line

Description

An external auxiliary supply is always recommended if communication and closed-loop control are to be independent of the supply system. An external auxiliary supply is particularly recommended for low-power lines susceptible to short-time voltage dips or power failures.

With an external supply independent of the main supply, warnings and fault messages may still be displayed on the operator panel and internal protection and monitoring devices if the main supply fails.

 **DANGER**

When the external auxiliary supply is connected, dangerous voltages are present in the cabinet unit even when the main circuit-breaker is open.

NOTICE

An external auxiliary supply (infeed) must always be used if the automatic restart (WEA) function is to be used with integrated EMERGENCY OFF option (L57) or EMERGENCY STOP option (L59, L60). Otherwise, the automatic restart function does not work.

Table 4- 11 Connection options for the external auxiliary voltage depending on the selected options.

| Cabinet unit option | External supply of auxiliary voltage independent of the main supply | | | |
|---|---|---------------------------|---|--|
| | 24 V DC Terminal –X9 | 230 V AC Terminal –X40 | 230 V AC (terminal –X40) ¹⁾ | 230 V AC (terminal –X40) with options L13 / L26 (when I > 800 A) |
| - With no further options - Version C | X | | | |
| L13 | | X | | |
| L26 (when I > 800 A) | | X | | |
| L83 | | | X | X |
| L84 | | | X | X |
| L86 | | | X | X |
| L87 | | | X | X |

¹⁾ This is required not only when the open and closed-loop control but also when the 230 V AC load (thermistor motor protection, PT100 evaluation, or insulation monitor) is to remain in operation if the main supply fails.

4.8 External Supply of the Auxiliary Supply from a Secure Line

4.8.1 230 V AC auxiliary supply

The maximum fuse rating is 16 A.

The connection is protected inside the cabinet with 3 A or 5 A.

Connection

- On terminal block -X40, remove the jumpers between terminals 1 and 2 as well as 5 and 6.
- Connect the external 230 V AC supply to terminals 2 (L1) and 6 (N).

4.8.2 24 V DC auxiliary supply

The power requirement is 5 A.

Connection

Connect the external 24 V DC supply to terminals 1 (P 24 V) and 2 (M_{ext}) of terminal block – X9.

4.9 Signal connections

4.9 Signal connections

4.9.1 Customer terminal module TM31 (-A60) (option G60)

Note

The factory setting and description of the customer terminal blocks can be found in the circuit diagrams.

The location of the customer terminal block in the cabinet unit is indicated in the layout diagram.

Shield connection

The shield connection of shielded control cables on the customer terminal block –A60 is established in the immediate vicinity of the terminal block. For this purpose, the customer terminal block –A60 and the mounting plates have cut-out sections which are used to snap the enclosed shield springs into place. The shields of incoming and outgoing cables must be applied directly to these shield connections. It is important here to establish the greatest possible area of contact and a good conductive connection.

Note

These shield springs can be used for all control cables in the cabinet unit because all the shield connections are identical in design.




Figure 4-8 Shield connection

Overview




Figure 4-9 Customer terminal block TM31

4.9 Signal connections




Figure 4-10 Connection overview of TM31 customer terminal block

Note


The digital inputs (terminals -X520 and -X530) in the example are powered by the internal 24 V supply of the customer terminal block (terminal -X540).

The two groups of digital inputs (optocoupler inputs) have a common reference potential for each group (ground reference M1 or M2). To close the circuit when the internal 24 V supply is used, the ground references M1 / M2 must be connected to internal ground (M).

If power is not supplied from the internal 24 V supply (terminal -X540), the jumper between ground M1 and M or M2 and M must be removed in order to avoid potential rounding. The external ground must then be connected to terminals M1 and M2.

X520: 4 digital inputs

Table 4- 12 Terminal block X520

| | Terminal | Designation ¹⁾ | Technical specifications |
|--|----------|---------------------------|---|
|  | 1 | DI 0 | Voltage: - 3 V to 30 V Typical current consumption: 10 mA at 24 V Reference potential is always terminal M1 Level: - high level: 15 V to 30 V - low level: -3 V to 5 V |
| | 2 | DI 1 | |
| | 3 | DI 2 | |
| | 4 | DI 3 | |
| | 5 | M1 | Ground reference |
| | 6 | M | Electronics ground |

¹⁾ DI: digital input; M1: ground reference; M: Electronics ground

Max. connectable cross-section: 1.5 mm²


Note

An open input is interpreted as "low".

4.9 Signal connections

X530: 4 digital inputs

Table 4- 13 Terminal block X530

| | Terminal | Designation ¹⁾ | Technical specifications |
|---|----------|---------------------------|---|
|  | 1 | DI 4 | Voltage: - 3 V to 30 V Typical current consumption: 10 mA at 24 V Reference potential is always terminal M2 Level: - high level: 15 V to 30 V - low level: -3 V to 5 V |
| | 2 | DI 5 | |
| | 3 | DI 6 | |
| | 4 | DI 7 | |
| | 5 | M2 | Ground reference |
| | 6 | M | Electronics ground |

¹⁾ DI: digital input; M2: ground reference; M: Electronics ground


Max. connectable cross-section: 1.5 mm²

Note

An open input is interpreted as "low".

X521: 2 analog inputs (differential inputs)

Table 4- 14 Terminal block X521

| | Terminal | Designation ¹⁾ | Technical specifications |
|---|----------|---------------------------|--|
|  | 1 | AI 0+ | As voltage input: -10 V - +10 V, Ri = 100 kΩ Resolution: 11 bits + sign |
| | 2 | AI 0- | |
| | 3 | AI 1+ | As current input: +4 mA - +20 mA / -20 mA - +20 mA / 0 mA - +20 mA, Ri = 250 Ω Resolution: 10 bits + sign |
| | 4 | AI 1- | |
| | 5 | P10 | Auxiliary voltage +10 V, continued short-circuit proof |
| | 6 | M | Ground reference |
| | 7 | N10 | Auxiliary voltage -10 V, continued short-circuit proof |
| | 8 | M | Ground reference |

¹⁾ AI: analog input; P10/N10: auxiliary voltage, M: Ground reference


Max. connectable cross-section: 1.5 mm²

CAUTION

The input current of the analog inputs must not exceed 35 mA when current measurements are performed.

S5: Selector for voltage/current AI0, AI1

Table 4- 15 Selector for voltage/current S5


| | Switch | Function |
|---|--------|--|
|  | S5.0 | Selector voltage (V) / current (I) AI0 |
| | S5.1 | Selector voltage (V) / current (I) AI1 |

Note

When delivered, both switches are set to current measurement (switch set to "I").

X522: 2 analog outputs, temperature sensor connection

Table 4- 16 Terminal block X522

| | Terminal | Designation ¹⁾ | Technical specifications |
|--|----------|---------------------------|---|
|  | 1 | AO 0V+ | -10 V - +10 V (max. 3 mA) |
| | 2 | AO 0- | +4 mA - +20 mA (max. load resistance \leq 500 Ω) |
| | 3 | AO 0C+ | -20 mA - +20 mA (max. load resistance \leq 500 Ω) |
| | 4 | AO 1V+ | 0 mA - +20 mA (max. load resistance \leq 500 Ω) |
| | 5 | AO 1- | Resolution: 11 bits + sign |
| | 6 | AO 1C+ | continued short-circuit proof |
| | 7 | +Temp | Temperature sensor connection: KTY84-1C130 / PTC |
| | 8 | -Temp | |

¹⁾ AO xV: analog output voltage; AO xC: Analog output current

Max. connectable cross-section: 1.5 mm²

DANGER

Risk of electric shock!

Only temperature sensors that meet the electrical separation specifications contained in EN 61800-5-1 may be connected to terminals "+Temp" and "-Temp".

If these instructions are not complied with, there is a risk of electric shock!

Note

The following probes can be connected to the temperature sensor connection: KTY84-1C130 / PTC.

NOTICE

The KTY temperature sensor must be connected with the correct polarity.


CAUTION

The permissible back EMF at the outputs is \pm 15 V

4.9 Signal connections

X540: Joint auxiliary voltage for the digital inputs

Table 4- 17 Terminal block X540

| | Terminal | Designation | Technical specifications |
|---|----------|-------------|--|
|  | 8 | P24 | 24 V DC Max. total load current of +24 V auxiliary voltage of terminal blocks X540 and X541 combined: 150 mA continued short-circuit proof |
| | 7 | P24 | |
| | 6 | P24 | |
| | 5 | P24 | |
| | 4 | P24 | |
| | 3 | P24 | |
| | 2 | P24 | |
| | 1 | P24 | |


Max. connectable cross-section: 1.5 mm²

Note

This voltage supply is only for powering the digital inputs.

X541: 4 non-floating digital inputs/outputs

Table 4- 18 Terminal strip X541

| | Terminal | Designation ¹⁾ | Technical specifications |
|---|----------|---------------------------|---|
|  | 6 | M | Electronics ground |
| | 5 | DI/DO 11 | As input: Voltage: -3 V to 30 V Typical current consumption: 10 mA at 24 V DC As output: The summation current of the four outputs (including the currents of the inputs) is limited to 100 mA (continued short-circuit proof) in the delivery condition. |
| | 4 | DI/DO 10 | |
| | 3 | DI/DO 9 | |
| | 2 | DI/DO 8 | |
| | 1 | P24 | |

¹⁾ DI/DO: Digital input/output; M: Electronics ground

Max. connectable cross-section: 1.5 mm²

Note

An open input is interpreted as "low".


When externally generated 24 V DC signals are connected to a digital input, the ground reference of the external signal must also be connected.

CAUTION

Due to the limitation of the aggregate of the output currents an over-current can cause a short circuit on an output terminal or even intrusion of the signal of a different terminal.

X542: 2 relay outputs (two-way contact)

Table 4- 19 Terminal block X542

| | Terminal | Designation ¹⁾ | Technical specifications |
|---|----------|---------------------------|--|
|  | 1 | DO 0.NC | Contact type: Changeover contact max. load current: 8 A Max. switching voltage: 250 V AC, 30 V DC |
| | 2 | DO 0.COM | |
| | 3 | DO 0.NO | Max. switching voltage: - at 250 V AC: 2000 VA (cosφ = 1) - at 250 V AC: 750 VA (cosφ = 0.4) - at 30 V DC: 240 W (ohmic load) Required minimum current: 100 mA |
| | 4 | DO 1.NC | |
| | 5 | DO 1.COM | |
| | 6 | DO 1.NO | |

¹⁾ DO: digital output, NO: normally-open contact, NC: normally-closed contact, COM: mid-position contact

Max. connectable cross-section: 2.5 mm²

Note

If 230 V AC is applied to the relay outputs, the Terminal Module must also be grounded via a 6 mm² protective conductor.

4.10 Other connections

Depending on the options installed, further connections have to be established, for example, dv/dt filter plus Voltage Peak Limiter, main contactor, sine-wave filter, connection for external auxiliary equipment, main circuit-breaker including fuses or circuit-breaker, EMERGENCY OFF button, cabinet illumination with service socket, anti-condensation heating for cabinet, contactor safety combinations (EMERGENCY OFF / EMERGENCY STOP), thermistor motor protection unit, braking unit, PT100 evaluation unit, insulation monitor, communication modules, encoder evaluator, and NAMUR option.

Detailed information on connecting individual options with interfaces can be found on the customer DVD supplied with the device.

4.10 Other connections

4.10.1 Clean Power version with integrated Line Harmonics Filter compact (Option L01)

Description

Line Harmonics Filter compact reduce the low-frequency line harmonics of the converter to levels that comply with the stringent IEEE 519-1992 standard. This applies to systems with a uk value $\leq 5\%$.

Installation point of the Line Harmonics Filter compact

The Line Harmonics Filter compact is installed fully wired in an auxiliary cabinet. A 400 mm or 600 mm wide cabinet is used depending on the unit rating and the voltage level. The Line Harmonics Filter is positioned to the left or right of the Line Module.

Table 4- 20 Overall width, total weight and position of the Line Harmonics Filter compact with Option L01

| Order number | Unit rating of the converter [kW] | Overall width [mm] | Total weight [kg] | Position of the Line Harmonics Filters (to the left or right of the Line Module) |
|--|-----------------------------------|--------------------|-------------------|--|
| Line voltage 380 V -10 % ... 480 V +10 % 3 AC at 50 Hz 380 V -10 % ... 480 V +8 % 3 AC at 60 Hz | | | | |
| 6SL3710-1GE32-1AAx | 110 | 1200 | 540 | Left |
| 6SL3710-1GE32-6AAx | 132 | 1200 | 540 | Left |
| 6SL3710-1GE33-1AAx | 160 | 1200 | 640 | Left |
| 6SL3710-1GE33-8AAx | 200 | 1400 | 730 | Left |
| 6SL3710-1GE35-0AAx | 250 | 1400 | 770 | Left |
| 6SL3710-1GE36-1AAx | 315 | 1800 | 1300 | Right |
| 6SL3710-1GE37-5AAx | 400 | 1800 | 1345 | Right |
| 6SL3710-1GE38-4AAx | 450 | 1800 | 1555 | Right |
| 6SL3710-1GE41-0AAx | 560 | 2200 | 1840 | Right |
| 6SL3710-2GE41-1AAx | 630 | 3600 | 2580 | Right |
| 6SL3710-2GE41-4AAx | 710 | 3600 | 2670 | Right |
| 6SL3710-2GE41-6AAx | 900 | 3600 | 3090 | Right |

4.10 Other connections

| Order number | Unit rating of the converter [kW] | Overall width [mm] | Total weight [kg] | Position of the Line Harmonics Filters (to the left or right of the Line Module) |
|--|-----------------------------------|--------------------|-------------------|--|
| Line voltage 500 V -10 % ... 600 V +10 % 3 AC at 50 Hz 500 V -10 % ... 600 V +8 % 3 AC at 60 Hz | | | | |
| 6SL3710-1GF31-8AAx | 110 | 1200 | 670 | Left |
| 6SL3710-1GF32-2AAx | 132 | 1200 | 670 | Left |
| 6SL3710-1GF32-6AAx | 160 | 1200 | 710 | Left |
| 6SL3710-1GF33-3AAx | 200 | 1200 | 710 | Left |
| 6SL3710-1GF34-1AAx | 250 | 1800 | 1340 | Right |
| 6SL3710-1GF34-7AAx | 315 | 1800 | 1340 | Right |
| 6SL3710-1GF35-8AAx | 400 | 1200 | 1340 | Right |
| 6SL3710-1GF37-4AAx | 500 | 2200 | 2000 | Right |
| 6SL3710-1GF38-1AAx | 560 | 2200 | 2040 | Right |
| 6SL3710-2GF38-6AAx | 630 | 3600 | 2660 | Right |
| 6SL3710-2GF41-1AAx | 710 | 3600 | 2660 | Right |
| 6SL3710-2GF41-4AAx | 1000 | 4400 | 3980 | Right |
| Line voltage 660 V -10 % ... 690 V +10 % 3 AC at 50 Hz 660 V -10 % ... 690 V +8 % 3 AC at 60 Hz | | | | |
| 6SL3710-1GH28-5AAx | 75 | 1200 | 550 | Left |
| 6SL3710-1GH31-0AAx | 90 | 1200 | 550 | Left |
| 6SL3710-1GH31-2AAx | 110 | 1200 | 550 | Left |
| 6SL3710-1GH31-5AAx | 132 | 1200 | 550 | Left |
| 6SL3710-1GH31-8AAx | 160 | 1200 | 670 | Left |
| 6SL3710-1GH32-2AAx | 200 | 1200 | 670 | Left |
| 6SL3710-1GH32-6AAx | 250 | 1200 | 710 | Left |
| 6SL3710-1GH33-3AAx | 315 | 1200 | 710 | Left |
| 6SL3710-1GH34-1AAx | 400 | 1800 | 1340 | Right |
| 6SL3710-1GH34-7AAx | 450 | 1800 | 1340 | Right |
| 6SL3710-1GH35-8AAx | 560 | 1800 | 1340 | Right |
| 6SL3710-1GH37-4AAx | 710 | 2200 | 2000 | Right |
| 6SL3710-1GH38-1AAx | 800 | 2200 | 2040 | Right |
| 6SL3710-2GH41-1AAx | 1000 | 3600 | 2660 | Right |
| 6SL3710-2GH41-4AAx | 1350 | 4400 | 3980 | Right |
| 6SL3710-2GH41-5AAx | 1500 | 4400 | 4060 | Right |

4.10 Other connections

Line system configurations

The Harmonics Filter compact may be operated with the following systems in accordance with IEC 60364-1:

- TN line systems with grounded neutral point or grounded phase conductor
- TT line systems with grounded neutral point or grounded phase conductor
- IT line systems that are not grounded or have a high-ohmic ground

Restrictions

Note

The maximum supply short-circuit power u_k is 10 %.

Note

On systems with a grounded phase conductor and a line voltage >600 V AC, line-side components should be installed to limit overvoltages to overvoltage category II in accordance with IEC 61800-5-1.

| |
|----------------|
| CAUTION |
|----------------|

| |
|--|
| Please observe the switching frequency! |
|--|

| |
|--|
| If the switching frequency (once every 3 minutes) defined in the technical specifications is not adhered to, severe damage to the connected Power Module may result. |
|--|

| |
|----------------|
| CAUTION |
|----------------|

| |
|--|
| Observe the waiting time when restarting! |
|--|

| |
|---|
| For cabinet units with a line voltage of 380 V ... 480 V 3 AC and 500 V ... 600 V 3 AC, it is essential to observe a waiting period of at least 30 seconds after deenergizing before restarting the converter. This waiting period is implemented using an internal timer relay, which prevents restarting. |
|---|

| |
|---|
| If a restart command is given before the waiting period has expired, fault F30027 "Power unit: Time monitoring for DC link pre-charging" is issued. |
|---|

| |
|---------------|
| NOTICE |
|---------------|

| |
|-------------------------------------|
| Operation with high voltages |
|-------------------------------------|

| |
|--|
| The Line Harmonics Filter increases the input voltage of the Power Module slightly compared to the connection voltage. |
|--|

| |
|--|
| For an connection voltage in the top tolerance range (480 V +10 %, 600 V +10 % or 690 V +10 %), the internal monitoring of the DC link voltage can produce fault F06310. Use parameters p2118 and p2119 to reparameterize this fault as a alarm. |
|--|

NOTICE

Operation with braking unit (option L61 / L62)

If a braking unit is used, and the connection voltage lies in the top tolerance range (480 V +10 %, 600 V +10 % or 690 V +10 %), the threshold value switch must only be set to the high response threshold in each case.

The chopper could otherwise trip inadvertently during normal operation.

Temperature evaluation

The Line Harmonics Filter compact is forced cooled via fans. In the event of fan failure, the integrated temperature sensors protect the Line Harmonics Filter compact against overheating.

- The temperature sensor for triggering the warning level is interconnected to digital input DI0 of the Control Unit. When the temperature sensor trips, "external alarm 1" (A7850) is triggered.
- The temperature sensor for triggering the fault threshold is interconnected to the line contactor or circuit breaker via a contactor relay. When the temperature sensor trips, the cabinet unit is shut down.
The signal from the temperature sensor is also interconnected to digital input DI1 of the Control Unit. In this way, if the temperature sensor trips, "external fault 1" (F7860) is triggered.

4.10.2 dV/dt filter compact plus Voltage Peak Limiter (option L07)

Description

The dV/dt filter compact plus Voltage Peak Limiter comprises two components: the dV/dt reactor and the voltage-limiting network (Voltage Peak Limiter), which cuts off the voltage peaks and feeds back the energy into the DC link. The dV/dt filter compact plus Voltage Peak Limiter is designed for use with motors for which the voltage strength of the insulation system is unknown or insufficient.

The dV/dt filter compact plus Voltage Peak Limiter limits the voltage load on the motor cables to values in accordance with the limit value curve A in compliance with IEC/TS 60034-25:2007.

The rate of voltage rise is limited to $< 1600 \text{ V}/\mu\text{s}$, the peak voltages are limited to $< 1400 \text{ V}$.

4.10 Other connections

Restrictions

The following constraints should be noted when a dV/dt filter compact plus Voltage Peak Limiter is used:

- The output frequency is limited to no more than 150 Hz.
- Maximum permissible motor cable lengths:
 - Shielded cable: max. 100 m
 - Unshielded cable: max. 150 m

WARNING

When a dV/dt filter compact plus Voltage Peak Limiter is used, the drive must not be continuously operated with an output frequency lower than 10 Hz.

A maximum load duration of 5 minutes at an output frequency lower than 10 Hz is permissible, provided that the drive is operated with an output frequency higher than 10 Hz for a period of 5 minutes thereafter, or deactivated..

Uninterrupted duty at an output frequency less than 10 Hz can produce thermal overload and destroy the dV/dt filter.

WARNING

When a dV/dt filter compact plus Voltage Peak Limiter is used, the pulse frequency of the Power Module must not exceed 2.5 kHz or 4 kHz. Setting a higher pulse frequency can lead to destruction of the dV/dt filter.

Note

It is permissible to set pulse frequencies in the range between the rated pulse frequency and the relevant maximum pulse frequency when a dV/dt filter compact plus Voltage Peak Limiter is used. "Current derating as a function of the pulse frequency" must be observed here (refer to the Technical Specifications).

Table 4- 21 Max. pulse frequency when a dV/dt filter compact plus Voltage Peak Limiter is used in units with a rated pulse frequency of 2 kHz

| Order no. 6SL3710-... | Unit rating [kW] | Output current for a pulse frequency of 2 kHz [A] | Max. pulse frequency when a dV/dt filter compact plus Voltage Peak Limiter is used |
|--------------------------------------|------------------|--|---|
| Supply voltage 380 – 480 V AC | | | |
| 1GE32-1AAx | 110 | 210 | 4 kHz |
| 1GE32-6AAx | 132 | 260 | 4 kHz |
| 1GE33-1AAx | 160 | 310 | 4 kHz |
| 1GE33-8AAx | 200 | 380 | 4 kHz |
| 1GE35-0AAx | 250 | 490 | 4 kHz |

Table 4- 22 Max. pulse frequency when a dV/dt filter compact plus Voltage Peak Limiter is used in units with a rated pulse frequency of 1,25 kHz

| Order no. 6SL3710-... | Unit rating [kW] | Output current for a pulse frequency of 1.25 kHz [A] | Max. pulse frequency when a dV/dt filter compact plus Voltage Peak Limiter is used |
|--------------------------------------|------------------|--|---|
| Supply voltage 380 – 480 V AC | | | |
| 1GE36-1AAx | 315 | 605 | 2.5 kHz |
| 1GE37-5AAx | 400 | 745 | 2.5 kHz |
| 1GE38-4AAx | 450 | 840 | 2.5 kHz |
| 1GE41-0AAx | 560 | 985 | 2.5 kHz |
| 2GE41-1AAx | 630 | 1120 | 2.5 kHz |
| 2GE41-4AAx | 710 | 1380 | 2.5 kHz |
| 2GE41-6AAx | 900 | 1580 | 2.5 kHz |
| Supply voltage 500 – 600 V AC | | | |
| 1GF31-8AAx | 110 | 175 | 2.5 kHz |
| 1GF32-2AAx | 132 | 215 | 2.5 kHz |
| 1GF32-6AAx | 160 | 260 | 2.5 kHz |
| 1GF33-3AAx | 200 | 330 | 2.5 kHz |
| 1GF34-1AAx | 250 | 410 | 2.5 kHz |
| 1GF34-7AAx | 315 | 465 | 2.5 kHz |
| 1GF35-8AAx | 400 | 575 | 2.5 kHz |
| 1GF37-4AAx | 500 | 735 | 2.5 kHz |
| 1GF38-1AAx | 560 | 810 | 2.5 kHz |
| 2GF38-6AAx | 630 | 860 | 2.5 kHz |
| 2GF41-1AAx | 710 | 1070 | 2.5 kHz |
| 2GF41-4AAx | 1000 | 1360 | 2.5 kHz |
| Supply voltage 660 – 690 V AC | | | |
| 1GH28-5AAx | 75 | 85 | 2.5 kHz |
| 1GH31-0AAx | 90 | 100 | 2.5 kHz |
| 1GH31-2AAx | 110 | 120 | 2.5 kHz |
| 1GH31-5AAx | 132 | 150 | 2.5 kHz |
| 1GH31-8AAx | 160 | 175 | 2.5 kHz |
| 1GH32-2AAx | 200 | 215 | 2.5 kHz |
| 1GH32-6AAx | 250 | 260 | 2.5 kHz |
| 1GH33-3AAx | 315 | 330 | 2.5 kHz |
| 1GH34-1AAx | 400 | 410 | 2.5 kHz |
| 1GH34-7aAx | 450 | 465 | 2.5 kHz |
| 1GH35-8AAx | 560 | 575 | 2.5 kHz |
| 1GH37-4AAx | 710 | 735 | 2.5 kHz |
| 1GH38-1aAx | 800 | 810 | 2.5 kHz |
| 2GH41-1AAx | 1000 | 1070 | 2.5 kHz |
| 2GH41-4AAx | 1350 | 1360 | 2.5 kHz |
| 2GH41-4AAx | 1500 | 1500 | 2.5 kHz |

4.10 Other connections

Commissioning

During commissioning, the dv/dt filter compact plus Voltage Peak Limiter must be logged on using STARTER or the AOP30 operator panel (p0230 = 2).

Note

When the factory settings are restored, parameter p0230 is reset.
The parameter must be reset if the system is commissioned again.

4.10.3 dv/dt filter plus Voltage Peak Limiter (option L10)

Description

The dv/dt filter plus Voltage Peak Limiter comprises two components: the dv/dt reactor and the Voltage Peak Limiter, which limits transients and returns the energy to the DC link.

The dv/dt filters plus Voltage Peak Limiter must be used for motors for which the proof voltage of the insulation system is unknown or insufficient. Standard motors of the 1LA5, 1LA6 and 1LA8 series only require them at supply voltages > 500 V +10%.

The dv/dt filter plus Voltage Peak Limiter limits the voltage gradient to values < 500 V/ μ s and the typical transients to the values below (with motor cable lengths of < 150 m):

- < 1000 V at $U_{line} < 575$ V
- < 1250 V at 660 V < $U_{line} < 690$ V.

Depending on the converter power, option L10 can be accommodated in the drive converter cabinet unit or an additional cabinet with a width 400 mm is required.

Table 4- 23 Accommodating the voltage limiting network in the cabinet or in an additional cabinet


| Voltage range | Installation of the dv/dt filter plus Voltage Peak Limiter within the converter cabinet unit | Installation of the VPL in an additional cabinet |
|---------------------|--|--|
| 380 V to 480 V 3 AC | 6SL3710-1GE32-1AAx 6SL3710-1GE32-6AAx 6SL3710-1GE33-1AAx 6SL3710-1GE33-8AAx 6SL3710-1GE35-0AAx | 6SL3710-1GE36-1AAx 6SL3710-1GE37-5AAx 6SL3710-1GE38-4AAx 6SL3710-1GE41-0AAx 6SL3710-2GE41-1AAx ¹⁾ 6SL3710-2GE41-4AAx ¹⁾ 6SL3710-2GE41-6AAx ¹⁾ |
| 500 V to 600 V 3 AC | 6SL3710-1GF31-8AAx 6SL3710-1GF32-2AAx 6SL3710-1GF32-6AAx 6SL3710-1GF33-3AAx | 6SL3710-1GF34-1AAx 6SL3710-1GF34-7AAx 6SL3710-1GF35-8AAx 6SL3710-1GF37-4AAx 6SL3710-1GF38-1AAx 6SL3710-2GF38-6AAx ¹⁾ 6SL3710-2GF41-1AAx ¹⁾ 6SL3710-2GF41-4AAx ¹⁾ |
| 660 V to 690 V 3 AC | 6SL3710-1GH28-5AAx 6SL3710-1GH31-0AAx 6SL3710-1GH31-2AAx 6SL3710-1GH31-5AAx 6SL3710-1GH31-8AAx 6SL3710-1GH32-2AAx 6SL3710-1GH32-6AAx 6SL3710-1GH33-3AAx | 6SL3710-1GH34-1AAx 6SL3710-1GH34-7AAx 6SL3710-1GH35-8AAx 6SL3710-1GH37-4AAx 6SL3710-1GH38-1AAx 6SL3710-2GH41-1AAx ¹⁾ 6SL3710-2GH41-4AAx ¹⁾ 6SL3710-2GH41-5AAx ¹⁾ |

¹⁾ With units that are connected in parallel, each individual sub-cabinet has a separate auxiliary cabinet for the Voltage Peak Limiter.

Restrictions

The following restrictions should be noted when a dv/dt filter plus Voltage Peak Limiter is used:

- The output frequency is limited to no more than 150 Hz.
- Maximum permissible motor cable lengths:
 - Shielded cable: max. 300 m
 - Unshielded cable: max. 450 m

| |
|--|
|  WARNING |
| When a dV/dt filter plus Voltage Peak Limiter is used, the pulse frequency of the Power Module must not exceed 2.5 kHz or 4 kHz. Setting a higher pulse frequency can lead to destruction of the dV/dt filter. |

4.10 Other connections

Note

It is permissible to set pulse frequencies in the range between the rated pulse frequency and the relevant maximum pulse frequency when a dV/dt filter plus Voltage Peak Limiter is used. "Current derating as a function of the pulse frequency" must be observed here (refer to the Technical Specifications).

Table 4- 24 Max. pulse frequency when a dV/dt filter plus Voltage Peak Limiter is used in units with a rated pulse frequency of 2 kHz

| Order no. 6SL3710-... | Unit rating [kW] | Output current for a pulse frequency of 2 kHz [A] | Max. pulse frequency when a dV/dt filter plus Voltage Peak Limiter is used |
|--------------------------------------|------------------|--|---|
| Supply voltage 380 – 480 V AC | | | |
| 1GE32-1AAx | 110 | 210 | 4 kHz |
| 1GE32-6AAx | 132 | 260 | 4 kHz |
| 1GE33-1AAx | 160 | 310 | 4 kHz |
| 1GE33-8AAx | 200 | 380 | 4 kHz |
| 1GE35-0AAx | 250 | 490 | 4 kHz |

Table 4- 25 Max. pulse frequency when a dV/dt filter plus Voltage Peak Limiter is used in units with a rated pulse frequency of 1,25 kHz

| Order no. 6SL3710-... | Unit rating [kW] | Output current for a pulse frequency of 1.25 kHz [A] | Max. pulse frequency when a dV/dt filter plus Voltage Peak Limiter is used |
|--------------------------------------|------------------|--|---|
| Supply voltage 380 – 480 V AC | | | |
| 1GE36-1AAx | 315 | 605 | 2.5 kHz |
| 1GE37-5AAx | 400 | 745 | 2.5 kHz |
| 1GE38-4AAx | 450 | 840 | 2.5 kHz |
| 1GE41-0AAx | 560 | 985 | 2.5 kHz |
| 2GE41-1AAx | 630 | 1120 | 2.5 kHz |
| 2GE41-4AAx | 710 | 1380 | 2.5 kHz |
| 2GE41-6AAx | 900 | 1580 | 2.5 kHz |
| Supply voltage 500 – 600 V AC | | | |
| 1GF31-8AAx | 110 | 175 | 2.5 kHz |
| 1GF32-2AAx | 132 | 215 | 2.5 kHz |
| 1GF32-6AAx | 160 | 260 | 2.5 kHz |
| 1GF33-3AAx | 200 | 330 | 2.5 kHz |
| 1GF34-1AAx | 250 | 410 | 2.5 kHz |
| 1GF34-7AAx | 315 | 465 | 2.5 kHz |
| 1GF35-8AAx | 400 | 575 | 2.5 kHz |
| 1GF37-4AAx | 500 | 735 | 2.5 kHz |
| 1GF38-1AAx | 560 | 810 | 2.5 kHz |
| 2GF38-6AAx | 630 | 860 | 2.5 kHz |
| 2GF41-1AAx | 710 | 1070 | 2.5 kHz |
| 2GF41-4AAx | 1000 | 1360 | 2.5 kHz |

| Order no. 6SL3710-... | Unit rating [kW] | Output current for a pulse frequency of 1.25 kHz [A] | Max. pulse frequency when a dV/dt filter plus Voltage Peak Limiter is used |
|--------------------------------------|------------------|--|---|
| Supply voltage 660 – 690 V AC | | | |
| 1GH28-5AAx | 75 | 85 | 2.5 kHz |
| 1GH31-0AAx | 90 | 100 | 2.5 kHz |
| 1GH31-2AAx | 110 | 120 | 2.5 kHz |
| 1GH31-5AAx | 132 | 150 | 2.5 kHz |
| 1GH31-8AAx | 160 | 175 | 2.5 kHz |
| 1GH32-2AAx | 200 | 215 | 2.5 kHz |
| 1GH32-6AAx | 250 | 260 | 2.5 kHz |
| 1GH33-3AAx | 315 | 330 | 2.5 kHz |
| 1GH34-1AAx | 400 | 410 | 2.5 kHz |
| 1GH34-7aAx | 450 | 465 | 2.5 kHz |
| 1GH35-8AAx | 560 | 575 | 2.5 kHz |
| 1GH37-4AAx | 710 | 735 | 2.5 kHz |
| 1GH38-1aAx | 800 | 810 | 2.5 kHz |
| 2GH41-1AAx | 1000 | 1070 | 2.5 kHz |
| 2GH41-4AAx | 1350 | 1360 | 2.5 kHz |
| 2GH41-4AAx | 1500 | 1500 | 2.5 kHz |

Commissioning

During commissioning, the dv/dt filter plus Voltage Peak Limiter must be logged on using STARTER or the AOP30 operator panel (p0230 = 2).

Note

When the factory settings are restored, parameter p0230 is reset.
The parameter must be reset if the system is commissioned again.

4.10 Other connections

4.10.4 Main Contactor (Option L13)

Description

The cabinet unit is designed as standard without a line contactor. Option L13 (main contactor) is needed if a switching element is required for disconnecting the cabinet from the supply (necessary with EMERGENCY OFF). The contactor is energized and supplied within the cabinet.

Connection

Table 4- 26 Terminal block X50 – checkback contact "main contactor closed"

| Terminal | Designation ¹⁾ | Technical specifications |
|----------|---------------------------|---|
| 4 | NO | Max. load current: 10 A |
| 5 | NC | Max. switching voltage: 250 V AC |
| 6 | COM | Max. switching capacity: 250 VA Required minimum load: ≥ 1 mA |

¹⁾ NO: normally-open contact, NC: normally-closed contact, COM: mid-position contact

Max. connectable cross-section: 4 mm²

4.10.5 Sinusoidal Filter (Option L15)

Description

The sine-wave filter limits the voltage gradient and the capacitive charge/discharge currents which usually occur with inverter operation. It also prevents additional noise caused by the pulse frequency. The service life of the motor is as long as that attained with direct mains operation.

CAUTION

If a sine-wave filter is connected to the converter, the converter must be activated during commissioning to prevent the filter from being destroyed (see "Commissioning").

Restrictions

The following restrictions must be taken into account when a sine-wave filter is used:

- The output frequency is limited to max. 115 Hz (at 500 – 600 V) and 150 Hz (at 380 – 480 V).
- The modulation type is permanently set to space-vector modulation without overmodulation.
- The maximum output frequency is limited to 85% of the input frequency.

- Maximum permissible motor cable lengths:
 - Unshielded cable: max. 450 m
 - Shielded cable: max. 300 m
- During commissioning, the pulse frequency rises to double the factory setting. This induces current derating, which must be applied to the cabinet unit rated currents listed in the technical specifications.

Note

If a filter cannot be parameterized (p0230 ≠ 3), this means that a filter has not been provided for the cabinet unit. In this case, the cabinet unit must not be operated with a sine-wave filter.

Table 4- 27 Technical specifications for sine-wave filters with SINAMICS G150

| Order no. SINAMICS G150 | Voltage [V] | Pulse frequency [kHz] | Output current [A] ¹⁾ |
|----------------------------|----------------|--------------------------|-------------------------------------|
| 6SL3710-1GE32-1AA0 | 3 AC 380 – 480 | 4 | 172 A |
| 6SL3710-1GE32-6AA0 | 3 AC 380 – 480 | 4 | 216 A |
| 6SL3710-1GE33-1AA0 | 3 AC 380 – 480 | 4 | 273 A |
| 6SL3710-1GE33-8AA0 | 3 AC 380 – 480 | 4 | 331 A |
| 6SL3710-1GE35-0AA0 | 3 AC 380 – 480 | 4 | 382 A |
| 6SL3710-1GF31-8AA0 | 3 AC 500 – 600 | 2,5 | 152 A |
| 6SL3710-1GF32-2AA0 | 3 AC 500 – 600 | 2,5 | 187 A |

¹⁾ The values apply to operation with a sine-wave filter and do not correspond with the rated current on the type plate.

Commissioning

When commissioning using the STARTER or AOP30, the sine-wave filter must be activated by means of appropriate selection screenforms or dialog boxes (p0230 = 3), see section "Commissioning".

The following parameters are changed automatically during commissioning.

Table 4- 28 Parameter settings for sine-wave filters with SINAMICS G150

| Parameter | Name | Setting |
|-----------|---|--|
| p0230 | Drive filter type, motor side | 3: Siemens sine-wave filter |
| p0233 | Power unit motor reactor | Filter inductance |
| p0234 | Power unit sine-wave filter capacitance | Filter capacitance |
| p0290 | Power unit overload response | Disable pulse frequency reduction |
| p1082 | Maximum speed | Fmax filter / pole pair number |
| p1800 | Pulse frequency | Nominal pulse frequency of the filter (see previous table) |
| p1802 | Modulator mode | Space-vector modulation without overmodulation |
| p1909 | Motor data identification, control word | Rs measurement only |

4.10 Other connections

Note

When the factory settings are restored, parameter p0230 is reset.
The parameter must be reset if the system is commissioned again.

4.10.6 Connection for External Auxiliary Equipment (Option L19)

Description

This option includes an outgoing circuit fused at max. 10 A for external auxiliary equipment (e.g. separately-driven fan for motor). The voltage is tapped at the converter input upstream of the main contactor/circuit-breaker and, therefore, has the same level as the supply voltage. The outgoing circuit can be switched within the converter or externally.

Connection

Table 4- 29 Terminal block X155 - Connection for external auxiliary equipment

| Terminal | Designation ¹⁾ | Technical specifications |
|----------|--|--|
| 1 | L1 | 380 - 480 V 3 AC 500 - 600 V 3 AC 660 - 690 V 3 AC |
| 2 | L2 | |
| 3 | L3 | |
| 11 | Contactor control | 230 V AC |
| 12 | | |
| 13 | NO: Checkback motor circuit breaker | 230 V AC / 0.5 A |
| 14 | | 24 V DC / 2 A |
| 15 | NO: Checkback from contactor | 240 V AC / 6 A |
| 16 | | |
| PE | PE | PE |

¹⁾ NO: NO contact

Max. connectable cross-section: 4 mm²

Note

The connection for external auxiliary equipment must be set in accordance with the connected consumer (-Q155).

Circuit proposal for controlling the auxiliary contactor from within the converter

The following circuit, for example, can be used if the auxiliary contactor is to be controlled from within the the converter. The "Operation" message is then no longer available for other purposes.




Figure 4-11 Circuit proposal for controlling the auxiliary contactor from within the converter

Note

If 230 V AC is applied to the relay outputs, the customer terminal block must also be grounded via a 6 mm² protective conductor.

4.10.7 Main switch incl. fuses or circuit breaker (option L26)

Description

For rated currents up to 800 A (single units) and up to 1380 A (units that are connected in parallel), a switch disconnecter with externally-mounted fuses is used as the main circuit breaker. For rated currents above 800 A (single units) and above 1380 A (units that are connected in parallel), the standard circuit breaker is used to disconnect the voltage and provide overload and short-circuit protection. The circuit breaker is controlled and supplied within the converter.

CAUTION

Switching at input

Cabinet units with circuit breaker may be powered up only once every 3 minutes. Failure to observe this rule can cause damage to the cabinet unit.

4.10 Other connections

Connection

Table 4- 30 Terminal block X50 – checkback contact "main/circuit breaker closed"

| Terminal | Designation ¹⁾ | Technical specifications |
|----------|---------------------------|--|
| 1 | NO | Max. load current: 10 A Max. switching voltage: 250 V AC Max. switching capacity: 250 VA Required minimum load: ≥ 1mA |
| 2 | NC | |
| 3 | COM | |

¹⁾ NO: normally-open contact, NC: normally-closed contact, COM: mid-position contact

Max. connectable cross-section: 4 mm²



DANGER

For rated currents of more than 800 A (single units) and above 1380 A (units that are connected in parallel) and with a live line voltage, dangerous voltages are present in the cabinet unit even when the circuit breaker is open. The cabinet unit must be completely deenergized when carry out work (observe the 5 safety rules).

Setting the release current for the circuit breaker

In equipment with a circuit breaker, the release current must be set to match the plant requirements. The appropriate specifications are given in the operating instructions supplied with the circuit breaker.

In the delivery condition, the tripping current is set as follows:

Table 4- 31 Delivery condition of the overcurrent tripping unit

| Order number | Output current | Overcurrent trip (L) | Short-circuit trip, non-delayed (I) |
|--------------------|----------------|----------------------|-------------------------------------|
| 6SL3710-1GE38-4AA0 | 840 A | 1.0 | 2 |
| 6SL3710-1GE41-0AA0 | 985 A | 0.9 | 2 |
| 6SL3710-2GE41-6AA0 | 1560 A | 1.0 (both switches) | 2 (both switches) |
| 6SL3710-1GF38-1AA0 | 810 A | 1.0 | 2 |
| 6SL3710-1GH38-1AA0 | 810 A | 1.0 | 2 |
| 6SL3710-2GH41-5AA0 | 1500 A | 0.9 (both switches) | 2 (both switches) |

NOTICE

If the release current is not set correctly, the circuit breaker could trip inadvertently or delayed causing excessive damage to the cabinet unit.

Diagnostics

Messages output during operation and in the event of faults are described in the Operating Instructions in the customer DVD supplied with the device.

4.10.8 EMERGENCY OFF pushbutton installed in the cabinet door (option L45)

Description

The EMERGENCY OFF pushbutton with protective collar is integrated in the door of the cabinet unit. The contacts of the pushbutton are connected to terminal block –X120. In conjunction with options L57, L59, and L60, EMERGENCY OFF of category 0 and EMERGENCY STOP of category 1 can be activated.

A braking unit may be necessary to achieve the required shutdown times.

Note

When the EMERGENCY OFF pushbutton is pressed, the motor coasts to a standstill and the main motor voltage is disconnected (to EN 60204-1 (VDE 0113)) in conjunction with options L57, L59 and L60. Auxiliary voltages (e.g. for separately-driven fans or anti-condensation heating) may still be present. Certain sections of the converter (e.g., the closed-loop controller or any auxiliary equipment) may also remain live. If all the voltages have to be completely disconnected, the EMERGENCY OFF pushbutton must be integrated in a protection concept, which must be implemented on the line side. For this purpose, an NC contact is installed at terminal block -X120.

Connection

Table 4- 32 Terminal block X120 –checkback contact "EMERGENCY OFF pushbutton in the cabinet door"

| Terminal | Designation ¹⁾ | Technical specifications |
|----------|---------------------------|--|
| 1 | NC 1 | Checkback contacts of EMERGENCY OFF pushbutton in cabinet door Max. load current: 10 A Max. switching voltage: 250 V AC Max. switching capacity: 250 VA Required minimum load: ≥1 mA |
| 2 | | |
| 3 | NC 2 ²⁾ | |
| 4 | | |

¹⁾ NC: normally-closed contact

²⁾ Factory setting in converter for options L57, L59, and L60

Max. connectable cross-section: 4 mm²

4.10 Other connections

4.10.9 Cabinet illumination with service socket (option L50)

Description

A universal lamp with an integrated service socket is installed in each cabinet panel. The power supply for the cabinet illumination and socket must be provided externally and fused at max. 10 A. The cabinet illumination is switched on manually via a slide switch or automatically by means of an integrated motion detector (delivery condition). The mode is selected via the switch on the light.

Connection

Table 4- 33 Terminal block X390 – connection for cabinet illumination with service socket

| Terminal | Designation | Technical specifications |
|----------|-------------|--------------------------|
| 1 | L1 | 230 V AC power supply |
| 2 | N | |
| 3 | PE | Protective conductor |

Max. connectable cross-section: 4 mm²

4.10.10 Cabinet anti-condensation heating (option L55)

Description

The anti-condensation heating is used at low ambient temperatures and high levels of humidity to prevent condensation forming.

One 100 W heater is installed for a 400 mm and 600 mm cabinet panel, and two 100 W heaters for an 800/1000 and 1200 mm cabinet panel. The power supply for the heating (110 V – 230 V AC) must be provided externally and fused at max. 16 A.



 **DANGER**

When the supply voltage for the cabinet anti-condensation heating is connected, dangerous voltages are present in the cabinet unit even when the main circuit breaker is open.

Connection

Table 4- 34 Terminal block X240 – connection for cabinet anti-condensation heating

| Terminal | Designation | Technical specifications |
|----------|-------------|------------------------------------|
| 1 | L1 | 110 V – 230 V AC Voltage supply |
| 2 | N | |
| 3 | PE | Protective conductor |

Max. connectable cross-section: 4 mm²

4.10.11 EMERGENCY OFF category 0; 230 V AC or 24 V DC (option L57)

Description

EMERGENCY OFF category 0 for uncontrolled stop to EN 60204-1. This function involves disconnecting the drive from the supply via the line contactor bypassing the electronics by means of a safety combination to EN 60204-1. The motor then coasts to a stop. To prevent the main contactor from switching under load, an OFF2 is triggered simultaneously. The operational status is indicated by means of three LEDs (-K120).

In the delivery condition, this type is set with a 230 V AC button circuit.

Note

When the EMERGENCY OFF button is pressed, the motor coasts to an uncontrolled standstill and the main motor voltage is disconnected (to EN 60204-1). Auxiliary voltages (e.g. for separately-driven fans or anti-condensation heating) may still be present. Certain sections of the converter (e.g., the closed-loop controller or any auxiliary equipment) may also remain live. If all the voltages have to be completely disconnected, the EMERGENCY OFF pushbutton must be integrated in a protection concept, which must be implemented on the line side. For this purpose, an NC contact is installed at terminal -X120.

Connection

Table 4- 35 Terminal block X120 – connection for EMERGENCY OFF category 0, 230 V AC and 24 V DC

| Terminal | 230 V AC and 24 V DC button circuit |
|----------|--|
| 4 | Jumper wired in the factory |
| 5 | |
| 7 | Loop in EMERGENCY OFF button from line side, remove jumpers 7-8 and connect button |
| 8 | |
| 9 | Jumper wired in the factory |
| 10 | |
| 11 | Jumper wired in the factory |
| 14 | |
| 12 | Jumper wired in the factory |
| 13 | |
| 15 | "On" for monitored start: Remove jumpers 15-16 and connect button. |
| 16 | |
| 17 | NO ¹⁾ : Checkback "trip safety combination" |
| 18 | |

¹⁾ NO: NO contact

Max. connectable cross-section: 4 mm²

4.10 Other connections

Reconnection to the 24 V DC Button Circuit

When using the 24 V DC button circuit, you must remove the following jumpers at terminal block X120:

- 4-5, 9-10, and 11-14

You must also insert the following jumpers at terminal block X120:

- 4-11, 5-10, and 9-14

Diagnostics

Messages output during operation and in the event of faults (meaning of LEDs on -K120) are described in the "Additional Operating Instructions" of the Operating Instructions.

4.10.12 EMERGENCY STOP category 1; 230 V AC (option L59)

Description

EMERGENCY STOP category 1 for controlled stop to EN 60204-1. This function stops the drive by means of a quick stop along a deceleration ramp that must be parameterized. The cabinet unit is then disconnected from the power supply via the line contactor, which bypasses the electronics by means of a safety combination (to EN 60204-1). The operating status and the function are indicated by means of eight LEDs (-K120, -K121).

Connection

Table 4- 36 Terminal block X120 – connection for EMERGENCY STOP category 1 (230 V AC)

| Terminal | Technical specifications |
|----------|--|
| 4 | Jumper wired in the factory |
| 5 | |
| 7 | Loop in EMERGENCY OFF button from line side, remove jumpers 7-8 and connect button |
| 8 | |
| 9 | Jumper wired in the factory |
| 10 | |
| 11 | Jumper wired in the factory |
| 14 | |
| 12 | Jumper wired in the factory |
| 13 | |
| 15 | "On" for monitored start: Remove jumpers 15–16 and connect button. |
| 16 | |
| 17 | NO ¹⁾ : Checkback "trip safety combination" |
| 18 | |

¹⁾ NO: NO contact

Max. connectable cross-section: 4 mm²

Setting

The time (0.5 to 30 s) set at the contactor safety combination (-K121) should be greater (or at least identical to) the time that the drive requires to reach standstill via quick stop (OFF3 ramp-down time, p1135), since the converter is disconnected from the power supply after expiry of the time (at -K121).

Diagnostics

Messages output during operation and in the event of faults (meaning of LEDs on -K120, -K121) are described in the "Additional Operating Instructions" of the Operating Instructions.

4.10 Other connections

4.10.13 EMERGENCY STOP category 1; 24 V DC (option L60)

Description

EMERGENCY STOP category 1 for controlled stop to EN 60204-1. This function stops the drive by means of a quick stop along a deceleration ramp that must be parameterized. The cabinet unit is then disconnected from the power supply via the line contactor, which bypasses the electronics by means of a safety combination to EN 60204-1. The operating status and the function are indicated by means of five LEDs (-K120).

Connection

Table 4- 37 Terminal block X120 – connection for EMERGENCY STOP category 1 (24 V DC)

| Terminal | Technical specifications |
|----------|--|
| 4 | Jumper wired in the factory |
| 11 | |
| 5 | Jumper wired in the factory |
| 10 | |
| 7 | Loop in EMERGENCY OFF button from line side, remove jumpers 7-8 and connect button |
| 8 | |
| 9 | Jumper wired in the factory |
| 14 | |
| 12 | Jumper wired in the factory |
| 13 | |
| 15 | "On" for monitored start: Remove jumpers 15–16 and connect button. |
| 16 | |
| 17 | NO ¹⁾ : Checkback "trip safety combination" |
| 18 | |

¹⁾ NO: NO contact

Max. connectable cross-section: 4 mm²

Setting

The time (0.5 to 30 s) set at the contactor safety combination (-K120) should be greater (or at least identical to) the time that the drive requires to reach standstill via quick stop (OFF3 ramp-down time, p1135), since the converter is disconnected from the power supply after expiry of the time (at -K120).

Diagnostics

Messages output during operation and in the event of faults (meaning of LEDs on -K120) are described in the "Additional Operating Instructions" of the Operating Instructions.

4.10.14 25 kW Braking Unit (Option L61); 50 kW Braking Unit (Option L62)

Description

Braking units are used when regenerative energy occurs occasionally and briefly, for example when the brake is applied to the drive (emergency stop). The braking units comprise a chopper power unit and a load resistor, which must be attached externally. To monitor the braking resistance, a thermostat contact integrated in the trip circuit of the drive is provided in the braking resistor.

Table 4- 38 Load data for the braking units

| Supply voltage | Continuous chopper power P_{DB} | Peak chopper output P_{15} | Chopper P_{20} output P_{20} | Chopper P_{40} output P_{40} | Braking resistor R_B | Max. current |
|----------------|-----------------------------------|------------------------------|----------------------------------|----------------------------------|-------------------------|--------------|
| 380 V – 480 V | 25 kW | 125 kW | 100 kW | 50 kW | $4.4 \Omega \pm 7.5 \%$ | 189 A |
| 380 V – 480 V | 50 kW | 250 kW | 200 kW | 100 kW | $2.2 \Omega \pm 7.5 \%$ | 378 A |
| 500 V – 600 V | 50 kW | 250 kW | 200 kW | 100 kW | $3.4 \Omega \pm 7.5 \%$ | 306 A |
| 660 V – 690 V | 25 kW | 125 kW | 100 kW | 50 kW | $9.8 \Omega \pm 7.5 \%$ | 127 A |
| 660 V – 690 V | 50 kW | 250 kW | 200 kW | 100 kW | $4.9 \Omega \pm 7.5 \%$ | 255 A |

Installing the braking resistor

The braking resistor should not be installed in the vicinity of the converter. The installation location must fulfill the following conditions:

- The braking resistors are only suitable for floor mounting.
- The maximum cable length between the cabinet unit and braking resistor is 100 m.
- Sufficient space must be available for dissipating the energy converted by the braking resistor.
- A sufficient distance from flammable objects must be maintained.
- The braking resistor must be installed as a free-standing unit.
- Objects must not be placed on or anywhere above the braking resistor.
- The braking resistor should not be installed underneath fire detection systems, since these could be triggered by the resulting heat.
- For outdoor installation, a hood must be provided to protect the braking resistor from precipitation (in accordance with degree of protection IP20).

CAUTION

A ventilation clearance of 200 mm must be maintained on all sides of the braking resistor (with ventilation grilles).

4.10 Other connections

Table 4- 39 Dimensions of the braking resistors

| | Unit | 25 kW resistor (option L61) | 50 kW resistor (option L62) |
|--------|------|-----------------------------|-----------------------------|
| Width | mm | 740 | 810 |
| Height | mm | 605 | 1325 |
| Depth | mm | 485 | 485 |




Figure 4-12 Dimension drawing for braking resistor (25 kW)





Figure 4-13 Dimension drawing for braking resistor (50 kW)

Connecting the braking resistor

| |
|--|
|  WARNING |
| The cables must only be connected to terminal block -X5 when the cabinet unit is switched off and the DC link capacitors are discharged. |

| |
|--|
| CAUTION |
| The cables for the braking resistor must be routed to prevent short-circuiting and ground faults in accordance with IEC 61800-5-2:2007, Table D.1. This can be accomplished, for example, by: <ul style="list-style-type: none"> • Eliminating the risk of mechanical damage to the cables • Using cables with double insulation • Maintaining adequate clearance, using spacers, for example • Routing the cables in separate cable ducts or tubes |

| |
|---|
| CAUTION |
| The length of the connecting cables between the cabinet unit and external braking resistor must not exceed 100 m. |

Table 4- 40 Terminal block -X5 – connection for external braking resistor

| Terminal | Description of function |
|----------|-----------------------------|
| 1 | Braking resistor connection |
| 2 | Braking resistor connection |

Max. connectable cross-section: 70 mm²

Recommended cable cross-sections:

- For L61 (25 kW): 35 mm²
- For L62 (50 kW): 50 mm²

Table 4- 41 Installing the thermostatic switch for the external braking resistor in the monitoring train of the cabinet unit

| Terminal | Description of function |
|----------|---|
| T1 | Thermostatic switch connection: connection with terminal X541:1 (P24 V) |
| T2 | Thermostatic switch connection: connection with terminal X541:5 (DI11) |

Max. connectable cross-section (due to TM31): 1.5 mm²


4.10 Other connections

4.10.14.1 Commissioning

Commissioning

When commissioning via STARTER, parameters are assigned to "external fault 3" and acknowledged automatically when option L61 or L62 are selected.


When commissioning via AOP30, the parameter entries required have to be set subsequently.



Cabinet unit settings

If the thermostatic switch for the braking resistor is connected to digital input 11, appropriate settings have to be made so that the drive is brought to a standstill if a fault occurs.

Once the device has been successfully commissioned, you have to make the following changes:



4.10.14.2 Diagnosis and duty cycles

Diagnosis

If the thermostat is opened due to a thermal overload on the braking resistor, fault F7861 ("External Fault 2") is triggered and the drive is switched off with OFF2.

If the brake chopper triggers a fault, fault F7862 "External fault 3" is triggered in the drive.

You can acknowledge malfunctions in the braking unit by pressing the "Acknowledge" button on the operator panel when the DC link voltage is present).

Duty cycles




Figure 4-14 Duty cycles for the braking resistors

4.10 Other connections

4.10.14.3 Threshold switch

The response threshold at which the braking unit is activated and the DC link voltage generated during braking are specified in the following table.

| | |
|---|----------------|
| | WARNING |
| The threshold switch must only be used when the cabinet unit is switched off and the DC link capacitors are discharged. | |

Table 4- 42 Response thresholds of the braking units

| Rated voltage | Response threshold | Switch position | Comment |
|---------------|--------------------|-----------------|---|
| 380 V – 480 V | 673 V | 1 | 774 V is the delivery condition setting. With line voltages of between 380 V and 400 V, the response threshold can be set to 673 V to reduce the voltage stress on the motor and converter. This does, however, reduce the possible braking power with the square of the voltage $(673/774)^2 = 0.75$. The maximum possible braking power is, therefore, 75%. |
| | 774 V | 2 | |
| 500 V – 600 V | 841 V | 1 | 967 V is the delivery condition setting. With a line voltage of 500 V, the response threshold can be set to 841 V to reduce the voltage stress on the motor and converter. This does, however, reduce the possible braking power with the square of the voltage $(841/967)^2 = 0.75$. The maximum possible braking power is, therefore, 75%. |
| | 967 V | 2 | |
| 660 V – 690 V | 1070 V | 1 | 1158 V is the delivery condition setting. With a line voltage of 660 V, the response threshold can be set to 1070 V to reduce the voltage stress on the motor and converter. This does, however, reduce the possible braking power with the square of the voltage $(1070/1158)^2 = 0.85$. The maximum possible braking power is, therefore, 85%. |
| | 1158 V | 2 | |

Position of the threshold switch

The Braking Module is located in the top section of the cabinet unit in the discharged air duct of the Power Module. The position of the threshold switch can be taken from the figures below.




Figure 4-15 Braking Modules for frame sizes FX and GX

4.10 Other connections




Figure 4-16 Braking Modules for frame sizes HX and JX

Position of the threshold switch

Note

The threshold switches for the Braking Modules are positioned on the panel as follows:

- Braking Modules for frame sizes FX and GX: position "1" is up; position "2" is down
 - Braking Modules for frame sizes HX and JX: position "1" is back; position "2" is front
-

4.10.15 Thermistor Motor Protection Unit (Option L83/L84)

Description

This option includes the thermistor motor protection unit (with PTB approval) for PTC thermistor sensors (PTC resistor type A) for warning and shutdown. The power supply for the thermistor motor protection unit is provided inside the converter where the evaluation is also performed.

Option L83 triggers the "external alarm 1" (A7850) if a fault occurs.

Option L84 triggers the "external fault 1" (F7860) if a fault occurs.

Connection

Table 4- 43 F127/F125 – connection for thermistor motor protection unit

| Equipment designation | Description of function |
|-----------------------|--|
| -F127: T1, T2 | Thermistor motor protection (alarm) |
| -F125: T1, T2 | Thermistor motor protection (shutdown) |

The PTC thermistor sensors are connected directly to terminals T1 and T2 of the evaluation unit.

Table 4- 44 Maximum cable length for the sensor circuit

| Line cross-section in mm ² | Line length in m |
|---------------------------------------|------------------|
| 2.5 | 2 x 2800 |
| 1.5 | 2 x 1500 |
| 0.5 | 2 x 500 |

Diagnostics

Messages output during operation and in the event of faults (meaning of LEDs on -F125, F127) are described in the Operating Instructions in the customer DVD supplied with the device.

4.10 Other connections

4.10.16 PT100 Evaluation Unit (Option L86)

Description

Note

The PT100 evaluation unit and the parameters for the measurement channels are described in the "Additional Operating Instructions".

The PT100 evaluation unit can monitor up to six sensors. The sensors can be connected in a two or three-wire system. With the two-wire system, inputs xT1 and xT3 must be assigned. With the three-wire system, input xT2 must also be connected to -B140, -B141 (x = 1, 2, 3). The limit values can be freely programmed for each channel. Shielded signal cables are recommended. If this is not possible, however, the sensor cables should at least be twisted in pairs.

In the delivery condition, the measurement channels are divided into two groups of 3 channels each. With motors, for example, this means that three PT100s in the stator windings and two PT100s in the motor bearings can be monitored. Unused channels can be suppressed via parameters.

The output relays are integrated in the internal fault and alarm train of the cabinet unit. The power for the PT100 evaluation unit is supplied and the evaluation itself executed within the converter.

When the temperature set for "alarm" is exceeded, "external alarm 1" (A7850) is triggered. When the temperature set for "fault" is exceeded, "external fault 1" (F7860) is triggered.

Connection

Table 4- 45 Terminals -A1-B140, -A1-B141 – connection for PT100 evaluation unit

| Terminal | Technical specifications |
|----------------|--|
| -B140: 1T1-1T3 | 24 – 240 V AC/DC; PT100; sensor 1; group 1 |
| -B140: 2T1-2T3 | 24 – 240 V AC/DC; PT100; sensor 2; group 1 |
| -B140: 3T1-3T3 | 24 – 240 V AC/DC; PT100; sensor 3; group 1 |
| -B141: 1T1-1T3 | 24 – 240 V AC/DC; PT100; sensor 1; group 2 |
| -B141: 2T1-2T3 | 24 – 240 V AC/DC; PT100; sensor 2; group 2 |
| -B141: 3T1-3T3 | 24 – 240 V AC/DC; PT100; sensor 3; group 2 |

Max. connectable cross-section: 2.5 mm²

Diagnostics

Messages output during operation and in the event of faults (meaning of LEDs on -B140, B141) are described in the Operating Instructions in the customer DVD supplied with the device.

4.10.17 Insulation Monitor (Option L87)

Description

In non-grounded systems (IT systems), the insulation monitor checks the entire electrically-connected circuit for insulation faults. The insulation resistance as well as all the insulation faults from the mains supply to the motor in the cabinet are detected. Two response values (between 1 k Ω and 10 M Ω) can be set. If a response value is undershot, an alarm is output to the terminal. A system fault is output via the signaling relay system.

When the cabinet unit is delivered, the plant configuration (one or several loads in one electrically-connected network) and the protection philosophy (immediate shutdown in the event of an insulation fault or restricted continued motion) can vary. This means that the signaling relays of the insulation monitor must be integrated by the customer in the fault and warning sequence.

Safety information

NOTICE

Only one insulation monitor can be used within the same electrically-connected network.

Note

When the insulation monitor is used, the connection bracket for the interference suppression capacitor must be removed (see "Electrical installation / Removing the connection bracket for the interference suppression capacitor with operation from an ungrounded supply").

Controls and displays on the insulation monitor




Figure 4-17 Controls and displays on the insulation monitor

4.10 Other connections

Table 4- 46 Meaning of the controls and displays on the insulation monitor

| Position | Meaning |
|----------|--|
| 1 | INFO key: To request standard information/ ESC key: Back menu function |
| 2 | TEST key: Call up self-test Arrow key up: Parameter change, scroll |
| 3 | RESET button: Delete insulation and fault messages Arrow key down: Parameter change, scroll |
| 4 | Menu key: Call up menu system Enter key: Confirm parameter change |
| 5 | Alarm LED 1 lights up: Insulation fault, first alarm threshold reached |
| 6 | Alarm LED 2 lights up: Insulation fault, second alarm threshold reached |
| 7 | LED lights up: System error present |

Connection

Table 4- 47 Connections on insulation monitor

| Terminal | Technical specifications |
|----------|---|
| A1 | Supply voltage via 6 A melting fuse: 88 to 264 V AC, 77 to 286 V DC |
| A2 | |
| L1 | Connection of the 3 AC system to be monitored |
| L2 | |
| AK | Connection to coupling device |
| KE | PE connection |
| T1 | External test button |
| T2 | External test button |
| R1 | External reset key (NC contact or wire jumper otherwise the fault code is not stored) |
| R2 | External reset key (NC contact or wire jumper) |
| F1 | STANDBY with aid of F1, F2 function input: |
| F2 | |
| M+ | External kΩ display, analog output (0 μA ... 400 μA) |
| M- | External kΩ display, analog output (0 μA ... 400 μA) |
| A | Serial interface RS 485 (termination by means of 120 ohm resistor) |
| B | |
| 11 | Signaling relay ALARM 1 (mid-position contact) |
| 12 | Signaling relay ALARM 1 (NC contact) |
| 14 | Signaling relay ALARM 1 (NO contact) |
| 21 | Signaling relay ALARM 2 (mid-position contact) |
| 22 | Signaling relay ALARM 2 (NC contact) |
| 24 | Signaling relay ALARM 2 (NO contact) |

Max. connectable cross-section: 2.5 mm²

Diagnostics

For a description of messages output during operation and in the event of faults (meaning of LEDs on -B101), consult the Operating Instructions in the customer DVD supplied with the device.

4.10.18 Communication Board Ethernet CBE20 (Option G33)

Description

Interface module CBE20 is used for communication via PROFINET.

The module is inserted in the option slot of the Control Unit at the factory.

4 Ethernet interfaces are available on the module. Diagnosis of the function mode and communication are possible via LEDs.

Interface overview




Figure 4-18 Communication Board Ethernet CBE20

MAC address

The MAC address of the Ethernet interfaces is indicated on the upper side of the CBE20. The plate is not visible when the module is installed.

Note

Remove the module from the option slot of the Control Unit and note down the MAC address so that it is available during subsequent commissioning.

4.10 Other connections

Removal/installation

CAUTION

The Option Board may only be inserted and removed when the Control Unit and Option Board are disconnected from the power supply.




Figure 4-19 Removing the CBE20 from the option slot on the Control Unit

X1400 Ethernet interface

Table 4- 48 Connector X1400, port 1 - 4

| | Pin | Signal name | Technical specifications |
|--|--------------------|-------------|-------------------------------|
| | 1 | RX+ | Receive data + |
| | 2 | RX- | Receive data - |
| | 3 | TX+ | Transmit data + |
| | 4 | --- | Reserved, do not use |
| | 5 | --- | Reserved, do not use |
| | 6 | TX- | Transmit data - |
| | 7 | --- | Reserved, do not use |
| | 8 | --- | Reserved, do not use |
| | Screened backshell | M_EXT | Screen, permanently connected |

4.10.19 CBC10 CAN Communication Board (option G20)

Description



Figure 4-20 CAN CBC10 Communication Board

The CBC10 CANopen communication board (CAN Communication Board) is used to connect drives in the SINAMICS drive system to higher-level automation systems with a CAN bus.

The CANopen Option Board uses two 9-pin sub D connectors for the connection to the CAN bus system.

The connectors can be used as inputs or outputs. Unused pins are plated through.

Among others, the following transmission rates are supported: 10, 20, 50, 125, 250, 500, 800 kBaud, and 1 Mbaud.

CAUTION

The Option Board may only be inserted and removed when the Control Unit and Option Board are disconnected from the power supply.

The CBC10 must only be operated by qualified personnel. The ESD notices must be observed.

The module is inserted in the option slot of the Control Unit at the factory.

4.10 Other connections

Interface overview





Figure 4-21 CAN CBC10 Communication Board


CAN bus interface -X451

Table 4- 49 CAN bus interface -X451

| | Pin | Designation | Technical specifications |
|---|-----|----------------------|---------------------------|
|  | 1 | Reserved, do not use | |
| | 2 | CAN_L | CAN signal (dominant low) |
| | 3 | CAN_GND | CAN ground |
| | 4 | Reserved, do not use | |
| | 5 | CAN_SHLD | Optional shield |
| | 6 | GND | CAN ground |
| | 7 | CAN_H | CAN signal |
| | 8 | Reserved, do not use | |
| | 9 | Reserved, do not use | |
| Type: 9-pin sub D socket | | | |

CAN bus interface -X452

Table 4- 50 CAN bus interface -X452

| | Pin | Designation | Technical specifications |
|---|-----|----------------------|---------------------------|
|  | 1 | Reserved, do not use | |
| | 2 | CAN_L | CAN signal (dominant low) |
| | 3 | CAN_GND | CAN ground |
| | 4 | Reserved, do not use | |
| | 5 | CAN_SHLD | Optional shield |
| | 6 | GND | CAN ground |
| | 7 | CAN_H | CAN signal |
| | 8 | Reserved, do not use | |
| | 9 | Reserved, do not use | |
| Type: 9-pin sub D pin | | | |

Further information about communication via CAN bus

Note

Detailed and comprehensive instructions and information for the CANopen interface can be found in the accompanying Function Manual. This manual is available as additional documentation on the accompanying customer DVD.

4.10 Other connections

4.10.20 SMC30 Sensor Module Cabinet-Mounted (option K50)

4.10.20.1 Description

The SMC30 Sensor Module is used for determining the actual motor speed. The signals emitted by the rotary pulse encoder are converted here and made available to the closed-loop controller via the DRIVE-CLiQ interface for evaluation purposes.

In conjunction with SINAMICS G150 the following sensors can be connected to the SMC30 Sensor Module:

- TTL encoder
- HTL encoder
- KTY or PTC temperature sensor

Table 4- 51 Connectable encoders with supply voltage

| Encoder type | X520 (D-Sub) | X521 (terminal) | X531 (terminal) | Open-circuit monitoring | Remote sense |
|-------------------|--------------|-----------------|-----------------|-------------------------|--------------|
| HTL bipolar 24 V | Yes | Yes | Yes | Yes | No |
| HTL unipolar 24 V | Yes | Yes | Yes | No | No |
| TTL bipolar 24 V | Yes | Yes | Yes | Yes | No |
| TTL bipolar 5 V | Yes | Yes | Yes | Yes | To X520 |
| TTL unipolar | No | No | No | No | No |

Table 4- 52 Maximum signal cable lengths

| Encoder type | Maximum signal cable length in m |
|--------------|----------------------------------|
| TTL | 100 |
| HTL unipolar | 100 |
| HTL bipolar | 300 |

Note

Because the physical transmission media is more robust, the bipolar connection should always be used for HTL encoders. The unipolar connection should only be used if the encoder type does not output push-pull signals.

Table 4- 53 Specification of measuring systems that can be connected

| Parameters | Designation | Threshold ⁴⁾ | Min. | Max. | Unit |
|---|-------------|-------------------------|-----------|---|------|
| High signal level (TTL bipolar at X520 or X521/X531) ¹⁾ | U_{Hdiff} | | 2 | 5 | V |
| Low signal level (TTL bipolar at X520 or X521/X531) ¹⁾ | U_{Ldiff} | | -5 | -2 | V |
| High signal level (HTL unipolar) | $U_H^{4)}$ | High | 17 | V_{CC} | V |
| | | Low | 10 | V_{CC} | V |
| Low signal level (HTL unipolar) | $U_L^{4)}$ | High | 0 | 7 | V |
| | | Low | 0 | 2 | V |
| High signal level (HTL bipolar) ²⁾ | U_{Hdiff} | | 3 | V_{CC} | V |
| Low signal level (HTL bipolar) ²⁾ | U_{Ldiff} | | $-V_{CC}$ | -3 | V |
| Signal frequency | f_s | | - | 300 | kHz |
| Edge clearance | t_{min} | | 100 | - | ns |
| Zero pulse inactive time (before and after A=B=high) | t_{Lo} | | 640 | $(t_{ALo-BHi} - t_{Hi})/2$ ³⁾ | ns |
| Zero pulse active time (while A=B=high and beyond) | t_{Hi} | | 640 | $t_{ALo-BHi} - 2 \times t_{Lo}$ ³⁾ | ns |

¹⁾ Other signal levels according to the RS 422 standard.

²⁾ The absolute level of the individual signals varies between 0 V and V_{CC} of the measuring system.

³⁾ $t_{ALo-BHi}$ is not a specified value, but is the time between the falling edge of track A and the next but one rising edge of track B.

⁴⁾ The threshold can be set via p0405.04 (switching threshold); the setting on delivery is "Low".




Figure 4-22 Signal characteristic of the A and B track between two edges: Time between two edges with pulse encoders

4.10 Other connections




Figure 4-23 Position of the zero pulse to the track signals

For encoders with a 5 V supply at X521/X531, the cable length is dependent on the encoder current (this applies cable cross-sections of 0.5 mm²):




Figure 4-24 Signal cable length as a function of the sensor current consumption

For encoders without Remote Sense the permissible cable length is restricted to 100 m (reason: the voltage drop depends on the cable length and the encoder current).





Figure 4-25 SMC30 Sensor Module

4.10 Other connections

4.10.20.2 Connection

X520: Encoder connection 1 for HTL/TTL encoder with open-circuit monitoring

Table 4- 54 Encoder connection X520

| | Pin | Signal name | Technical specifications |
|---|-----|----------------------|---|
|  | 1 | +Temp | Temperature sensor connection KTY84-1C130/PTC |
| | 2 | Reserved, do not use | |
| | 3 | Reserved, do not use | |
| | 4 | P encoder 5 V/24 V | Encoder supply |
| | 5 | P encoder 5 V/24 V | Encoder supply |
| | 6 | P sense | Sense input encoder power supply |
| | 7 | M encoder (M) | Ground for encoder power supply |
| | 8 | -Temp | Temperature sensor connection KTY84-1C130/PTC |
| | 9 | M sense | Ground sense input |
| | 10 | R | Reference signal R |
| | 11 | R* | Inverse reference signal R |
| | 12 | B* | Inverse incremental signal B |
| | 13 | B | Incremental signal B |
| | 14 | A* | Inverse incremental signal A |
| | 15 | A | Incremental signal A |

Connector type: 15-pin socket

DANGER

Risk of electric shock!

Only temperature sensors that meet the electrical separation specifications contained in EN 61800-5-1 may be connected to terminals "+Temp" and "-Temp".

If these instructions are not complied with, there is a risk of electric shock!

CAUTION


The encoder power supply can be parameterized to 5 V or 24 V. The encoder may be destroyed if you enter the wrong parameter.

NOTICE

The KTY temperature sensor must be connected with the correct polarity.

X521 / X531: Encoder connection 2 for HTL/TTL encoder with open-circuit monitoring

Table 4- 55 Encoder connection X521


| | Terminal | Signal name | Technical specifications |
|---|----------|-------------|------------------------------|
|  | 1 | A | Incremental signal A |
| | 2 | A* | Inverse incremental signal A |
| | 3 | B | Incremental signal B |
| | 4 | B* | Inverse incremental signal B |
| | 5 | R | Reference signal R |
| | 6 | R* | Inverse reference signal R |
| | 7 | CTRL | Control signal |
| | 8 | M | Ground via inductivity |

Max. connectable cross-section: 1.5 mm²


Note

When unipolar HTL encoders are used, A*, B*, and R* on the terminal block must be jumpered with M_Encoder (X531).

Table 4- 56 Encoder connection X531

| | Terminal | Signal name | Technical specifications |
|---|----------|----------------------|---|
|  | 1 | P encoder 5 V/24 V | Encoder supply |
| | 2 | M encoder | Ground for encoder power supply |
| | 3 | -Temp | Temperature sensor connection KTY84-1C130/PTC |
| | 4 | +Temp | |
| | 5 | Reserved, do not use | |
| | 6 | Reserved, do not use | |
| | 7 | Reserved, do not use | |
| | 8 | Reserved, do not use | |

Max. connectable cross-section: 1.5 mm²

| |
|--|
|  DANGER Risk of electric shock! Only temperature sensors that meet the electrical separation specifications contained in EN 61800-5-1 may be connected to terminals "+Temp" and "-Temp". If these instructions are not complied with, there is a risk of electric shock! |
|--|

Note

Note that when the encoder is connected via terminals, the cable shield must be applied to the module.

4.10 Other connections

NOTICE
The KTY temperature sensor must be connected with the correct polarity.

4.10.20.3 Connection examples

Connection example 1: HTL encoder, bipolar, without zero marker -> p0405 = 9 (hex)




Figure 4-26 Connection example 1: HTL encoder, bipolar, without zero marker

Connection example 2: TTL encoder, unipolar, without zero marker -> p0405 = A (hex)




Figure 4-27 Connection example 2: TTL encoder, unipolar, without zero marker

4.10.21 Voltage Sensing Module for determining the actual motor speed and the phase angle (option K51)

Voltage recording module VSM10 is used to operate a permanent-field synchronous machine without encoder with the requirement for switching to a machine which is already running (capture function).

The terminals on the Voltage Sensing Module (-B51) are pre-assigned in the factory and must not be changed by the customer.

To commission the function, the permanent-field synchronous machine without encoder must be input and "Flying restart" activated with p1200.

4.10.22 Customer terminal block (option G60)

Description

With option G60, a TM31 interface module (customer terminal block –A60) is already installed in the cabinet unit. This provides the following interfaces:

- 8 digital inputs
- 4 bidirectional digital inputs/outputs
- 2 relay outputs with changeover contact
- 2 analog inputs
- 2 analog outputs
- 1 temperature sensor input (KTY84-130/PTC)

The description of the interfaces is given in the Chapter "Electrical Installation/Signal connections"

Integration of the interfaces takes place using pre-interconnections prepared in the factory, which can be selected during commissioning.

4.10 Other connections

4.10.23 Customer terminal block extension (option G61)

Description

With option G60, a TM31 interface module (customer terminal block –A60) is already installed in the cabinet unit. A second module (–A61) provides the following additional digital and analog inputs/outputs in the drive system:

- 8 digital inputs
- 4 bidirectional digital inputs/outputs
- 2 relay outputs with changeover contact
- 2 analog inputs
- 2 analog outputs
- 1 temperature sensor input (KTY84-130/PTC)

The second TM31 must be installed on the system side. Default settings are not provided.

4.10.24 Terminal module for activation of "Safe Torque Off" and "Safe STOP 1" (option K82)

Description

Option K82 (terminal module for activating "Safe Torque Off" and "Safe Stop 1") is used for isolated activation via a variable control-voltage range of the safety functions already present in the standard version, which can also be used without option K82.

Use the option K82 to activate the following safety integrated functions (terminology according to draft IEC 61800-5-2):

- Safe torque off (STO)
- Safe Stop 1 (SS1, time-controlled)

Note

The integrated safety functions, starting from the Safety Integrated (SI) input terminals of the SINAMICS components (Control Unit, Power Module), satisfy the requirements according to EN 61800-5-2, EN 60204-1, DIN EN ISO 13849-1 category 3 (formerly EN 954-1) for Performance Level (PL) d and IEC 61508 SIL2.

In combination with the option K82, the requirements specified in EN 61800-5-2, EN 60204-1 as well as in DIN EN ISO 13849-1 category 3 (formerly EN 954-1) are satisfied for Performance Level (PL) d and IEC 61508 SIL2.

Note

Detailed and comprehensive instructions and information for the Safety Integrated functions can be found in the accompanying Function Manual. This manual is available as additional documentation on the customer DVD supplied with the device.

4.10.25 NAMUR terminal block (option B00)

Description

The terminal block is designed in accordance with the requirements and guidelines defined by the standards association for measurement and control systems in the chemical industry (NAMUR – recommendation NE37), that is, certain device functions are assigned to fixed terminals. The inputs and outputs assigned to the terminals fulfill PELV ("protective extra-low voltage and protective separation") requirements.

The terminal block only contains the necessary functions. Unlike the NAMUR recommendation, optional terminals are not available.

The 24 V DC is supplied on the line side via terminals –A1-X2:1-3 (protected with 1 A within the converter). You must ensure that the PELV safety requirements (protective extra-low voltage with protective separation) are fulfilled.

To monitor the temperature of explosion-proof motors, option B00 features a PTC thermistor release mechanism with PTB approval. Shutdown if limit value is exceeded. The associated PTC sensor is connected to terminal –A1-X3:90, 91.

The terminal block is divided into three sections:

- -X1; -X2: for the power connections
- -A1-X2: for signal cables, which must fulfill PELV requirements with electrical separation.
- -A1-X3: for connecting the motor PTC thermistor detector

Connection

Table 4- 57 Terminal block -A1-X2 – 24 V supply voltage connection

| Terminal | Designation | Default | Comment |
|----------|-------------|--------------------------|--------------------------------------|
| 1 | M | Reference conductor | |
| 2 | P24 V | 24 V DC supply | Protected internally with fuse (1 A) |
| 3 | P24 V | 24 V DC outgoing circuit | |

Max. connectable cross-section: 2.5 mm²

4.10 Other connections

Table 4- 58 Terminal block -A1-X2 – connection NAMUR control terminal block

| Terminal | Designation | Default | Comment |
|----------|--------------|--------------------------------------|---|
| 10 | DI | ON/OFF (dynamic)/ ON/OFF (static) | Effective operation can be coded by a wire jumper on terminal -A1-X400:9;10 (delivery condition: jumper inserted): jumper inserted: ON/OFF (dynamic)/ jumper removed: ON/OFF (static) |
| 11 | DI | OFF (dynamic) | |
| 12 | DI | Faster | Motorized potentiometer |
| 13 | DI | Slower | Motorized potentiometer |
| 14 | DI | RESET | Acknowledge error |
| 15 | DI | Interlock | OFF2 |
| 16 | DI | Counterclockwise | "0" signal: CW phase sequence "1" signal: CCW phase sequence |
| 17 | DI | Power Disconnection | EMERGENCY OFF circuit |
| 18 | | | "0" signal: Power disconnection "1" signal: No power disconnection |
| 30 | DO (COM) | Ready for operation | Relay output (NO contact) |
| 31 | DO (NO) | | |
| 32 | DO (COM) | Motor turning | Relay output (NO contact) |
| 33 | DO (NO) | | |
| 34 | DO (NO) | Fault | Relay output (two-way contact) |
| 35 | DO (COM) | | |
| 36 | DO (NC) | | |
| 50/51 | AI 0/4-20 mA | | |
| 60/61 | AO 0/4-20 mA | Motor frequency | Default: 4 - 20 mA (defaulted with motor frequency, can be reparameterized for other variables) |
| 62/63 | AO 0/4-20 mA | Motor current | Default: 4 - 20 mA (defaulted with motor current, can be reparameterized for other variables) |

Max. connectable cross-section: 2.5 mm²

Table 4- 59 Terminal block -A1-X3 – connection for the motor PTC thermistor sensor

| Terminal | Designation | Default | Comment |
|----------|-------------|---------------------------------|--------------------------------------|
| 90/91 | AI | Connection for a PTC thermistor | Shutdown if limit value is exceeded. |

Max. connectable cross-section: 2.5 mm²

Adapting the analog inputs and outputs

If the setting ranges of the analog inputs and outputs are to be changed, the associated interface converters (-T411 / -T412 / -T413) must be set. The corresponding interface converter must be removed for this purpose and the rotary switch on the side ("S1") turned to the corresponding position.

Table 4- 60 Terminal block -A1-X2 – Adaptation of analog inputs and outputs

| Terminal | Designation | Item code of interface converter | Settings on rotary switch S1 |
|----------|-------------|----------------------------------|--|
| 50/51 | AI | T411 | 2: 0 - 20 mA 4: 4 - 20 mA (preassignment) |
| 60/61 | AO | T412 | 1: 0 - 20 mA 2: 4 - 20 mA (preassignment) |
| 62/63 | AO | T413 | 1: 0 - 20 mA 2: 4 - 20 mA (preassignment) |

4.10.26 Separate 24 V DC power supply for NAMUR (option B02)

Description

If the customer cannot provide a separate 24 V DC supply (PELV), this option enables a second power supply to be installed to provide the PELV (terminal assignment as option B00, 24 V infeed at terminal -A1-X1:1,2,3 no longer needed).

4.10.27 Outgoing section for external auxiliary equipment for NAMUR (option B03)

Description

If power is to be supplied to a motor fan on site, option B03 provides an uncontrolled fuse-protected (10 A) outgoing section. As soon as the supply voltage is present at the converter input, it is also present at these terminals. The voltage corresponds to the converter input voltage. You must take this into account when configuring the separately driven fan.

Connection

Table 4- 61 Terminal block -A1-X1 – uncontrolled power outlet (10 A) for supplying a separately driven motor fan

| Terminal | Default | Comments |
|-------------|--|----------------|
| 1, 2, 3, PE | Outgoing section for separately driven motor fan | $U = U_{line}$ |

Max. connectable cross-section: 2.5 mm²

4.10 Other connections


5

Commissioning

5.1 Chapter content

This chapter provides information on the following:

- An overview of the operator panel functions
- Initial commissioning of the cabinet (initialization)
 - Entering the motor data (drive commissioning)
 - Entering the most important parameters (basic commissioning), concluding with motor identification
- Data backup
- Parameter reset to factory settings



5.2 STARTER commissioning tool

Important information prior to commissioning

The cabinet unit offers a varying number of internal signal interconnections depending on the delivery condition and the options installed. For the converter control to be able to process the signals correctly, several software settings must be made.

During initial power-up of the Control Unit and during first commissioning, parameter macros are executed and the necessary settings made. The settings are documented in the Appendix.

After initial power-up, first commissioning, and also following a "Parameter reset to factory settings", individual parameter values deviate from the factory settings stated in the List Manual.

5.2 STARTER commissioning tool

Description

You can use the STARTER commissioning tool to configure and commission SINAMICS drives and drive systems. The drive can be configured using the STARTER drive configuration wizard.

Note

This chapter shows you how to carry out commissioning using STARTER. STARTER features a comprehensive online help function, which provides detailed explanations of all the processes and available system settings. For this reason, this chapter only describes the individual commissioning steps.

Prerequisite: STARTER Version

The following STARTER version is required for commissioning SINAMICS with firmware V4.3 SP2:

- STARTER V4.1.5 +SSP for SINAMICS V 04.32.10.00

Prerequisites for installing STARTER

Hardware

The following minimum requirements must be complied with:

- PG or PC
- Pentium III, 800 MHz min., (> 1 GHz recommended)
- 512 MB main memory (1 GB recommended)
- Screen resolution 1024×768 pixels, 16-bit color depth

**Software**

The following minimum prerequisites must be observed when using STARTER without an existing STEP-7 installation:

- Microsoft Windows 2000 SP4
- Microsoft Windows 2003 Server SP1, SP2
- Microsoft Windows XP Professional SP2, SP3
- Microsoft Windows VISTA Business SP1 (without DCC)
- Microsoft Windows VISTA Ultimate SP1 (without DCC)
- Microsoft Internet Explorer V6.0 or higher
- STARTER setup is possible with native Windows XP versions with far east languages only if the Windows XP software is an MUI version.
- Acrobat Reader V5.0 or higher is required to open the function diagrams in the online help.

Note

If STARTER is used in combination with other STEP7 components, the prerequisites for the S7 components shall apply.

5.2.1 Installing the STARTER commissioning tool

STARTER is installed using the "setup" file on the customer DVD supplied. When you double-click the "Setup" file, the installation Wizard guides you through the process of installing STARTER.

5.2 STARTER commissioning tool

5.2.2 Layout of the STARTER user interface

STARTER features four operating areas:




Figure 5-1 STARTER operating areas

| Operating area | Explanation |
|----------------------|--|
| 1: Toolbars | In this area, you can access frequently used functions via the icons. |
| 2: Project navigator | The elements and projects available in the project are displayed here. |
| 3: Working area | In this area, you can change the settings for the drive units. |
| 4: Detail view | Detailed information about faults and alarms, for example, is displayed this area. |

5.3 Procedure for commissioning via STARTER

Basic procedure using STARTER

STARTER uses a sequence of dialog screens for entering the required drive unit data.

NOTICE

These dialog screens contain default settings, which you may have to change according to your application and configuration.

This is intentional because

By taking time to consider what configuration data you enter, you can prevent inconsistencies between the project data and drive unit data (identifiable in online mode).

5.3.1 Creating the project

Click the STARTER icon on your desktop or choose the following menu path in the Windows start menu to call up STARTER: Start > Simatic > STEP 7 > STARTER.

The first time you run the software, the main screen (shown below) appears with the following windows:

- STARTER Getting Started Drive Commissioning
- STARTER Project Wizard

The commissioning steps are listed below in numerical order.

5.3 Procedure for commissioning via STARTER

Accessing the STARTER project wizard




Figure 5-2 Main screen of the STARTER parameterization and commissioning tool

⇒ Close the "STARTER Getting Started Drive Commissioning" screen by choosing **HTML Help > Close**.

Note

When you deactivate the **Display wizard during start** checkbox, the project wizard is no longer displayed the next time you start STARTER.

You can call up the project wizard by choosing **Project > New with Wizard**.

To deactivate the online help for **Getting Started**, follow the instructions provided in Help.

You can call up the online help at any time by choosing **Help > Getting Started**.

STARTER features a detailed online help function.

The STARTER project wizard




Figure 5-3 STARTER project wizard

⇒ Click **Arrange drive units offline...** in the STARTER project wizard.




Figure 5-4 Create new project

⇒ Enter a **project name** and, if necessary, the **author**, **memory location** and a **comment**.

⇒ Click **Continue >** to set up the PG/PC interface.

5.3 Procedure for commissioning via STARTER




Figure 5-5 Set up interface

⇒ Click **Change and test...** and set up the interface in accordance with your device configuration.

The **Properties...**, **Copy...** and **Select...** pushbuttons are now active.




Figure 5-6 Setting the interface

Note

To parameterize the interface, you must install the appropriate interface card (e.g.: PC Adapter (PROFIBUS))




Figure 5-7 Setting the interface - properties

NOTICE

You must activate **PG/PC is the only master on bus** if no other master (PC, S7, etc.) is available on the bus.

Note

Projects can be created and PROFIBUS addresses for the drive objects assigned even if a PROFIBUS interface has not been installed on the PC.

To prevent bus addresses from being assigned more than once, only the bus addresses available in the project are proposed.

⇒ Once you have done this, click **OK** to confirm the settings and return to the project wizard.

5.3 Procedure for commissioning via STARTER




Figure 5-8 Setting the interface

⇒ Click **Continue** > to set up a drive unit in the project wizard.




Figure 5-9 Inserting the drive unit

⇒ Choose the following data from the list fields:

Device: Sinamics

Type: G150 CU320-2 DP

Version: 4.3.2

Bus address: the corresponding bus address for the cabinet unit
The entry in **Name:** field is user defined.

⇒ Click **Insert**

The selected drive unit is displayed in a preview window in the project wizard.




Figure 5-10 Inserting the drive unit

⇒ Click **Continue >**
A project summary is displayed.




Figure 5-11 Summary

⇒ Click **Complete** to finish creating a new drive unit project.

5.3 Procedure for commissioning via STARTER

5.3.2 Configure the drive unit

In the project navigator, open the component that contains your drive unit.




Figure 5-12 Project navigator – Configure drive unit

⇒ In the project navigator, click the plus sign next to the drive unit that you want to configure. The plus sign becomes a minus sign and the drive unit configuration options are displayed as a tree below the drive unit.

⇒ Double-click **Configure the drive unit**.

Configuring the drive unit




Figure 5-13 Configuring the drive unit

⇒ Under **Connection voltage**, choose the correct voltage. Under **Cooling method**: choose the correct cooling method for your drive unit.

Note

In this step, you make a preliminary selection of the cabinet units. You do not define the line voltage and cooling method yet.

⇒ A list is now displayed under **Drive unit selection**:. Choose the corresponding drive unit according to type (order no.) (see type plate).

⇒ Click **Continue** >

5.3 Procedure for commissioning via STARTER

Choosing the options




Figure 5-14 Choosing the options

⇒ From the combination box **Options selection**: select the options belonging to your drive unit by clicking on the corresponding check box (see type plate).

CAUTION

If a sine-wave filter (option L15) is connected, it must be activated when the options are selected to prevent the filter from being destroyed.

NOTICE

During option selection it is essential to activate any motor reactor (option L08) or dV/dt filter (option L10) present, otherwise the motor control will not perform at its best.

Note

Check your options carefully against the options specified on the type plate.

Since the wizard establishes internal interconnections on the basis of the options selected, you cannot change the selected options by clicking **< Back**.

If you make an incorrect entry, delete the entire drive unit from the project navigator and create a new one.

⇒ Check your options carefully and then click **Continue >**

Selecting the control structure




Figure 5-15 Selecting the control structure

5.3 Procedure for commissioning via STARTER

⇒ Select the required data:

- **Function modules:**

- Technology controller
- Extended messages/monitoring

- **Control method:**

choose one of the following open-loop/closed-loop control types:

- 0: V/f control with linear characteristic
- 1: V/f control with linear characteristic and FCC
- 2: V/f control with parabolic characteristic
- 3: V/f control with parameterizable characteristic
- 4: V/f control with linear characteristic and ECO
- 5: V/f control for drive requiring a precise frequency (e.g. textiles)
- 6: V/f control for drive requiring a precise frequency and FCC
- 7: V/f control with parabolic characteristic and ECO
- 18: I/f control with fixed current
- 19: V/f control with independent voltage setpoint
- 20: Speed control (without encoder)
- 21: Speed control (with encoder)
- 22: Torque control (without encoder)
- 23: Torque control (with encoder)

⇒ Click **Continue** >

Configuring the drive unit properties




Figure 5-16 Configuring the drive unit properties

⇒ Under **Standard:**, choose the appropriate standard for your motor, whereby the following is defined:

- IEC motor (50 Hz, SI unit): Line frequency 50 Hz, motor data in kW
- NEMA motor (60 Hz, US unit): Line frequency 60 Hz, motor data in hp

⇒ Under **Connection voltage:**, enter the appropriate voltage of the cabinet unit.

⇒ Click **Continue >**

5.3 Procedure for commissioning via STARTER

Configuring the motor – Selecting the motor type




Figure 5-17 Configuring the motor – Selecting the motor type

⇒ Under **Motor name**: enter a name for the motor.

⇒ From the selection box next to **Motor type**: select the appropriate motor for your application.

⇒ In the **Parallel connection motor** field, enter the number of motors connected in parallel, if necessary. Motors connected in parallel must be of the same type and size.

Note

The steps described below also apply to commissioning an induction motor.

When commissioning a permanent-magnet synchronous motor, there are a few special conditions that apply, which are detailed in a separate chapter (see "Setpoint channel and closed-loop control/permanent-magnet synchronous motors").

⇒ Click **Continue >**

Configuring the motor – Entering motor data

Configuration - G150_CU320_2_DP - Motor data

Drive: Drive_1, DDS 0, MDS 0

Motor data, Induction motor (rotary):

| Paramet | Parameter text | Value | Unit |
|---------|--------------------------|-----------|------|
| p304[0] | Rated motor voltage | 340 | Vrms |
| p305[0] | Rated motor current | 204.00 | Arms |
| p307[0] | Rated motor power | 95.00 | kW |
| p308[0] | Rated motor power factor | 0.840 | |
| p310[0] | Rated motor frequency | 50.60 | Hz |
| p311[0] | Rated motor speed | 1500.0 | rpm |
| p335[0] | Motor cooling type | [1] Force | |

The motor data must be entered completely!

Do you want to enter the optional data?

Do you want to enter the equivalent circuit diagram data?

Note:
Deselection of the optional or equivalent circuit diagram data resets these irrevocably.

Motor identification is required when the equivalent circuit diagram data is deselected. Motor identification is optional when the equivalent circuit diagram data is entered.

< Back Cancel Help

Figure 5-18 Configuring the motor – Entering motor data

- ⇒ Enter the motor data (see motor type plate).
- ⇒ If necessary, check **Do you want to enter the optional data?**
- ⇒ If necessary, activate **Do you want to enter the equivalent circuit diagram data?**

Note

Click **Template** to open another selection screenform where you can choose the motor used in your application from a long list of standard motor types. Select a motor from the list to enter the data stored in the system for that motor automatically in the data fields.

5.3 Procedure for commissioning via STARTER

NOTICE

You should only check the "Do you want to enter equivalent circuit diagram data?" box if the data sheet with equivalent circuit diagram data is available. If any data is missing, an error message will be output when the system attempts to load the drive project to the target system.

⇒ Click **Continue** >

Configuring the motor – Entering optional data




Figure 5-19 Entering optional motor data

⇒ If required, enter the optional motor data.

⇒ Click **Continue** >

Configuring the motor – Entering the equivalent circuit diagram data




Figure 5-20 Entering equivalent circuit diagram data

⇒ If required, enter the equivalent circuit diagram data.

⇒ Click **Continue >**

5.3 Procedure for commissioning via STARTER

Calculating the motor/controller data



Figure 5-21 Calculating the motor/controller data

⇒ In **Calculation of the motor/controller data**, select the appropriate default settings for your device configuration.

Note

If the equivalent circuit diagram data was entered manually (see figure "Entering the equivalent circuit diagram data"), the motor/controller data should be calculated without calculating the equivalent circuit diagram data.

⇒ Click **Continue >**

Configuring the motor holding brake




Figure 5-22 Configuring the motor holding brake

⇒ Under **Holding brake configuration**: choose the appropriate settings for your device configuration.

⇒ Click **Continue >**

5.3 Procedure for commissioning via STARTER

Entering the encoder data (option K50)

Note

If you have specified option K50 (SMC30 Sensor Module), the following screen is displayed in which you can enter the encoder data.




Figure 5-23 Entering the encoder data

⇒ In the **Encoder name**: field, enter a name of your choice.

Note

The delivery condition is a bipolar HTL encoder with 1024 pulses per revolution at terminal X521/X531.

⇒ To select a different predefined encoder configuration, check the **Select standard encoder from list** radio button and select one of the encoders from the list.

⇒ To enter special encoder configurations, click the **Enter data** radio button and then the **Encoder data** button. The following screen is displayed in which you can enter the required data.

The screenshot shows the 'Encoder Data' dialog box with the following settings:

- Encoder type:** Rotary
- Measuring system:** Incremental HTL/TTL
- Encoder evaluation:** SMC30
- Supply voltage:** 24 V
- Encoder connection:** Terminal
- Incremental tracks:** Pulses/revolution: 1024, Level: HTL, Signal: Bipolar
- Zero marks:** Configuration: No zero mark, Zero mark spacing: (empty), No. of zero marks: (empty)

Figure 5-24 Entering encoder data – User-defined encoder data

⇒ Select the **measuring system**.

In conjunction with SINAMICS G150, the following encoders can be selected:

- HTL
- TTL

⇒ Enter the required encoder data.

⇒ Click **OK**.

CAUTION

Once the encoder has been commissioned, the supply voltage (5/24 V) set for the encoder is activated on the SMC30 Module. If a 5 V encoder is connected and the supply voltage has not been set correctly, the encoder may be damaged.

5.3 Procedure for commissioning via STARTER

Default settings for setpoints/command sources




Figure 5-25 Default settings for setpoints/command sources

⇒ Under **Command sources**, choose and **Setpoint sources**: choose the appropriate settings for your device configuration.

The following command and setpoint source options are available:

- | | |
|-------------------|---|
| Command sources: | PROFIdrive (default) TM31 terminals NAMUR PROFIdrive NAMUR |
| Setpoint sources: | PROFIdrive (default) TM31 terminals Motorized potentiometer Fixed setpoint |

Note

With SINAMICS G150, only CDS0 is normally used as a default setting for the command and setpoint sources.

Make sure that the selected default setting is compatible with the actual system configuration.

Note

The choice "no selection" is also available as default setting for the command and setpoint sources; if selected, no default settings are applied for the command and setpoint sources.

⇒ Check your default settings carefully and then click **Continue** >

Defining the technological application/motor identification




Figure 5-26 Defining the technological application/motor identification

5.3 Procedure for commissioning via STARTER

⇒ Select the required data:

- **Technological application:**

- **"(0) Standard drive (VECTOR)"**
Edge modulation is not enabled.
The dynamic voltage reserve is increased (10 V), which reduces the maximum output voltage.
- **"(1) Pumps and fans"(default setting)**
Edge modulation is enabled.
The dynamic voltage reserve is reduced (2 V), which increases the maximum output voltage.
- **"(2) (Encoderless control down to f = 0 (passive loads))"**
Controlled operation down to standstill is possible for passive loads.
These include applications in which the load cannot produce a regenerative torque on startup and the motor comes to a standstill when pulses are inhibited.

- **Motor identification:**

In many cases, "Motor identification at standstill" is the correct default setting for SINAMICS G150.

"Motor identification at standstill and with motor running" is the recommended setting for speed control with encoder; this measurement is normally performed on non-coupled machines.

| |
|---|
|  DANGER |
|---|

| |
|---|
| When the rotating measurement is selected, the drive triggers movements in the motor that can reach the maximum motor speed. The EMERGENCY OFF functions must be fully operational during commissioning. To protect the machines and personnel, the relevant safety regulations must be observed. |
|---|

⇒ Click **Continue** >

Selecting the PROFIdrive telegram type




Figure 5-27 Selecting the PROFIdrive telegram type

⇒ Under **PROFIdrive telegram type**: select the PROFIdrive telegram type.

Message frame types

- 1: Standard telegram 1
- 2: Standard telegram 2
- 3: Standard telegram 3
- 4: Standard telegram 4
- 20: SIEMENS telegram 20 (VIK-NAMUR)
- 220: SIEMENS telegram 220 (metal industry)
- 352: SIEMENS telegram 352 (PCS7)
- 999: Free telegram configuration with BICO

⇒ Click **Continue >**

5.3 Procedure for commissioning via STARTER

Entering important parameters



Figure 5-28 Important parameters

⇒ Enter the required parameter values.

Note

STARTER provides tool tips if you position your cursor on the required field **without clicking in the field**.

⇒ Click **Continue >**

Summary of the drive unit data




Figure 5-29 Summary of the drive unit data

⇒ You can use the **Copy to clipboard** function to copy the summary of the drive unit data displayed on the screen to a word processing program for further use.

⇒ Click **Finish**.

⇒ Save your project to the hard disk by choosing **Project > Save**.

5.3 Procedure for commissioning via STARTER

5.3.3 Additional settings required for units that are connected in parallel

After commissioning by means of STARTER, additional settings must be made for units that are connected in parallel:

- For 380 V – 480 V 3 AC:
6SL3710-2GE41-1AAx, 6SL3710-2GE41-4AAx, 6SL3710-2GE41-6AAx
- For 500 V – 600 V 3 AC:
6SL3710-2GF38-6AAx, 6SL3710-2GF41-1AAx, 6SL3710-2GF41-4AAx
- For 660 V – 690 V 3 AC:
6SL3710-2GH41-1AAx, 6SL3710-2GH41-4AAx, 6SL3710-2GH41-5AAx

Settings to monitor the checkback signal from the main contactor or circuit breaker for 12-pulse infeed

The checkback contacts of the main contactors and the circuit breakers are connected in series in the factory and wired to digital input 5 of the Control Unit.

After the drive unit has been commissioned, the checkback signal monitoring function must be activated. This is realized using parameter $p0860\{\text{VECTOR}\} = 722.5\{\text{CU}\}$.

DANGER

If the monitoring function for the main contactor or circuit breaker checkback signal is not activated, then the drive could be powered up even if the main contactor or circuit breaker on an individual system fails. This could overload and damage the input rectifiers on the individual system.

NOTICE

When resetting (restoring) the parameterization to the factory setting, this setting must be again made after the drive unit has been recommissioned.

Settings for motor connection to a motor with one-winding system

During commissioning, a motor with several winding systems is automatically defined.

The setting for a one-winding system is made after commissioning has been completed by setting parameter $p7003$ to 0.

NOTICE

If the "motor with a one-winding system" is not set using $p7003 = 0$, then the drive can be powered down (tripped) during the motor identification routine with an "overcurrent" fault message. The system will not be properly tuned.

NOTICE



When resetting (restoring) the parameterization to the factory setting, this setting must be again made after the drive unit has been recommissioned.

5.3.4 Starting the drive project

You have created a project and saved it to your hard disk. You now have to transfer your project configuration data to the drive unit.

Transferring the STARTER project to the drive unit


To transfer the STARTER project you created offline to the drive unit, carry out the following steps:

| Step | | Selection in toolbar |
|------|---|---|
| 1 | Choose Project > Connect to target system |  |
| 2 | Choose Target system > Load project to target system |  |

NOTICE

The project has now been loaded to the drive unit. The data is currently only stored in the volatile memory of the drive unit and not on the CompactFlash card.

To store the project data on the CompactFlash card so that it is protected in the event of a power failure, carry out the following step.

| Step | | Selection in toolbar |
|------|--|---|
| 3 | Choose Target system > Copy from RAM to ROM |  |

Note

The **Copy from RAM to ROM** icon is only active when the drive unit is selected in the project navigator.

5.3 Procedure for commissioning via STARTER

Results of the previous steps

- You have created a drive unit project offline using STARTER.
- You have saved the project data to the hard disk on your PC.
- You have transferred the project data to the drive unit.
- You have saved your project data to the CompactFlash card so that it is backed up in the event of a power failure.

Note

The STARTER commissioning tool supports complex drive system operations.

If you are confronted with any system conditions in online mode that are beyond your control, you are advised to delete the drive project from the project navigator and carefully create a new project in STARTER using the appropriate configuration data for your application.

5.3.5 Commissioning with STARTER via Ethernet

Description

The Control Unit can be commissioned using PG/PC via the integrated Ethernet Interface. This interface is provided for commissioning purposes only and cannot be used to control the drive in operation.

Preconditions

- STARTER from version 4.1.5 or higher
- Control Unit CU320-2 DP with device version "C"

STARTER via Ethernet (example)




Figure 5-30 STARTER via Ethernet (example)

Procedure for establishing online operation via Ethernet

1. Installing the Ethernet interface in the PG/PC according to the manufacturer's specifications
2. Setting the IP address in Windows XP.
The PG/PC is assigned a free IP address (e.g. 169.254.11.1). The factory setting of the internal Ethernet interface -X127 of the Control Unit is 169.254.11.22.
3. Setting the online interface in STARTER.
4. Assigning the IP address and the name via STARTER (node initialization).
The Ethernet interface must be initialized so that the STARTER can establish communication. Selecting online mode in STARTER.

Setting the IP address in Windows XP

On your desktop, right-click "Network environment" -> Properties -> double-click on the network card and choose -> Properties -> Internet Protocol (TCP/IP) -> Properties -> Enter the IP addresses and the subnet mask.




Figure 5-31 Internet Protocol (TCP/IP) properties

5.3 Procedure for commissioning via STARTER

Assigning the IP address and the name via STARTER, "Accessible nodes" function

Use the STARTER to assign an IP address and a name to the Ethernet interface.

- Connect the PG/PC and the Control Unit using an Ethernet cable.
- Switch on the Control Unit.
- Open STARTER.
- Either create a new project or open an existing project
- A search is performed for available nodes in Ethernet via Project -> Accessible nodes or the "Accessible nodes" button.
- The SINAMICS drive object is detected and displayed as a bus node with IP address 169.254.11.22 and without name.




Figure 5-32 Accessible nodes

- Mark the bus node entry and select the displayed menu item "Edit Ethernet node" with the right mouse button.

- In the following "Edit Ethernet node" screen, enter the device name for the Ethernet interface (e.g. "drive1") and click the "Assign name" button. Enter the IP address (e.g. 169.254.11.10) in the IP configuration and specify the subnet screen (e.g. 255.255.255.0). Then click the "Assign IP configuration" button and close the mask.

Note

ST (Structured Text) conventions must be satisfied for the name assignment of IO devices in Ethernet (SINAMICS components). The names must be unique within Ethernet.

The characters "-" and "." are not permitted in the name of an IO device.




Figure 5-33 Edit Ethernet Node

- Pressing the "Update (F5)" button displays the IP address and name in the entry for the bus node. If not, close the "Accessible nodes" screen and perform another search for accessible nodes.
- If the Ethernet interface is displayed as bus node, mark the entry and press the "Accept" button.
- The SINAMICS drive is displayed as drive object in the project navigator.
- You can now configure the drive unit (see Chapter "Configuring the drive unit").

Note

The IP address and device name are stored on the memory card of the Control Unit (non-volatile)..

5.3 Procedure for commissioning via STARTER

Parameters

Parameters can also be used to modify and/or display the properties of the Ethernet interface.

- p8900 IE name of the station
- p8901 IE IP address of the station
- p8902 IE default gateway of station
- p8903 IE subnet mask of station
- p8904 IE DHCP mode
- p8905 IE interface configuration
- r8910 IE name of station active
- r8911 IE IP address of station active
- r8912 IE default gateway of station active
- r8913 IE subnet mask of station active
- r8914 IE DHCP mode of station active
- r8915 IE MAC address of station

5.3.6 Connection via serial interface

As well as the PROFIBUS connection, there is also the option of exchanging data via a serial interface.

Prerequisites

There must be a serial interface (COM) on the PC from which the connection is to be made.

Settings

1. In STARTER, select the **Serial cable (PPI)** interface from **Project > Set PC/PG interface**. If this is not available from the dropdown list, you first have to add it using **Select**.
2. Make the following settings. Address "0" is important in this case; the transmission speed can be chosen freely.




Figure 5-34 Setting the interface

3. When creating the drive unit in conjunction with a serial interface (serial cable), bus address "3" is set automatically.
4. The connecting cable from Control Unit to the AOP30 must be disconnected on the Control Unit. A null modem cable must be used there to connect the PC (COM interface) to the Control Unit. This interface must not be switched.

5.4 The AOP30 operator panel

5.4 The AOP30 operator panel

Description

An operator panel is located in the cabinet door of the cabinet unit for operating, monitoring, and commissioning tasks. It has the following features:

- Graphical, back-lit LCD for plain-text display and a "bar display" of process variables
- LEDs for indicating the operating modes
- Help function describing causes of and remedies for faults and alarms
- Keypad for controlling drives during operation
- LOCAL/REMOTE switchover for selecting the control terminal (master control assigned to operator panel or Customer Terminal Block / PROFIBUS)
- Numeric keypad for entering setpoint or parameter values
- Function keys for prompted navigation through the menus
- Two-stage security concept to protect against accidental or unauthorized changes to settings
- Degree of protection IP 54 (when installed)




Figure 5-35 Components of the cabinet unit operator panel (AOP30)

5.5 First commissioning with the AOP30

5.5.1 Initial ramp-up

Start screen

When the system is switched on for the first time, the Control Unit is initialized automatically. The following screen is displayed:




Figure 5-36 Initial screen

When the system boots up, the parameter descriptions are loaded into the operating field from the CompactFlash card.





Figure 5-37 Load the parameter descriptions while booting up the system

Selecting the language

When the system is first booted up, a screen for selecting the language appears.



You can select the language in the dialog screen.

To change the language, choose <F2> or <F3>.

To select the language, choose <F5>.

5.5 First commissioning with the AOP30

Once the language has been selected, the booting up process continues.

Once the system has successfully ramped up, the drive has to be commissioned when the system is switched on for the first time after it has been delivered. The converter can then be switched on.

When the system is then ramped up again, it can be operated immediately.

Navigation within the interactive screens

Within an interactive screen, the selection boxes can usually be selected using the <F2> and/or <F3> keys. Selection fields are generally texts surrounded by a frame. When they are selected, they are highlighted with a white text on a black background.

The present value of a highlighted selection box can usually be changed by pressing <F5> "OK" and/or "Change". Another entry box then appears and the value you want is entered directly using the numerical keypad or can be selected from a list.

You can change from one interactive screen to the next or previous screen by selecting the "Next" or "Previous" selection boxes and then confirming by pressing <F5> "OK".

If a screen contains particularly important parameters, the selection field "Continue" only appears at the bottom of the screen. This is because every single parameter in this interactive screen has to be checked and/or corrected thoroughly before the next interactive screen can be accessed.

5.5.2 Basic Commissioning

Entering the motor data

During initial commissioning, you have to enter motor data using the operator panel. Use the data shown on the motor type plate.




Figure 5-38 Example of a motor type plate

Table 5- 1 Motor data


| | Parameter no. | Values | Unit |
|--|---------------|--------|---------------------------------------|
| System of units for line frequency and entering motor data | p0100 | 0 1 | IEC [50 Hz / kW] NEMA [60 Hz / hp] |
| Motor: | | | |
| Rated voltage | p0304 | | [V] |
| Rated current | p0305 | | [A] |
| Rated power | p0307 | | [kW] / [hp] |
| Rated power factor cos φ (at p0100 = 0 only) | p0308 | | |
| Rated efficiency η (at p0100 = 1 only) | p0309 | | [%] |
| Rated frequency | p0310 | | [Hz] |
| Rated speed | p0311 | | [min-1] / [rpm] |

5.5 First commissioning with the AOP30

Basic commissioning: Selecting the motor type and entering the motor data

For the following cabinet units, possible additional settings must be made before the following sequence (see "Additional settings for cabinet units with high power rating"):

- For 380 V – 480 V 3 AC:
6SL3710-2GE41-1AAx, 6SL3710-2GE41-4AAx, 6SL3710-2GE41-6AAx
- For 500 V – 600 V 3 AC:
6SL3710-2GF38-6AAx, 6SL3710-2GF41-1AAx, 6SL3710-2GF41-4AAx
- For 660 V – 690 V 3 AC:
6SL3710-2GH41-1AAx, 6SL3710-2GH41-4AAx, 6SL3710-2GH41-5AAx



You can select the motor standard and type in the dialog screen.

The following is defined for the motor standard:

- 0: Line frequency 50 Hz, motor data in kW
- 1: line frequency 60 Hz, motor data in hp

The following selection options are available for the motor type:

- 1: Induction motor
 - 2: Permanent-magnet synchronous motor
- Other values are not permitted.

To navigate through the selection fields, choose <F2> or <F3>.

To activate a selection, choose <F5>.

Entering motor data specified on the type plate

To navigate through the selection fields, choose <F2> or <F3>.



To activate a selection, choose <F5>.

To change a parameter value, navigate to the required selection field and activate with <F5>.

The system displays another window in which you can:

- Enter the value directly, or
- select the value from a list.

When you have finished entering the motor data, choose "Continue" underneath the final parameter value and activate with <F5>.





Note

The steps described below also apply to commissioning an induction motor.

When commissioning a permanent-magnet synchronous motor (p0300 = 2), there are a few special conditions that apply, which are detailed in a separate chapter (see "Setpoint channel and closed-loop control/Permanent-magnet synchronous motors").

Basic commissioning: entering the encoder data (if available)



When the SMC30 is connected for encoder evaluation (with option K50), it is recognized by the AOP30 and a screen is displayed in which you can enter the encoder data.

To navigate through the selection fields, choose <F2> or <F3>.

To activate a selection, choose <F5>.

Predefined encoders can be easily set by selecting parameter p0400 (encoder type selection):

- 3001: 1024 HTL A/B R at X521/X531
- 3002: 1024 TTL A/B R at X521/X531
- 3003: 2048 HTL A/B R at X521/X531
- 3005: 1024 HTL A/B at X521/X531
- 3006: 1024 TTL A/B at X521/X531
- 3007: 2048 HTL A/B at X521/X531
- 3008: 2048 TTL A/B at X521/X531
- 3009: 1024 HTL A/B unipolar at X521/X531
- 3011: 2048 HTL A/B unipolar at X521/X531
- 3020: 2048 TTL A/B R with sense to X520

5.5 First commissioning with the AOP30

Note

The delivery condition is a bipolar HTL encoder with 1024 pulses per revolution and a 24 V power supply.

The section ("Electrical Installation") contains two connection examples for HTL and TTL encoders.

Note

If the connected encoder does not match any of the encoders predefined in p0400, follow the simple procedure below for entering the encoder data:

- Via p0400, select an encoder type whose data is similar to that of the connected encoder.
- Select "User-defined encoder" (p0400 = 9999). Previously set values are stored here.
- Adjust the bit fields of p0404, p0405, and p0408 to the data for the connected encoder.

Table 5- 2 Meaning of the bit setting for p0404

| Bit | Meaning | Value 0 | Value 1 |
|-----|--------------|---------|---------|
| 20 | Voltage 5 V | No | Yes |
| 21 | Voltage 24 V | No | Yes |

Table 5- 3 Meaning of the bit settings for p0405

| Bit | Meaning | Value 0 | Value 1 |
|-----|---------------------|---------------|-------------------|
| 0 | Signal | Unipolar | Bipolar |
| 1 | Level | HTL | TTL |
| 2 | Track monitoring | None | A/B>< -A/B |
| 3 | Zero pulse | 24 V unipolar | Same as A/B track |
| 4 | Switching threshold | Low | High |
| 5 | Pulse/direction | No | Yes |

CAUTION

Once the encoder has been commissioned, the supply voltage (5/24 V) set for the encoder is activated on the SMC30 module. If a 5 V encoder is connected and the supply voltage has not been set correctly via p0404 (bit 20 = "Yes", bit 21 = "No"), the encoder may be damaged.

Basic commissioning: Entering the basic parameters

{2:VECTOR} Basic commissioning

Back Contin

p0230 Drive filter type 0:no filter

p0700cMacro BI 5:PROFIdrive

p1000cMacro CI n_set 1:PROFIdrive

Help ▲ ▼ OK

F1 F2 F3 F4 F5

{2:VECTOR} Basic commissioning d:0

p1070cmain setpoint {02}02050{001}

p1080dminimum speed 0.000 min⁻¹

p1082dmaximum speed 1500.000 min⁻¹

p1120dRFG ramp-up time 20.000 s

Help ▲ ▼ OK

F1 F2 F3 F4 F5

{2:VECTOR} Basic commissioning d:0

p1120dRFG ramp-up time 20.000 s

p1121dRFG ramp-down time 30.000 s

p1135dRFG OFF3 t_down 10.000 s

Cancel comm Contin

Help ▲ ▼ OK

F1 F2 F3 F4 F5

Final confirmation

Back

Permanent parameter transfer
execute with "continue" and OK.

Cancel comm Contin

Help ▼ OK

F1 F2 F3 F4 F5

Entering the basic commissioning parameters:

If a sine-wave filter (option L15) is connected, it must be activated in p0230 (p0230 = 3) otherwise it could be destroyed.

p0700: Preset command source

5: PROFIdrive

6: TM31 terminals

7: Namur

10: PROFIdrive Namur

p1000: Preset setpoint source

1: PROFIdrive

2: TM31 terminals

3: Motorized potentiometer

4: Fixed setpoint

Once a setpoint source has been selected (p1000), the main setpoint p1070 is defaulted accordingly.

To navigate through the selection fields, choose <F2> or <F3>.

To activate a selection, choose <F5>.

To change a parameter value, navigate to the required selection field and activate with <F5>.

Another window appears in which you can - enter the required value directly, or - select the value from a list.

Final confirmation

Confirm the basic parameters to save them.

Once you have selected "Continue" and activated your entries with <F5>, the basic parameters you entered are permanently saved and the calculations required for closed-loop control are carried out.

5.5 First commissioning with the AOP30

NOTICE

If a filter is present on the motor side, it must be entered in p0230 (option L07 – dV/dt-filter compact plus Voltage Peak Limiter: p0230 = 2, option L08 – motor reactor: p0230 = 1, option L10 – dV/dt filter plus Voltage Peak Limiter: p0230 = 2, option L15 – sine-wave filter: p0230 = 3). Motor control will not otherwise function properly.
When p0230 = 4 "Sine-wave filter, third-party", a separate sine-wave filter can be entered. An input screen then appears in which the specific filter can be entered.

Note

The choice "no selection" is also available as default setting for the command and setpoint sources; if selected, no default settings are applied for the command and setpoint sources.

Basic commissioning: Motor identification

{2:VECTOR} motor identification
Select the type of identification:
Stationary and rotating
Only stationary
No identification
Help ▼ OK

F1 F2 F3 F4 F5

{2:VECTOR} motor identification
NOTE
Start the drive
with LOCAL and ON key
Help Cancel

F1 F2 F3 F4 F5

Selecting motor identification

To navigate through the selection fields, choose <F2> or <F3>.

To activate a selection, choose <F5>.

Stationary measurement increases the control performance, as this minimizes deviations in the electrical characteristic values due to variations in material properties and manufacturing tolerances.

Rotary measurement determines the data required (e.g., moment of inertia) for setting the speed controller. It also measures the magnetization characteristic and rated magnetization current of the motor.

To activate this function, press the LOCAL key (wait until the LED in the LOCAL key lights up) and then ON.

If motor identification is not carried out, the motor control uses the motor characteristic values calculated from the nameplate data rather than the measured values.

 **DANGER**

When the rotating measurement is selected, the drive triggers movements in the motor that can reach the maximum motor speed. The EMERGENCY OFF functions must be fully operational during commissioning. To protect the machines and personnel, the relevant safety regulations must be observed.

Note

If a fault is present when selecting the stationary or rotary measurement, motor identification cannot be carried out.
To rectify the fault, you must choose "No identification" to close the screen, then eliminate the fault.
After this, motor identification can be selected again via <MENU> - <Commissioning/service> - <Drive commissioning> - <Motor identification>.

5.5.3 Additional settings required for units that are connected in parallel

Additional settings must be made for units that are connected in parallel before selecting the motor and entering the motor data via the operator panel:

- For 380 V – 480 V 3 AC:
6SL3710-2GE41-1AAx, 6SL3710-2GE41-4AAx, 6SL3710-2GE41-6AAx
- For 500 V – 600 V 3 AC:
6SL3710-2GF38-6AAx, 6SL3710-2GF41-1AAx, 6SL3710-2GF41-4AAx
- For 660 V – 690 V 3 AC:
6SL3710-2GH41-1AAx, 6SL3710-2GH41-4AAx, 6SL3710-2GH41-5AAx

5.5 First commissioning with the AOP30

Settings to monitor the checkback signal from the main contactor or circuit breaker for 12-pulse infeed


The checkback contacts of the main contactors and the circuit breakers are connected in series in the factory and wired to digital input 5 of the Control Unit.

After the drive unit has been commissioned, the checkback signal monitoring function must be activated. This is realized using parameter p0860{Vector} = 722.5{Control_Unit}.

p0860 = r0722.5


Select parameter p0860 "Line contactor checkback" and connect to digital input DI5.

<MENU> <Parameterization> <Single DO>
<2:VECTOR> <OK> select "p0860",
<change> select "{1:CU_G}" <OK>, select
"r0722" <OK>, select ".05 DI 5 (X132.2)"
<OK>



A confirmation window is displayed in which a summary of the line contactor feedback is displayed.

To confirm the set connection, choose <F5>.



⚠ DANGER

If the monitoring function for the main contactor or circuit breaker checkback signal is not activated, then the drive could be powered up even if the main contactor or circuit breaker on an individual system fails. This could overload and damage the input rectifiers on the individual system.

NOTICE

When resetting (restoring) the parameterization to the factory setting, this setting must be again made after the drive unit has been recommissioned.

Settings for motor connection to a motor with one-winding system

Before the commissioning, a motor with several winding systems is automatically defined.

The setting for a one-winding system is made during commissioning by setting parameter p7003 to 0.

Settings via the AOP30

During commissioning, you are asked whether a motor is connected to a one-winding system or multiple winding system. This setting must be made according to the motor connected.

NOTICE

If the "motor with a one-winding system" is not set using $p7003 = 0$, then the drive can be powered down (tripped) during the motor identification routine with an "overcurrent" fault message. The system will not be properly tuned.

NOTICE

When resetting (restoring) the parameterization to the factory setting, this setting must be again made before the drive unit is re-commissioned.

5.6 Status after commissioning

LOCAL mode (control via operator panel)

- You switch to LOCAL mode by pressing the "LOCAL/REMOTE" key.
- Control (ON/OFF) is carried out via the "ON" and "OFF" keys.
- You can specify the setpoint using the "increase" and "decrease" keys or by entering the appropriate numbers using the numeric keypad.

Analog outputs (with option G60 "Customer terminal module TM31")

- The actual speed (r0063) is output as a current output in the range 0 to 20 mA at analog output 0 (X522:2 and 3).
A current of 20 mA is equal to the maximum speed in p1082.
- The actual current value (r0068) is output as a current output in the range 0 to 20 mA at analog output 1 (X522:5 and 6).
A current of 20 mA corresponds to the current limit (p0640), which is set to 1.5 times the rated motor current (p0305).

Digital outputs (with option G60 "Customer terminal module TM31")

- The "enable pulses" signal is output at digital output 0 (X542:2 and 3).
- The "no fault active" signal is output at digital output 1 (X542:5 and 6) (protection against wire break).
- The "ready for power up" signal is output at digital output 8 (X541:2).

5.7 Parameter reset to factory settings


5.7 Parameter reset to factory settings

The factory settings represent the defined original status of the device on delivery.

Resetting the parameters to the factory settings means that all the parameter settings made since the system was delivered are reset.



Resetting Parameters via AOP30

Table 5- 4 Procedure for resetting parameters to the factory settings with AOP30





Parameter reset via STARTER

With STARTER, the parameters are reset in online mode. The required steps are described below:

| Step | Selection in toolbar |
|--|---|
| Choose Project > Connect to target system |  |
| Click the drive unit whose parameters you want to reset to the factory settings and click Restore factory settings icon in the toolbar. |  |

5.7 Parameter reset to factory settings

| Step | Selection in toolbar |
|--|---|
| <p>To confirm, click OK.</p>  | |
| <p>Choose Target system > Copy from RAM to ROM</p> |  |

Note

The **Copy from RAM to ROM** icon is only active when the drive unit is selected in the project navigator.

When the parameters have been reset to the factory settings, initial commissioning needs to be carried out.

5.7 Parameter reset to factory settings


6

Operation

6.1 Chapter content

This chapter provides information on the following:

- Basic information about the drive system
- Selecting command sources via:
 - PROFIdrive
 - Terminal strip
 - NAMUR terminal block
- Specifying setpoints via:
 - PROFIdrive
 - Analog inputs
 - Motorized potentiometer
 - Fixed setpoints
- Control via the AOP30 operator panel



6.2 General information about command and setpoint sources

6.2 General information about command and setpoint sources

Description

Four default settings are available for selecting the command sources and four for selecting the setpoint sources for the SINAMICS G150 cabinet unit. The choice "no selection" is also available; if selected, no default settings are applied for the command and setpoint sources.

Command sources

- PROFIdrive
- TM31 terminals
- NAMUR
- PROFIdrive NAMUR

Setpoint sources

- PROFIdrive
- Analog inputs
- Motorized potentiometer
- Fixed setpoints

The various assignments are explained in the following sections.

Note

Make sure that the default settings you choose during commissioning are compatible with the cabinet configuration (see "Commissioning")

Emergency STOP signals (L57, L59, and L60) and motor protection signals (L83 and L84) are always active (regardless of the command source).

Function diagrams

To supplement these operating instructions, the customer DVD contains simplified function diagrams describing the operating principle.

The diagrams are arranged in accordance with the chapters in the Operating Instructions. The page numbers (6xx) describe the functionality in the following chapter.

At certain points in this chapter, reference is made to function diagrams with a 4-digit number. These are stored on the customer DVD in the "SINAMICS G130/G150 List Manual", which provides experienced users with detailed descriptions of all the functions.

6.3 Basic information about the drive system

6.3.1 Parameters

Overview

The drive is adapted to the relevant drive task by means of parameters. Each parameter is identified by a unique parameter number and by specific attributes (e.g. read, write, BICO attribute, group attribute, and so on).

The parameters can be accessed via the following means:

- PC with the "STARTER" commissioning tool via PROFIBUS
- The user-friendly AOP30 Operator Panel

Parameter types

The following adjustable and display parameters are available:

- Adjustable parameters (write/read)
These parameters have a direct impact on the behavior of a function.
Example: Ramp-up and ramp-down time of a ramp-function generator
- Display parameters (read only)
These parameters are used to display internal variables.
Example: Current motor current




Figure 6-1 Parameter types

All these drive parameters can be read and changed via PROFIBUS using the mechanisms defined in the PROFIdrive profile.

6.3 Basic information about the drive system

Parameter categories

The parameters for the individual drive objects (see "Drive objects") are categorized according to data sets as follows (see "Operation/data sets"):

- Data-set-independent parameters
These parameters exist only once per drive object.
- Data-set-dependent parameters
These parameters can exist several times for each drive object and can be addressed via the parameter index for reading and writing. A distinction is made between various types of data set:
 - CDS: Command data set
By parameterizing several command data sets and switching between them, the drive can be operated with different pre-configured signal sources.
 - DDS: Drive data set
The drive data set contains the parameters for switching between different drive control configurations.
 - PDS: Powerstack Data Set
The number of powerstack data sets corresponds to the number of power units combined for units that are connected in parallel.

The CDS and DDS can be switched over during normal operation. Further types of data set also exist, however these can only be activated indirectly by means of a DDS changeover.

- EDS: Encoder data set
- MDS: Motor data set

6.3 Basic information about the drive system




Figure 6-2 Parameter categories

6.3 Basic information about the drive system

6.3.2 Drive objects

A drive object is a self-contained software function with its own parameters and, if necessary, its own faults and alarms. Drive objects can be provided as standard (e.g. I/O evaluation), or you can add single (e.g. option board) or multiple objects (e.g. drive control).




Figure 6-3 Drive objects

Standard drive objects

- Drive control
Drive control handles closed-loop control of the motor. At least 1 Power Module and at least 1 motor and up to 3 encoders are assigned to the drive control.
- Control Unit, inputs/outputs
The inputs/outputs on the Control Unit are evaluated within a drive object.

Optionally installed drive objects

- Option board evaluation
A further drive object handles evaluation of an installed option board. The specific method of operation depends on the type of option board installed.
- Terminal Module evaluation
A separate drive object handles evaluation of the respective optional Terminal Modules.

Properties of a drive object

- Separate parameter space
- Separate window in STARTER
- Separate fault/alarm system
- Separate PROFIdrive telegram for process data

Configuring drive objects

When you commission the system for the first time using the STARTER tool, you will use configuration parameters to set up the software-based "drive objects" which are processed on the Control Unit. Various drive objects can be created within a Control Unit.

The drive objects are configurable function blocks and are used to execute specific drive functions.

If you need to configure additional drive objects or delete existing ones after initial commissioning, the drive system must be switched to configuration mode.

The parameters of a drive object cannot be accessed until the drive object has been configured and you have switched from configuration mode to parameterization mode.

Note

Each installed drive object is allocated a number between 0 and 63 during initial commissioning for unique identification.

Parameters

- p0101 Drive object numbers
- r0102 Number of drive objects
- p0107 Drive object type
- p0108 Drive object configuration

6.3 Basic information about the drive system

6.3.3 Data Sets

Description

For many applications, it is beneficial if more than one parameter can be changed simultaneously by means of **one** external signal during operation/when the system is ready for operation.

This can be carried out using indexed parameters, whereby the parameters are grouped together in a data set according to their functionality and indexed. Indexing allows several different settings, which can be activated by switching the data set, to be defined in each parameter.

Note

The command and drive data sets can be copied in STARTER (Drive -> Configuration -> "Command data sets" or "Drive data sets" tab).
The displayed command and drive data sets can be selected in the associated STARTER screen forms..

CDS: Command data set

The BICO parameters (binector and connector inputs) are grouped together in a command data set. These parameters are used to interconnect the signal sources of a drive (see "Operation/BICO technology: Interconnecting signals").

By parameterizing several command data sets and switching between them, the drive can be operated with different pre-configured signal sources.

A command data set contains the following (examples):

- Binector inputs for control commands (digital signals)
 - ON/OFF, enable signals (p0844, etc.)
 - Jog (p1055, etc.)
- Connector inputs for setpoints (analog signals)
 - Voltage setpoint for V/f control (p1330)
 - Torque limits and scaling factors (p1522, p1523, p1528, p1529)

In the delivery condition, two command data sets are available; this number can be increased to a maximum of four using p0170 (number of command data sets (CDS)).

The following parameters are available for selecting command data sets and for displaying the currently selected command data set:

Table 6- 1 Command data set: selection and display

| CDS | Select bit 1 p0811 | Select bit 0 p0810 | Display | |
|-----|-----------------------|-----------------------|------------------|----------------|
| | | | selected (r0836) | active (r0050) |
| 0 | 0 | 0 | 0 | 0 |
| 1 | 0 | 1 | 1 | 1 |
| 2 | 1 | 0 | 2 | 2 |
| 3 | 1 | 1 | 3 | 3 |

If a command data set, which does not exist, is selected, the current data set remains active.




Figure 6-4 Example: Switching between command data set 0 and 1

DDS: Drive data set

A drive data set contains various adjustable parameters that are relevant with respect to open and closed-loop drive control:

- Numbers of the assigned motor and encoder data sets:
 - p0186: Assigned motor data set (MDS)
 - p0187 to p0189: up to 3 assigned encoder data sets (EDS)
- Various control parameters, e.g.:
 - Fixed speed setpoints (p1001 to p1015)
 - Speed limits min./max. (p1080, p1082)
 - Characteristic data of ramp-function generator (p1120 ff)
 - Characteristic data of controller (p1240 ff)
 - ...

The parameters that are grouped together in the drive data set are identified in the SINAMICS parameter list by "Data set DDS" and are assigned an index [0..n].

6.3 Basic information about the drive system

It is possible to parameterize several drive data sets. You can switch easily between different drive configurations (control type, motor, encoder) by selecting the corresponding drive data set.

One drive object can manage up to 32 drive data sets. The number of drive data sets is configured with p0180.

Binector inputs p0820 to p0824 are used to select a drive data set. They represent the number of the drive data set (0 to 31) in binary format (where p0824 is the most significant bit).

- p0820 BI: Drive data set selection DDS, bit 0
- p0821 BI: Drive data set selection DDS, bit 1
- p0822 BI: Drive data set selection DDS, bit 2
- p0823 BI: Drive data set selection DDS, bit 3
- p0824 BI: Drive data set selection DDS, bit 4

Supplementary conditions and recommendations

- Recommendation for the number of DDS in a drive
The number of DDS in a drive should correspond with the number of changeover options; in other words
 $p0180 \text{ (DDS)} \geq p0130 \text{ (MDS)}$.
- Max. number of DDS for one drive object = 32 DDS

EDS: Encoder data set

An encoder data set contains various adjustable parameters describing the connected encoder for the purpose of configuring the drive.

- Adjustable parameters, e.g.:
 - Encoder interface component number (p0141)
 - Encoder component number (p0142)
 - Encoder type selection (p0400)

The parameters that are grouped together in the encoder data set are identified in the SINAMICS parameter list by "Data set EDS" and are assigned an index [0..n].

A separate encoder data set is required for each encoder controlled by the Control Unit. Up to 3 encoder data sets are assigned to a drive data set via parameters p0187, p0188, and p0189.

An encoder data set can only be changed using a DDS changeover.

Each encoder may only be assigned to one drive and within a drive must - in each drive data set - either always be encoder 1, always encoder 2 or always encoder 3.

One application for the EDS changeover would be a power component with which several motors are operated in turn. A contactor circuit is used to changeover between these motors. Each of the motors can be equipped with an encoder or be operated without an encoder. Each encoder must be connected to its own SMx.

If encoder 1 (p0187) is changed over via DDS, then an MDS must also be changed over.

One drive object can manage up to 16 encoder data sets. The number of encoder data sets configured is specified in p0140.

When a drive data set is selected, the assigned encoder data sets are selected automatically.

MDS: Motor data set

A motor data set contains various adjustable parameters describing the connected motor for the purpose of configuring the drive. It also contains certain display parameters with calculated data.

- Adjustable parameters, e.g.:
 - Motor component number (p0131)
 - Motor type selection (p0300)
 - Rated motor data (p0304 ff)
 - ...
- Display parameters, e.g.:
 - Calculated rated data (p0330 ff)
 - ...

The parameters that are grouped together in the motor data set are identified in the SINAMICS parameter list by "Data set MDS" and are assigned an index [0..n].

A separate motor data set is required for each motor that is controlled by the Control Unit via a Motor Module. The motor data set is assigned to a drive data set via parameter p0186.

A motor data set can only be changed using a DDS changeover.

The motor data set changeover is, for example, used for:

- Changing over between different motors
- Changing over between different windings in a motor (e.g. star-delta changeover)
- Motor data adaptation

If several motors are operated alternately on one Motor Module, a corresponding number of drive data sets must be created. See "Functions / Drive functions" for additional information and instructions on changing over motors.

One drive object can manage up to 16 motor data sets. The number of motor data sets in p0130 may not exceed the number of drive data sets in p0180.

6.3 Basic information about the drive system

Example of data set assignment

Table 6- 2 Example, data set assignment

| DDS | Motor (p0186) | Encoder 1 (p0187) | Encoder 2 (p0188) | Encoder 3 (p0189) |
|-------|---------------|-------------------|-------------------|-------------------|
| DDS 0 | MDS 0 | EDS 0 | EDS 1 | EDS 2 |
| DDS 1 | MDS 0 | EDS 0 | EDS 3 | -- |
| DDS 2 | MDS 0 | EDS 0 | EDS 4 | EDS 5 |
| DDS 3 | MDS 1 | EDS 0 | -- | -- |

Copying the command data set (CDS)

Set parameter p0809 as follows:

1. p0809[0] = number of the command data set to be copied (source)
2. p0809[1] = number of the command data to which the data is to be copied (target)
3. p0809[2] = 1

Start copying.

Copying is finished when p0809[2] = 0.

Copying the drive data set (DDS)

Set parameter p0819 as follows:

1. p0819[0] = Number of the drive data set to be copied (source)
2. p0819[1] = Number of the drive data set to which the data is to be copied (target)
3. p0819[2] = 1

Start copying.

Copying is finished when p0819[2] = 0.

Copy motor data set (MDS)

Set parameter p0139 as follows:

1. p0139[0] = Number of the motor data set that is to be copied (source)
2. p0139[1] = Number of the motor data set which should be copied into (target)
3. p0139[2] = 1

Start copying.

Copying has been completed, if p0139[2] = 0.

Function diagram

| | |
|---------|-------------------------|
| FP 8560 | Command data sets (CDS) |
| FP 8565 | Drive data set (DDS) |
| FP 8570 | Encoder data set (EDS) |
| FP 8575 | Motor data sets (MDS) |

Parameters

- p0120 Power Module data sets (PDS) number
- p0130 Motor data sets (MDS) number
- p0139[0...2] Copy motor data set (MDS)
- p0140 Encoder data sets (EDS) number
- p0170 Command data set (CDS) number
- p0180 Drive data set (DDS) number
- p0186 Assigned motor data set (MDS)
- p0187[0...n] Encoder 1 encoder data set number
- p0188[0...n] Encoder 2 encoder data set number
- p0189[0...n] Encoder 3 encoder data set number
- p0809 Copy command data set CDS
- p0810 BI: Command data set selection CDS bit 0
- p0811 BI: Command data set selection CDS bit 1
- p0819[0...2] Copy drive data set DDS
- p0820 BI: Drive data set selection, bit 0
- p0821 BI: Drive data set selection, bit 1
- p0822 BI: Drive data set selection, bit 2
- p0823 BI: Drive data set selection, bit 3
- p0824 BI: Drive data set selection, bit 4

6.3.4 BICO technology: interconnecting signals

Description

Every drive contains a large number of interconnectable input and output variables and internal control variables.

BICO technology (Binector Connector Technology) allows the drive to be adapted to a wide variety of conditions.

6.3 Basic information about the drive system

Digital signals, which can be connected freely by means of BICO parameters, are identified by the prefix BI, BO, CI or CO in their parameter name. These parameters are identified accordingly in the parameter list or in the function diagrams.

Note



The STARTER parameterization and commissioning tool is recommended when using BICO technology.

Binectors, BI: binector input, BO: Binector output

A binector is a digital (binary) signal without a unit which can assume the value 0 or 1.

Binectors are subdivided into binector inputs (signal sink) and binector outputs (signal source).

Table 6- 3 Binectors



| Abbreviation and symbol | Name | Description |
|--|---|--|
| BI  | Binector input Binector Input (signal sink) | Can be interconnected to a binector output as source. The number of the binector output must be entered as a parameter value. |
| BO  | Binector output Binector output (signal source) | Can be used as a source for a binector input. |

Connectors, CI: connector input, CO: Connector output

A connector is a digital signal e.g. in 32-bit format. It can be used to emulate words (16 bits), double words (32 bits) or analog signals. Connectors are subdivided into connector inputs (signal sink) and connector outputs (signal source).

The options for interconnecting connectors are restricted to ensure that performance is not adversely affected.

Table 6- 4 Connectors

| Abbreviation and symbol | Name | Description |
|--|---|--|
| CI  | Connector input Connector input (signal sink) | Can be interconnected to a connector output as source. The number of the connector output must be entered as a parameter value. |
| CO  | Connector output Connector output (signal source) | Can be used as a source for a connector input. |

Interconnecting signals using BICO technology

To interconnect two signals, a BICO input parameter (signal sink) must be assigned to the desired BICO output parameter (signal source).

The following information is required in order to connect a binector/connector input to a binector/connector output:

- Binectors: Parameter number, bit number, and drive object ID
- Connectors with no index: Parameter number and drive object ID
- Connectors with index: Parameter number, index, and drive object ID




Figure 6-5 Interconnecting signals using BICO technology

Note

A connector input (CI) cannot be interconnected with any connector output (CO, signal source). The same applies to the binector input (BI) and binector output (BO).

"Data type" in the parameter list provides information about the data type of the parameter and the data type of the BICO parameter for each CI and BI parameter.

For CO and BO parameters, only the data type of the BICO parameter is given.

Notation:

- Data type BICO input: Data type parameter / Data type BICO parameter
Example: Unsigned32 / Integer16
- Data type BICO output: Data type BICO parameter
Example: FloatingPoint32

The possible interconnections between BICO input (signal sink) and BICO output (signal source) are described in the List Manual in the table "Possible combinations for BICO interconnections" in the section "Explanations on the parameter list".

The BICO parameter interconnection can be implemented in different data sets (CDS, DDS, MDS, etc.). The different interconnections in the data sets are activated by switching the data sets. Interconnections across drive objects are also possible.

6.3 Basic information about the drive system

Internal encoding of the binector/connector output parameters

The internal codes are needed, for example, to write BICO input parameters via PROFIdrive.




Figure 6-6 Internal encoding of the binector/connector output parameters

Example 1: interconnecting digital signals

Suppose you want to operate a drive via terminals DI 0 and DI 1 on the Control Unit using jog 1 and jog 2.




Figure 6-7 Interconnection of digital signals (example)

Example 2: connection of OC/OFF3 to several drives

The OFF3 signal is to be connected to two drives via terminal DI 2 on the Control Unit.

Each drive has a binector input 1. OFF3 and 2. OFF3. The two signals are processed via an AND gate to STW1.2 (OFF3).




Figure 6-8 Connection of OFF3 to several drives (example)

BICO interconnections to other drives

The following parameters are available for BICO interconnections to other drives:

- r9490 Number of BICO interconnections to other drives
- r9491[0...15] BI/CI of BICO interconnections to other drives
- r9492[0...15] BO/CO of BICO interconnections to other drives
- p9493[0...15] Reset BICO interconnections to other drives

Binector-connector converters and connector-binector converters

Binector-connector converter

- Several digital signals are converted to a 32-bit integer double word or to a 16-bit integer word.
- p2080[0...15] BI: PROFIdrive PZD send bit-serial

Connector-binector converter

- A 32-bit integer double word or a 16-bit integer word is converted to individual digital signals.
- p2099[0...1] CI PROFIdrive PZD selection receive bit-serial

6.3 Basic information about the drive system

Fixed values for interconnection using BICO technology

The following connector outputs are available for interconnecting any fixed value settings:

- p2900[0...n] CO: Fixed value_%_1
- p2901[0...n] CO: Fixed value_%_2
- p2930[0...n] CO: Fixed Value_M_1

Example:

These parameters can be used to interconnect the scaling factor for the main setpoint or to interconnect an additional torque.

6.4 Command sources

6.4.1 "PROFIdrive" default setting

Prerequisites

The "PROFIdrive" default setting was chosen during commissioning:

- STARTER: "PROFIdrive"
- AOP30: "5: PROFIdrive"

Command sources




Figure 6-9 Command sources - AOP30 ↔ PROFIdrive

Priority

The command source priorities are shown in the diagram "Command sources - AOP30↔PROFIdrive".

Note

The emergency OFF and motor protection signals are always active (regardless of the command source).

All of the supplementary setpoints are deactivated for LOCAL master control.

6.4 Command sources

TM31 terminal assignment with "PROFdrive" default setting (if option G60 is present)

When you choose the "PROFdrive" default setting, use the following terminal assignment for TM31:




Figure 6-10 TM31 terminal assignment with "PROFdrive" default setting

Control word 1

The bit assignment for control word 1 is described in "Description of the control words and setpoints".

Status word 1

The bit assignment for status word 1 is described in "Description of the status words and actual values".

Switching the command source

The command source can be switched using the LOCAL/REMOTE key on the AOP30.

6.4.2 "TM31 terminals" default setting

Prerequisites

The customer terminal module option (G60) is installed in the cabinet unit.
The "TM31 Terminals" default setting was chosen during commissioning:

- STARTER: "TM31 Terminals"
- AOP30: "6: TM31 terminals"

Command sources




Figure 6-11 Command sources - AOP30 ↔ terminal TM31

Priority

The priority of the command sources is shown in the diagram "Command sources - AOP30 ↔ terminal TM31".

Note

The emergency OFF and motor protection signals are always active (regardless of the command source).

All of the supplementary setpoints are deactivated for LOCAL master control.

6.4 Command sources

TM31 terminal assignment with "TM31 Terminals" default setting

When you choose the "TM31 Terminals" default setting, the terminal assignment for TM31 is as follows:




Figure 6-12 TM31 terminal assignment with "TM31 Terminals" default setting

Switching the command source

The command source can be switched using the LOCAL/REMOTE key on the AOP30.

6.4.3 "NAMUR" default setting

Prerequisites

The NAMUR terminal block (option B00) is installed in the cabinet unit.

The "NAMUR" default setting was chosen during commissioning:

- STARTER: "NAMUR"
- AOP30: "7: NAMUR"

Command sources




Figure 6-13 Command sources - AOP30↔NAMUR terminal block

Priority

The priority of the command sources is shown in the diagram "Command sources - AOP30↔NAMUR terminal block".

Note

The EMERGENCY STOP and motor protection signals are always active (regardless of the command source).

For LOCAL master control, all of the supplementary setpoints are deactivated.

6.4 Command sources

Terminal Assignment with the "NAMUR" Default Setting

When you choose the "NAMUR" default setting, the terminal assignment is as follows (as with option B00):




Figure 6-14 Terminal assignment with "NAMUR terminal block" default setting

Switching the command source

The command source can be switched using the LOCAL/REMOTE key on the AOP30.

6.4.4 "PROFIdrive NAMUR" default setting

Prerequisites

The NAMUR terminal block (option B00) is installed in the cabinet unit.
The "PROFIdrive" default setting was chosen during commissioning:

- STARTER: "PROFIdrive Namur"
- AOP30: "10: PROFIdrive Namur"

Command sources




Figure 6-15 Command sources - AOP30↔PROFIdrive NAMUR

Priority

The priority of the command sources is shown in the diagram "Command sources - AOP30↔PROFIdrive NAMUR".

Note

The EMERGENCY STOP and motor protection signals are always active (regardless of the command source).

All of the supplementary setpoints are deactivated for LOCAL master control.

6.4 Command sources

Terminal assignment for the "PROFIdrive NAMUR" default setting

When you choose the "PROFIdrive NAMUR" default setting, the terminal assignment is as follows (as with option B00):




Figure 6-16 Terminal assignment for the "PROFIdrive NAMUR" default setting

Control word 1

The bit assignment for control word 1 is described in "Description of the control words and setpoints".

Status word 1

The bit assignment for status word 1 is described in "Description of the status words and actual values".

Switching the command source

The command source can be switched using the LOCAL/REMOTE key on the AOP30.

6.5 Setpoint sources

6.5.1 Analog inputs

Description

The customer terminal block TM31 features two analog inputs for specifying setpoints for current or voltage signals.

In the factory setting, analog input 0 (terminal X521:1/2) is used as a current input in the range 0 to 20 mA.

Prerequisites

The default setting for analog inputs was chosen during commissioning:

- STARTER: "TM31 Terminals"
- AOP30: "2: TM31 terminals"




Figure 6-17 Signal flow diagram: analog input 0

Function diagram

- | | |
|---------|------------------------------|
| FP 9566 | TM31 – analog input 0 (AI 0) |
| FP 9568 | TM31 – analog input 1 (AI 1) |

Parameters

- r4052 Actual input voltage/current
- p4053 Analog inputs smoothing time constant
- r4055 Current referenced input value
- p4056 Analog inputs type
- p4057 Analog inputs, characteristic value x1

6.5 Setpoint sources


- p4058 Analog inputs, characteristic value y1
- p4059 Analog inputs, characteristic value x2
- p4060 Analog inputs, characteristic value y2
- p4063 Analog inputs offset

Note

In the factory setting and after basic commissioning, an input current of 20 mA is equal to the main setpoint 100% reference speed (p2000), which has been set to the maximum speed (p1082).

Example: Changing Analog Input 0 from Current to Voltage Input –10 to +10 V

Table 6- 5 Example: setting analog input 0



Note


The change to the analog input must then be stored on the CompactFlash card so that it is protected in the event of a power failure.

F3505 – Fault: "Analog input wire break"

This fault is triggered when the analog input type (p4056) is set to 3 (4 ... 20 mA with open-circuit monitoring) and the input current of 2 mA has been undershot.

The fault value can be used to determine the analog input in question.

Table 6- 6 Fault screen



Component number

- 3: Module -A60 (option G60)
- 4: Module -A61 (option G61)
- 0: Analog input 0: -X521:1/2
- 1: Analog input 1: -X521:3/4

6.5.2 Motorized potentiometer

Description

The digital motorized potentiometer enables you to set speeds remotely using switching signals (+/- keys). It is activated via terminals or PROFIBUS. As long as a logical 1 is present at signal input "MOP raise" (setpoint higher), the internal numerator integrates the setpoint. You can set the integration time (time taken for the setpoint to increase) using parameter p1047. In the same way, you can decrease the setpoint using signal input "MOP lower". The deceleration ramp can be set using parameter p1048. Configuration parameter p1030.0 = 1 (default setting = 0) is used to activate that the actual motorized potentiometer is saved in a non-volatile fashion when powering-down the drive unit. When powering-up the drive unit, the starting (initial) value of the motorized potentiometer is set to the last, actual value that was present when the drive unit was powered-down.

Prerequisites

The default setting for the motorized potentiometer was chosen during commissioning:

- STARTER: "Motorized potentiometer"
- AOP30: "3: Motorized potentiometer"

Signal flow diagram




Figure 6-18 Signal flow diagram: Motorized potentiometer

Function diagram

FD 3020 Motorized potentiometer

6.5 Setpoint sources

Parameters

- p1030 Motorized potentiometer, configuration
- p1037 Motorized potentiometer, maximum speed
- p1038 Motorized potentiometer, minimum speed
- p1047 Motorized potentiometer, ramp-up time
- p1048 Motorized potentiometer, ramp-down time
- r1050 Motorized potentiometer, setpoint after the ramp-function generator

6.5.3 Fixed speed setpoints

Description

A total of 15 variable fixed speed setpoints are available. The default setting specified for the setpoint sources during commissioning via STARTER or the operating panel makes 3 fixed speed setpoints available. They can be selected via terminals or PROFIBUS.

Requirement

The default setting for the fixed speed setpoints was chosen during commissioning:

- STARTER: "Fixed setpoint"
- AOP30: "4: Fixed setpoint"

Signal flow diagram




Figure 6-19 Signal flow diagram: Fixed speed setpoints

Function diagram

FP 3010 Fixed speed setpoints

Parameter

- p1001 Fixed speed setpoint 01
- p1002 Fixed speed setpoint 02
- p1003 Fixed speed setpoint 03
- r1024 Fixed speed setpoint effective

Note

Other fixed speed setpoints are available using p1004 to p1015. They can be selected using p1020 to p1023.

6.6 PROFIBUS

6.6 PROFIBUS

6.6.1 PROFIBUS connection

Positions of PROFIBUS port, address switch, and diagnostics LED

The PROFIBUS port, address switch, and diagnostics LED are located on the Control Unit CU320-2 DP.





Figure 6-20 View of the Control Unit with PROFIBUS interface

PROFIBUS connection

The PROFIBUS is connected by means of a 9-pin SUB D socket (X126). The connections are electrically isolated.


Table 6- 7 X126 - PROFIBUS port

| | Pin | Signal name | Meaning | Range |
|---|-----|-------------|--|------------------------|
|  | 1 | SHIELD | Ground connection | |
| | 2 | M24_SERV | Power supply for teleservice, ground | 0 V |
| | 3 | RxD/TxD-P | Receive / transmit data P (B/B') | RS485 |
| | 4 | CNTR-P | Control signal | TTL |
| | 5 | DGND | PROFIBUS data reference potential (C/C') | |
| | 6 | VP | Supply voltage plus | 5 V ± 10% |
| | 7 | P24_SERV | Power supply for teleservice P, + (24 V) | 24 V (20.4 V - 28.8 V) |
| | 8 | RxD/TxD-N | Receive / transmit data N (A/A') | RS485 |
| | 9 | - | not assigned | |


Connectors

The cables must be connected via PROFIBUS connectors as they contain the necessary terminating resistors.

The figure below shows suitable PROFIBUS connectors with/without a PG/PC connector.



PROFIBUS connector
without PG/PC connection
6ES7972-0BA41-0XA0



PROFIBUS connector
with PG/PC connection
6ES7972-0BB41-0XA0

6.6 PROFIBUS

Bus terminating resistor

The bus terminating resistor must be switched on or off depending on its position in the bus, otherwise the data will not be transmitted properly.

The terminating resistors for the first and last nodes in a line must be switched on; the resistors must be switched off at all other connectors.

The cable shield must be connected at both ends over large-surface area contacts.




Figure 6-21 Position of the bus terminating resistors

Cable routing




Figure 6-22 Cable routing

6.6 PROFIBUS

6.6.2 Control via PROFIBUS

More information on PROFIBUS programming

For more information about the PROFIBUS programming, refer to the section "PROFIBUS DP/PROFINET IO communication" in the documentation "SINAMICS S120 Function Manual".

"DP1 (PROFIBUS)" diagnostics LED

The PROFIBUS diagnostics LED is located on the front of the Control Unit. Its states are described in the following table.

Table 6- 8 Description of the LEDs

| Color | State | Description |
|-------|------------------|--|
| ----- | OFF | Cyclic communication has not (yet) taken place. |
| Green | Steady light | PROFIBUS is ready for communication and cyclic communication is taking place. |
| Green | Flashing, 0.5 Hz | Full cyclic communication is not yet taking place. Possible causes: The master is not transmitting setpoints. |
| Red | Steady light | Cyclic communication has been interrupted. |

Setting the PROFIBUS Address

There are two ways to set the PROFIBUS address:



1. Via p0918
 - To set the bus address for a PROFIBUS node using STARTER, first set the rotary code switches to 0_{dec} (00_{hex}) and 127_{dec} (7F_{hex}).
 - Then use parameter p0918 to set the address to a value between 1 and 126.
2. Via the PROFIBUS address switches on the Control Unit
 - The address is set manually to values between 1 and 126 using the rotary coding switches. In this case, p0918 is only used to read the address.

The address switch is behind the blanking plate. The blanking plate is part of the scope of supply.

PROFIBUS address switches

The PROFIBUS address is set as a hexadecimal value via two rotary coding switches. Values between 0_{dec} (00_{hex}) and 127_{dec} (7F_{hex}) can be set as the address. The upper rotary coding switch (H) is used to set the hexadecimal value for 16¹ and the lower rotary coding switch (L) is used to set the hexadecimal value for 16⁰.

Table 6-9 PROFIBUS address switches

| Rotary coding switches | Significance | Examples | | |
|---|----------------------|-------------------|-------------------|--------------------|
| | | 21 _{dec} | 35 _{dec} | 126 _{dec} |
| | | 15 _{hex} | 23 _{hex} | 7E _{hex} |
|  DP H | 16 ¹ = 16 | 1 | 2 | 7 |
|  DP L | 16 ⁰ = 1 | 5 | 3 | E |

The factory setting for the rotary coding switches is 0_{dec} (00_{hex}).

Setting the PROFIBUS ID number

The PROFIBUS Ident Number (PNO-ID) can be set using p2042.

SINAMICS can be operated on PROFIBUS with various identities. This allows a PROFIBUS GSD that is independent of the device to be used (e.g. PROFIdrive VIK-NAMUR with Ident Number 3AA0 hex).

- 0: SINAMICS S/G
- 1: VIK-NAMUR

New settings do not become active until after POWER ON, reset, or download.

Note

The advantages of Totally Integrated Automation (TIA) can only be utilized when selecting "0".

6.6.3 Monitoring: Telegram failure

Description

Following a telegram failure and after a monitoring time has elapsed (t_{An}), bit r2043.0 is set to "1" and alarm A01920 is output. Binector output r2043.0 can be used for an emergency stop, for example.

6.6 PROFIBUS

Once a delay time (p2044) has elapsed, fault F01910 is output and fault reaction OFF3 (quick stop) is triggered. If no OFF response is to be triggered, the fault response can be reparameterized accordingly.

Fault F01910 can be acknowledged immediately. The drive can then be operated even without PROFIBUS.




Figure 6-23 Monitoring: Telegram failure

6.6.4 Telegrams and process data

General information

Selecting a telegram via CU parameter p0922 determines which process data is transferred between the master and slave.

From the perspective of the slave (SINAMICS), the received process data comprises the receive words and the process data to be sent the send words.

The receive and send words comprise the following elements:

- Receive words: Control words and setpoints
- Send words: Status words and actual values

Default setting "Profidrive"

When the "Profidrive" default setting is chosen for command and setpoint selection (see "Command sources / "Profidrive" default settings"), "Free telegram" (p0922 = 999) is selected.

The receive message frame is parameterized as follows as a result of the default setting (plan 622):

| | |
|------|---------|
| STW1 | NSOLL_A |
|------|---------|

The send telegram is parameterized as follows (factory setting, plan 623):

| | | | | | |
|------|------------|-------------|------------|------------|------------|
| ZSW1 | NIST_GLATT | IAIST_GLATT | MIST_GLATT | PIST_GLATT | FAULT_CODE |
|------|------------|-------------|------------|------------|------------|

You do not have to make any further settings in order to use these telegrams.

User-defined telegram selection

a. Standard telegrams

Standard telegrams are structured in accordance with PROFIdrive profile or internal company specifications. The internal process data links are established automatically in accordance with the telegram number setting in CU parameter p0922.

The following standard telegrams can be set via parameter p0922:

- p0922 = 1 -> Speed setpoint, 16 bit
- p0922 = 2 -> Speed setpoint, 32 bit
- p0922 = 3 -> Speed setpoint 32 bit with 1 position controller
- p0922 = 4 -> Speed setpoint 32 bit with 2 position controller
- p0922 = 20 -> Speed setpoint, 16 bit VIK-NAMUR
- p0922 = 352 -> Speed setpoint, 16 PCS7

Depending on the setting in p0922, the interface mode of the control and status word is automatically set:

- p0922 = 1, 352, 999:
STW 1/ZSW 1: Interface Mode SINAMICS / MICROMASTER, p2038 = 0
- p0922 = 20:
STW 1/ZSW 1: Interface Mode PROFIdrive VIK-NAMUR, p2038 = 2

b. Manufacturer-specific telegrams

The manufacturer-specific telegrams are structured in accordance with internal company specifications. The internal process data links are set up automatically in accordance with the telegram number setting.

The following vendor-specific telegrams can be set via p0922:

- p0922 = 220 Speed setpoint 32 bit, metal industry

c. Free telegrams (p0922 = 999)

Send and receive telegrams can be configured as required by using BICO technology to interconnect the send and receive words. The default process data assigned under a) is retained during the changeover to p0922 = 999, although it can be changed or supplemented at any time.

To maintain compliance with the PROFIdrive profile, however, the following assignments should be retained:

- Interconnect PZD receive word 1 as control word 1 (STW 1)
- Interconnect PZD send word 1 as status word 1 (STW 1)

For more information about possible interconnections, see function diagrams FP2460 and FP2470 and the simplified diagrams 620 to 622.

6.6 PROFIBUS

Telegram interconnections

After changing p0922 = 999 (factory setting) to p0922 ≠ 999, the telegrams are interconnected and blocked automatically.

Note

Telegrams 20 and 352 are the exceptions. Here, the PZD06 in the send telegram and PZD03 to PZD06 in the receive telegram can be interconnected as required.

When you change p0922 ≠ 999 to p0922 = 999, the previous telegram interconnection is retained and can be changed.

Note

If p0922 = 999, a telegram can be selected in p2079. A telegram interconnection is automatically made and blocked. However, the telegram can also be extended.

This is an easy method of creating extended telegram interconnections on the basis of existing telegrams.

6.6.5 Structure of the telegrams

Table 6- 10 Structure of the telegrams

| Telegr. | PZD 1 | PZD 2 | PZD 3 | PZD 4 | PZD 5 | PZD 6 | PZD 7 | PZD 8 | PZD 9 | PZD 10 |
|---------|---------|--------------|-------------|------------|------------|--------------------------------|----------|-------|-------|--------|
| 1 | STW1 | NSOLL_A | | | | | | | | |
| | ZSW1 | NIST_A | | | | | | | | |
| 2 | STW1 | NSOLL_B | | STW2 | | | | | | |
| | ZSW1 | NIST_B | | ZSW2 | | | | | | |
| 3 | STW1 | NSOLL_B | | STW2 | G1_STW | | | | | |
| | ZSW1 | NIST_B | | ZSW2 | G1_ZSW | G1_XIST1 | G1_XACT2 | | | |
| 4 | STW1 | NSOLL_B | | STW2 | G1_STW | G2_STW | | | | |
| | ZSW1 | NIST_B | | ZSW2 | G1_ZSW | Further assignment, see FP2420 | | | | |
| 20 | STW1 | NSOLL_A | | | | | | | | |
| | ZSW1 | NIST_A_GLATT | IAIST_GLATT | MIST_GLATT | PIST_GLATT | MELD_NAMUR | | | | |
| 220 | STW1_BM | NSOLL_B | | STW2_BM | M_ADD | M_LIM | free | free | free | free |
| | ZSW1_BM | NIST_A | IAIST | MIST | WARN_CODE | FAULT_CODE | ZSW2_BM | free | free | free |
| 352 | STW1 | NSOLL_A | PCS7_3 | PCS7_4 | PCS7_5 | PCS7_6 | | | | |
| | ZSW1 | NIST_A_GLATT | IAIST_GLATT | MIST_GLATT | WARN_CODE | FAULT_CODE | | | | |
| 999 | STW1 | free | free | free | free | free | free | free | free | free |
| | ZSW1 | free | free | free | free | free | free | free | free | free |

6.6.5.1 Overview of control words and setpoints

Table 6- 11 Overview of control words and setpoints

| Abbreviation | Description | Parameters | Function diagram |
|--------------|---|---|------------------|
| STW1 | Control word 1 (interface mode SINAMICS, p2038 = 0) | See table "Control word 1 (interface mode SINAMICS, p2038 = 0)" | FP2442 |
| STW1 | Control word 1 (interface mode VIK-NAMUR, p2038 = 2) | See table "Control word 1 (interface mode VIK-NAMUR, p2038 = 2)" | FP2441 |
| STW1_BM | Control word 1, metal industry (interface mode SINAMICS, p2038 = 0) | See table "Control word 1, metal industry (interface mode SINAMICS, p2038 = 0)" | FP2425 |
| STW2 | Control word 2 (interface mode SINAMICS, p2038 = 0) | See table "Control word 2 (interface mode SINAMICS, p2038 = 0)" | FP2444 |
| STW2_BM | Control word 2, metal industry (interface mode SINAMICS, p2038 = 0) | See table "Control word 2, metal industry (interface mode SINAMICS, p2038 = 0)" | FP2426 |
| NSOLL_A | Speed setpoint A (16-bit) | p1070 | FP3030 |
| NSOLL_B | Speed setpoint B (32-bit) | p1155 | FP3080 |
| PCS7_x | PCS7-specific setpoints | | |

6.6 PROFIBUS

6.6.5.2 Overview of status words and actual values

Table 6- 12 Overview of status words and actual values

| Abbreviation | Description | Parameters | Function diagram |
|--------------|--|--|------------------|
| ZSW1 | Status word 1 (interface mode SINAMICS, p2038 = 0) | See table "Status word 1 (interface mode SINAMICS, p2038 = 0)" | FP2452 |
| ZSW1 | Status word 1 (interface mode VIK-NAMUR, p2038 = 2) | See table "Status word 1 (interface mode VIK-NAMUR, p2038 = 2)" | FP2451 |
| ZSW1_BM | Status word 1, metal industry (interface mode SINAMICS, p2038 = 0) | See table "Status word 1, metal industry (interface mode SINAMICS, p2038 = 0)" | FP2428 |
| ZSW2 | Status word 2 (interface mode SINAMICS, p2038 = 0) | See table "Status word 2 (interface mode SINAMICS, p2038 = 0)" | FP2454 |
| ZSW2_BM | Status word 2, metal industry (interface mode SINAMICS, p2038 = 0) | See table "Status word 2, metal industry (interface mode SINAMICS, p2038 = 0)" | FP2429 |
| NIST_A | Speed setpoint A (16 bit) | r0063[0] | FP4715 |
| NIST_B | Speed setpoint B (32 bit) | r0063 | FP4710 |
| IAIST | Actual value of current | r0068[0] | FP6714 |
| MIST | Actual torque value | r0080[0] | FP6714 |
| PIST | Actual power value | r0082[0] | FP6714 |
| NIST_GLATT | Actual speed value smoothed | r0063[1] | FP4715 |
| IAIST_GLATT | Current actual value, smoothed | r0068[1] | FP6714 |
| MIST_GLATT | Torque actual value, smoothed | r0080[1] | FP6714 |
| PIST_GLATT | Power actual value, smoothed | r0082[1] | FP6714 |
| MELD_NAMUR | VIK-NAMUR message bit bar | r3113, see table "NAMUR message bit bar" | -- |
| WARN_CODE | Alarm code | r2132 | FP8065 |
| ERROR_CODE | Error code | r2131 | FP8060 |

6.6.6 Further information about communication via PROFINET

Further information about communication via PROFIBUS

For more information about PROFINET IO communication, refer to "PROFIBUS communication" in the accompanying "SINAMICS S120 Function Manual".

6.7 Control via the operator panel

6.7.1 Operator panel (AOP30) overview and menu structure


Description

The operator panel can be used for the following activities:

- Parameterization (commissioning)
- Monitoring status variables
- Controlling the drive
- Diagnosing faults and alarms

All the functions can be accessed via a menu.

Your starting point is the main menu, which you can always call up using the yellow MENU key:



Dialog screen for the main menu:

It can be accessed at any time with the "MENU" key.

Press "F2" or "F3" to navigate through the menu options in the main menu.

Note

AOP reset

If the AOP no longer reacts, you can trigger an AOP reset by simultaneously pressing the key and OFF buttons (longer than two seconds) and then releasing the OFF button.

6.7 Control via the operator panel

Menu structure of the operator panel




Figure 6-24 Menu structure of the operator panel

6.7.2 Operation screen menu

Description

The operation screen displays the most important status variables for the drive unit:

In the delivery condition, it displays the operating state of the drive, the direction of rotation, the time, as well as four drive variables (parameters) numerically and two in the form of a bar display for continuous monitoring.

You can call up the operation screen in one of two ways:

1. After the power supply has been switched on and the system has ramped up.
2. By pressing the MENU key twice and then F5 "OK".




Figure 6-25 Operation screen

If a fault occurs, the system automatically displays the fault screen (see "Faults and alarms").

In LOCAL control mode, you can choose to enter the setpoint numerically (F2: setpoint).

The "Define operation screen" menu can be selected directly using F3 "Change".

The individual parameters of the operation screen can be selected using F4 "Sel. par". The corresponding parameter number of the short identifier is displayed using F1 "Help+" and a description of the parameter can be called up.

Settings

When you choose Commissioning / service → AOP settings → Define operation screen, you can adjust the display type and the values displayed as required (see "Operation / AOP30 settings").

6.7.3 Parameterization menu

You can adjust the device settings in the Parameterization menu.

The drive software is modular. The individual modules are called DOs ("drive objects").

6.7 Control via the operator panel

The following DOs are available in the SINAMICS G150:

- CU: General parameters for the Control Unit
- VECTOR: Drive control
- TM31: Terminal module TM31 (option G60)

Parameters with identical functions may exist with the same parameter number in more than one DO (e.g. p0002).

The AOP30 is used for operating devices that comprise more than one drive so that attention is focused on one drive (i.e. the "current" drive). You can switch between the drives either in the operation screen or in the main menu. The corresponding function key is labeled "Drive".

This drive determines the following:

- Operation screen
- Fault and alarm displays
- The controller (ON, OFF, ...) of a drive

Depending on your requirements, you can choose between two AOP display types:

1. All parameters

All the parameters present in the device are listed here. The DO to which the parameter currently selected belongs (inverted) is displayed in curly brackets in the top left of the screen.

2. DO selection

In this display, you can pre-select a DO. Only the parameters for this DO are then listed. (The expert list display in STARTER only uses this DO view)

In both cases, the set access level governs which parameters are displayed. You can set the access level in the menu for inhibit functions, which can be called up using the key button.

The parameters for access levels 1 and 2 are sufficient for simple applications.

At access level 3 "Expert", you can change the structure of the function by interconnecting BICO parameters.

In the data set selection menu, you can choose which of the data sets chosen is currently DISPLAYED.

Data set parameters are indicated by a "c", "d", "m", "e", or "p" between the parameter number and parameter designator.

When a data set parameter is changed, the data set selection dialog appears.

| Data block selection | | | |
|----------------------|-----------------------------------|--------------------------------|---|
| Type | Max | Drive | AOP |
| Command DB | c: <input type="text" value="1"/> | <input type="text" value="0"/> | <input checked="" type="text" value="0"/> |
| Drive DB | d: <input type="text" value="0"/> | <input type="text" value="0"/> | <input type="text" value="0"/> |
| Motor DB | m: <input type="text" value="0"/> | <input type="text" value="0"/> | <input type="text" value="0"/> |
| Help | ▲ ▼ | Back | OK |

F1 F2 F3 F4 F5

Figure 6-26 Data set selection

Explanation of the operator control dialog

- "Max" shows the maximum number of data sets parameterized (and thereby available for selection) in the drive.
- "Drive" indicates which data set is currently active in the drive.
- "AOP" indicates which particular data set is currently being displayed in the operator panel.


6.7 Control via the operator panel

6.7.4 Menu: Fault/alarm memory

When you select the menu, a screen appears containing an overview of faults and alarms that are present.


For each drive object, the system indicates whether any faults or alarms are present. ("Fault" or "Alarm" appears next to the relevant drive object).

In the graphic below, you can see that at least one active fault/alarm is present for the "VECTOR" drive object. No faults/alarms are indicated for the other drive objects.




Fault/alarm memory

When you navigate to the line with active alarms/faults and then press the F5 <Diag> key, the system displays a screen in which you have to select the current or old alarms/faults.



Display diagnosis

When you navigate to the required line and then press the F5 <OK> key, the corresponding faults/alarms are displayed. The list of current faults is selected here as an example.



Display of current faults

A maximum of eight current faults are displayed along with their fault number and name of the fault.

To display additional help regarding the cause of the problem and how to solve it, choose F1 <Help>.

To acknowledge the faults, choose F5 <Ack.>. If a fault cannot be acknowledged, the fault remains.



6.7.5 Menu commissioning / service

6.7.5.1 Drive commissioning

This option enables you to re-commission the drive from the main menu.

Basic Commissioning

Only the basic commissioning parameters are queried and stored permanently.

Complete commissioning

Complete commissioning with motor and encoder data entry is carried out. Following this, key motor parameters are recalculated from the motor data. The parameter values calculated during previous commissioning are lost.

In a subsequent motor identification procedure, the calculated values are overwritten.

Motor identification

The selection screen for motor identification appears.

Resetting the fan runtime

After a fan replacement, the time counter for monitoring the fan runtime must be reset.

6.7.5.2 Device commissioning

Device commissioning

In this menu, you can enter the device commissioning status directly. This is the only way that you can reset parameters to the factory setting for example.

6.7.5.3 AOP settings

Control settings

This defines the settings for the control keys in LOCAL mode (see "Operation / Control via the operator panel / Operation via the operator panel").

Display settings

In this menu, you set the lighting, brightness, and contrast for the display.

6.7 Control via the operator panel

Defining the operation screen

In this menu, you can switch between five operation screens. You can set the parameters that are to be displayed.




Figure 6-27 Defining the operation screen

The following image shows how the entries are assigned to the screen positions:




Figure 6-28 Layout of the entries in the operation screen

6.7.5.4 Lists of signals for the operation screen

The following tables list some of the main signals for the operation screen along with the associated reference variables and default settings for fast commissioning.

VECTOR object

Table 6- 13 List of signals for the operation screen - VECTOR object

| Signal | Parameters | Short name | Unit | Scaling (100 %=...) See table below |
|--|-------------------------|------------|-------|-------------------------------------|
| Factory setting (entry no.) | | | | |
| Speed setpoint upstream of ramp-function generator | (1) r1114 | NSETP | 1/min | p2000 |
| Output frequency | (2) r0024 | F_OUT | Hz | Reference frequency |
| Power smoothed | (3) r0032 | PACTV | kW | r2004 |
| DC link voltage smoothed | (4) r0026 | U_DC | V | p2001 |
| Actual speed value smoothed | (5) r0021 | N_ACT | 1/min | p2000 |
| Absolute actual current smoothed | (6) r0027 | I_IST | A | p2002 |
| Motor temperature | (7) r0035 ¹⁾ | T_MOT | °C | Reference temperature |
| Converter temperature | (8) r0037 | T_LT | °C | Reference temperature |
| Actual torque smoothed | (9) r0031 | M_ACT | Nm | p2003 |
| Converter output voltage smoothed | (10) r0025 | C_OUT | V | p2001 |
| For diagnostic purposes | | | | |
| Speed setpoint smoothed | r0020 | NSETP | 1/min | p2000 |
| Control factor smoothed | r0028 | AUSST | % | Reference modulation depth |
| Field-producing current component | r0029 | IDACT | A | p2002 |
| Torque-producing current component | r0030 | IQACT | A | p2002 |
| Converter overload Degree of thermal overload | r0036 | LTI2T | % | 100 % = Shutdown |
| Speed actual value motor encoder | r0061 | N_ACT | 1/min | p2000 |
| Speed setpoint after filter | r0062 | NSETP | 1/min | p2000 |
| Actual speed smoothed | r0063 | N_ACT | 1/min | p2000 |
| Control deviation | r0064 | NDIFF | 1/min | p2000 |
| Slip frequency | r0065 | FSCHL | Hz | Reference frequency |
| Output frequency | r0066 | F_OUT | Hz | Reference frequency |
| Output voltage | r0072 | UACT | V | p2001 |
| Control factor | r0074 | AUSST | % | Reference modulation depth |
| Torque-generating actual current | r0078 | IQACT | A | p2002 |
| Actual torque value | r0080 | M_ACT | Nm | p2003 |
| For further diagnostic purposes | | | | |
| Fixed speed setpoint effective | r1024 | | 1/min | p2000 |
| Active motorized potentiometer setpoint | r1050 | | 1/min | p2000 |
| Resulting speed setpoint | r1119 | NSETP | 1/min | p2000 |
| Speed controller output | r1508 | NREGY | Nm | p2003 |
| I component of speed controller | r1482 | NREGI | Nm | p2003 |
| PROFIBUS setpoint | r2050 | PBSOL | 1/min | p2000 |

¹⁾ If a temperature sensor has not been installed, a value of -200 °C is displayed.

6.7 Control via the operator panel

Normalization for VECTOR object

Table 6- 14 Normalization for VECTOR object

| Size | Scaling parameter | Default for quick commissioning |
|----------------------------|---|----------------------------------|
| Reference speed | 100% = p2000 | p2000 = Maximum speed (p1082) |
| Reference voltage | 100% = p2001 | p2001 = 1000 V |
| Reference current | 100% = p2002 | p2002 = Current limit (p0640) |
| Reference torque | 100% = p2003 | p2003 = 2 x rated motor torque |
| Reference power | 100% = r2004 | r2004 = (p2003 x p2000 x π) / 30 |
| Reference frequency | 100% = p2000/60 | |
| Reference modulation depth | 100 % = Maximum output voltage without overload | |
| Reference flux | 100 % = Rated motor flux | |
| Reference temperature | 100% = 100°C | |

TM31 object

Table 6- 15 List of signals for the operation screen – TM31 object

| Signal | Parameter | Short name | Unit | Scaling (100 % = ...) |
|------------------------|-----------|------------|-------|-----------------------|
| Analog input 0 [V, mA] | r4052[0] | AI_UI | V, mA | V: 100 V / mA: 100 mA |
| Analog input 1 [V, mA] | r4052[1] | AI_UI | V, mA | V: 100 V / mA: 100 mA |
| Analog input 0, scaled | r4055[0] | AI_% | % | as set in p200x |
| Analog input 1, scaled | r4055[1] | AI_% | % | as set in p200x |

Setting the date/time (for date stamping of error messages)

In this menu, you set the date and time.

You can also set whether and/or how the AOP and drive unit are to be synchronized. Synchronization of the AOP with the drive enables error messages to be date- and time-stamped.

- None (factory setting)
The times for the AOP and drive unit are not synchronized.
- AOP -> Drive
 - If you activate this option, the AOP and drive unit are synchronized immediately whereby the current AOP time is transferred to the drive unit.
 - The current AOP time is transferred to the drive unit every time the AOP is started.
 - At 02:00 (AOP time) every day, the current AOP time is transferred to the drive unit.

- Drive -> AOP
 - If you activate this option, the AOP and drive unit are synchronized immediately whereby the current drive unit time is transferred to the AOP.
 - The current drive unit time is transferred to the AOP every time the AOP is started.
 - At 02:00 (AOP time) every day, the current drive unit time is transferred to the AOP.

Date format

In this menu, the date format can be set:

- DD.MM.YYYY: European date format
- MM/DD/YYYY: North American data format

DO name display mode

In this menu, you can switch the display of the DO name between the standard abbreviation (e.g. VECTOR) and a user-defined DO name (e.g. Motor_1).

User-defined DO name (factory setting: NO)

- **Yes:** The "User-defined DO name" stored in parameter p0199 is displayed, instead of the standard DO abbreviation.
- **No:** The standard DO abbreviation is displayed.

Resetting AOP settings

When you choose this menu option, the AOP factory settings for the following are restored:

- Language
- Display (brightness, contrast)
- Operation screen
- Control settings

NOTICE

When you reset parameters, all settings that are different to the factory settings are reset immediately. This may cause the cabinet unit to switch to a different, unwanted operational status.

For this reason, you should always take great care when resetting parameters.

6.7 Control via the operator panel

6.7.5.5 AOP30 diagnosis

Software/database version

You can use this menu to display the firmware and database versions.

The database version must be compatible with the drive software status (you can check this in parameter r0018).

Battery status

In this menu, you can display the battery voltage numerically (in Volts) or as a bar display. The battery ensures that the data in the database and the current time are retained.

When the battery voltage is represented as a percentage, a battery voltage of ≤ 2 V is equal to 0%, and a voltage of ≥ 3 V to 100%.

The data is secure up to a battery voltage of 2 V.

- If the battery voltage is ≤ 2.45 V, the message "Replace battery" is displayed in the status bar.
- If the battery voltage is ≤ 2.30 V, the system displays the following message: "Warning: weak battery".
- If the battery voltage is ≤ 2 V, the system displays the following message: "Caution: The battery is dead".
- If the time and/or database are not available after the system has been switched off for a prolonged period due to the voltage being too low, the loss is established by means of a CRC check when the system is switched on again. This triggers a message instructing the user to replace the battery and then load the database and/or set the time.

For instructions on how to change the battery, see "Maintenance and servicing".

Keyboard test

In this screen, you can check that the keys are functioning properly. Keys that you press are represented on a symbolic keyboard on the display. You can press the keys in any order you wish. You cannot exit the screen (F4 – "back") until you have pressed each key at least once.

Note

You can also exit the key test screen by pressing any key and keeping it pressed.

LED test

In this screen, you can check that the 4 LEDs are functioning properly.

6.7.6 Language/Sprache/Langue/Idioma/Lingua

The operator panel downloads the texts for the different languages from the drive.

You can change the language of the operator panel via the "Language/Sprache/Langue/Idioma/Lingua" menu.

Note

Additional languages for the display

Languages in addition to the current available languages in the display are available on request.

6.7.7 Operation via the operator panel (LOCAL mode)

You activate the control keys by switching to LOCAL mode. If the green LED in the LOCAL/REMOTE key does not light up, the key is not active.

Note

If the "OFF in REMOTE" function is activated, the LED in the LOCAL-REMOTE key flashes.

For LOCAL master control, all of the supplementary setpoints are de-activated.

After the master control has been transferred to the operator panel, the BICO interconnections at bit 0 to bit 10 of the control word of the sequence control are not effective (refer to function diagram 2501).

6.7.7.1 LOCAL/REMOTE key



Activate LOCAL mode: Press the LOCAL key.

LOCAL mode: LED lights up

REMOTE mode: LED does not light up: the ON, OFF, JOG, direction reversal, faster, and slower keys are not active.

Settings: Menu – Commissioning / Service – AOP Settings – Control Settings

Save LOCAL mode (factory setting: yes)

- **Yes:** The "LOCAL" or "REMOTE" operating mode is saved when the power supply is switched off and restored when the power supply is switched back on.
- **No:** "LOCAL" or "REMOTE" operating mode is not saved. "REMOTE" is active when the supply voltage is switched back on.

OFF in REMOTE (factory setting: no)

- **Yes:** The OFF key functions in REMOTE mode even if the drive is being controlled by external sources (PROFIBUS, customer terminal strip, NAMUR terminal strip).
WARNING This function is not an EMERGENCY STOP function!
- **No:** The OFF key is only effective in LOCAL mode.

6.7 Control via the operator panel

LOCAL/REMOTE also during operation (factory setting: no)

- **Yes:** You can switch between LOCAL and REMOTE when the drive is switched on (motor is running).
- **No:** Before the system switches to LOCAL, a check is carried out to determine whether the drive is in the operational status. If so, the system does not switch to LOCAL and outputs the message "Local not possible". Before the system switches to REMOTE, the drive is switched off and the setpoint is set to 0.

6.7.7.2 ON key / OFF key



ON key: always active in LOCAL when the operator input inhibit is deactivated.

OFF key: in the factory setting, acts as OFF1 = ramp-down at the deceleration ramp (p1121); when n = 0: voltage disconnection (only if a main contactor is installed)
The OFF key is effective in the LOCAL mode and when the "OFF in REMOTE" function is active.

Settings: Menu – Commissioning / Service – AOP Settings – Control Settings

Red OFF key acts as: (factory setting: OFF1)

- **OFF1:** Ramp-down on the deceleration ramp (p1121)
- **OFF2:** Immediate pulse block, motor coasts to a standstill
- **OFF3:** Ramp-down on the emergency stop ramp (p1135)

6.7.7.3 Switching between clockwise and counter-clockwise rotation



Settings: Menu – Commissioning / Service – AOP Settings – Control Settings

Switching between CCW/CW (factory setting: no)

- **Yes:** Switching between CW/CCW rotation by means of the CW/CCW key possible in LOCAL mode
- **No:** The CW/CCW key has no effect in LOCAL mode

For safety reasons, the CW/CCW key is disabled in the factory setting (pumps and fans must normally only be operated in one direction).

In the operation status in LOCAL mode, the current direction of rotation is indicated by an arrow next to the operating mode.

Note

You have to make additional settings when switching between CW/CCW rotation.

6.7.7.4 Jog

JOG

Settings: Menu – Commissioning / Service – AOP Settings – Control Settings

JOG key active (factory setting: no)

- **Yes:** The jog key is effective in the LOCAL mode in the state "ready to power-up" (not in "operation"). The speed that is set in parameter p1058 is approached.
- **No:** The JOG key has no effect in LOCAL mode

6.7.7.5 Increase setpoint / decrease setpoint



You can use the increase and decrease keys to set the setpoint with a resolution of 1min⁻¹ of the maximum speed.

You can also enter the setpoint numerically. To do so, press F2 in the operation screen. The system displays an inverted edit field for entering the required speed. Enter the required value using the numeric keypad. Press F5 "OK" to confirm the setpoint.

When you enter values numerically, you can enter any speed between the minimum speed (p1080) and the maximum speed (p1082).

Setpoint entry in LOCAL mode is unipolar. You can change the direction of rotation by pressing the key that allows you to switch between CW/CCW rotation.

- CW rotation and "Increase key" mean:
The displayed setpoint is positive and the output frequency is increased.
- CCW rotation and "Increase key" mean:
The displayed setpoint is negative and the output frequency is increased.

6.7.7.6 AOP setpoint

Settings: MENU – Commissioning/Service – AOP Settings – Control Settings

Save AOP setpoint (factory setting: no)

- **Yes:** In LOCAL mode, the last setpoint (once you have released the INCREASE or DECREASE key or confirmed a numeric entry) is saved. The next time you switch the system on in LOCAL mode, the saved value is selected. This is also the case if you switched to REMOTE in the meantime or the power supply was switched off. When the system is switched from REMOTE to LOCAL mode while the drive is switched on (motor is running), the actual value that was last present is set as the output value for the motorized potentiometer setpoint and saved. If the system is switched from REMOTE to LOCAL mode while the drive is switched off, the motorized potentiometer setpoint that was last saved is used.
- **No:** On power-up in LOCAL mode, the speed is always set to the value entered under "AOP starting setpoint". When the system is switched from REMOTE to LOCAL mode while the drive is switched on (motor is running), the actual value that was last present is set as the output value for the AOP setpoint.

6.7 Control via the operator panel

AOP setpoint ramp-up time (factory setting: 10 s)

AOP setpoint ramp-down time (factory setting: 10 s)

- **Recommendation:** set as ramp-up/ramp-down time (p1120 / p1121).
Changing the ramp-up/ramp-down times does not affect the settings for parameters p1120 and p1121 because this is an AOP-specific setting.

AOP starting setpoint (factory setting: 0.000 rpm)

Note

The internal drive ramp-function generator is always active.

Settings: MENU – Commissioning/Service – AOP Settings – Control Settings

Save AOP local mode (factory setting: no)

- **Yes:** Deactivates the "Control via operator panel" function, thereby disabling the LOCAL/REMOTE key.
- **No:** Activates the LOCAL/REMOTE key.

Note

LOCAL functionality can also be locked on the drive by means of the p0806 parameter (BI: Lock master control).

Settings: MENU – Commissioning/Service – AOP Settings – Control Settings

Acknowledge error from the AOP (factory setting: yes)

- **Yes:** Errors can be acknowledged via the AOP.
- **No:** Errors cannot be acknowledged via the AOP.

6.7.7.7 Timeout monitoring









In "LOCAL" mode or if "OFF in REMOTE" is active, the drive is shut down after 1 s if the data cable between the AOP and drive is disconnected.

6.7.7.8 Operator input inhibit / parameterization inhibit



To prevent users from accidentally actuating the control keys and changing parameters, you can activate an operator input / parameters disable using a key pushbutton. Two key icons appear in the top right of the display when these inhibit functions are enabled.

Table 6- 16 Display of operator input/parameters disable

| Inhibit type | Online operation | Offline operation |
|---|---|---|
| No inhibit |  |  |
| Operator input inhibit |  |  |
| Parameters disable |  |  |
| Operator input inhibit + parameters disable |  |  |

Settings




Figure 6-29 Set inhibit functions

The "Operator input inhibit" setting can be changed directly via <F5> "Change" once you have selected the selection field.

When "Parameterization inhibit" is activated, you have to enter a numeric password (repeat this entry). You must also enter this password when deactivating "Parameterization inhibit".

Operator input inhibit (factory setting: not active)

- **Active:** The parameters can still be viewed, but a parameter value cannot be saved (message: "Note: operator input inhibit active"). The OFF key (red) is enabled. The LOCAL, REMOTE, ON (green), JOG, CW/CCW, INCREASE, and DECREASE keys are disabled.

Parameterization inhibit (factory setting: not active)

- **Active:** Parameters cannot be changed unless a password is entered. The parameterization process is the same as with the operator input inhibit. If you try and change parameters, the message "Note: Parameterization inhibit active" is displayed. All the control keys can, however, still be actuated.

Access level (factory setting: Expert):

The different parameters required for this complex application are filtered so that they can be displayed as clearly as possible. You select them according to the access level.

An expert level, which must only be used by expert personnel, is required for certain actions.

6.7 Control via the operator panel

Note

A "Copy RAM to ROM" is carried out automatically if the operator input inhibit or parameterization inhibit are activated; this saves the parameter settings in a non-volatile memory on the memory card.

6.7.8 Faults and alarms

Indicating faults and alarms

If a fault occurs, the drive displays the fault and/or alarm on the operator panel. Faults are indicated by the red "FAULT" LED and a fault screen is automatically displayed. You can use the F1 Help function to call up information about the cause of the fault and how to remedy it. You can use F5 Ack. to acknowledge a stored fault.

Alarms are indicated by means of the yellow "ALARM" LED. The system also displays a note in the status bar providing information on the cause.

What is a fault?

A fault is a message from the drive indicating an error or other exceptional (unwanted) status that causes the drive to shutdown. This could be caused by a fault within the converter or an external fault triggered, for example, by the winding temperature monitor for the motor. The faults are displayed and can be reported to a higher-level control system via PROFIBUS. In the factory default setting, the message "converter fault" is also sent to a relay output. Once you have rectified the cause of the fault, you have to acknowledge the fault message.

What is an alarm?

An alarm is the response to a fault condition identified by the drive. It does not result in the drive being switched off and does not have to be acknowledged. Alarms are "self acknowledging", that is, they are reset automatically when the cause of the alarm has been eliminated.

Fault and alarm displays

Every fault and alarm is entered in the fault/alarm buffer along with time the error occurred. The time stamp refers to the system time (r2114).

You can call up an overview screen that displays the current status of faults and/or alarms for every drive object in the system by choosing MENU – Fault memory / alarm memory.

A context menu featuring the "Back" and "Quit" options appears when you press F4 "Next". The function required can be selected using F2 and F3 and executed by pressing F5 "OK". The "Acknowledge" function sends an acknowledgement signal to each drive object. The red FAULT LED extinguishes once all the faults have been acknowledged.




Figure 6-30 Fault screen

You can use F5 Ack. to acknowledge a stored fault.




Figure 6-31 Alarm screen

Alarms that are no longer active are removed from the alarm memory with F5 Clear.

6.7.9 Saving the parameters permanently

Description

If parameters have been changed using the operator panel (confirm with OK in the Parameter Editor), the new values are initially stored in the volatile memory (RAM) of the converter. An "S" flashes in the top right of the AOP display until they are saved to a permanent memory. This indicates that at least 1 parameter has been changed and not yet stored permanently.

Two methods are available for permanently saving parameters that have been changed:

- To store the parameters permanently, choose <MENU> <Parameterization> <OK> <Permanent parameter transfer>.
- When confirming a parameter setting with OK, press the OK key for > 1 s. The system displays a message asking you whether the setting is to be saved in the EEPROM. If you press "Yes", the system saves the setting in the EEPROM. If you press "No", the setting is not saved permanently and the "S" starts flashing.

In both cases, **all** changes that have not yet been saved permanently are stored in the EEPROM.

6.7 Control via the operator panel

6.7.10 Parameterization errors

If a fault occurs when reading or writing parameters, a popup window containing the cause of the problem is displayed.

The system displays:

Parameter write error (d)pxxx.yy:0xnn

and a plain-text explanation of the type of parameterization error.

6.8 PROFINET IO

6.8.1 Activating online operation: STARTER via PROFINET IO

Description

Online operation with PROFINET IO is implemented using TCP/IP.

Prerequisites

- STARTER from version 4.1.5 or higher
- Latest version of the initialization tool PST (Primary Setup Tool)

The Primary Setup Tool is available on the STARTER DVD or it can be downloaded free of charge from the Internet:

<http://support.automation.siemens.com/WW/view/de/19440762>

- CBE20

STARTER via PROFINET IO (example)




Figure 6-32 STARTER via PROFINET (example)

Procedure, establishing online operation with PROFINET

1. Set the IP address in Windows XP
The PC/PG is referred here to a fixed, free IP address.
2. Settings in STARTER
3. Assigning the IP address and the name via PST (node initialization) or STARTER
The PROFINET interface must be "baptized" so that the STARTER can establish communication.
4. Select online operation in STARTER.

6.8 PROFINET IO

Set the IP address in Windows XP

On the desktop, right-click on "Network environment" -> Properties -> double-click on Network card and choose -> Properties -> Internet Protocol (TCP/IP) -> Properties -> Enter the freely-assignable addresses.




Figure 6-33 Properties of the Internet Protocol (TCP/IP)

Settings in STARTER

The following settings are required in STARTER for communication via PROFINET:

- Extras -> Set PG/PC interface




Figure 6-34 Set the PG/PC interface

- Right-click Drive unit -> Target device -> Online access -> Module address




Figure 6-35 Activating online operation

6.8 PROFINET IO

Assigning the IP address and the name

Note

ST (Structured Text) conventions must be satisfied for the name assignment of IO devices in PROFINET (SINAMICS components). The names must be unique within PROFINET. The characters "-" and "." are not permitted in the name of an IO device.

Assignment with the PST initialization tool

You can use the PST initialization tool (Primary Setup Tool) to assign an IP address and a name to the PROFINET interface.

- Connect the direct Ethernet cable from the PG/PC to the PROFINET interface.
- Switch on the Control Unit.
- Starting the Primary Setup Tool.
- Settings -> Network card -> Select the network card
- Network -> Search (or F5)
- Select the PROFINET device -> Module -> Assign name -> Enter the station name -> OK
- Module -> Load
- Network -> Search (or F5)
- Select "Ind. Ethernet interface" branch under the PROFINET device -> Assign IP address -> Enter the IP address (e.g. 169.254.11.22) -> Enter the subnet mask (e.g. 255.255.0.0)
The subnet masks must match before STARTER can be run.
- Module -> Load

Note

The IP address and device name for the Control Unit are stored on the memory card (non-volatile).

Assignment with STARTER, "Accessible nodes" function

Use the STARTER to assign an IP address and a name to the PROFINET interface.

- Connect the direct Ethernet cable from the PG/PC to the PROFINET interface.
- Switch on the Control Unit.
- Open STARTER.
- A search is performed for available nodes in PROFINET via Project -> Accessible nodes or the "Accessible nodes" button.
- The SINAMICS drive object with CBE20 is detected and displayed as a bus node with IP address 0.0.0.0 and without name.
- Mark the bus node entry and select the displayed menu item "Edit Ethernet node" with the right mouse button.

- In the following "Edit Ethernet node" screen, enter the device name for the PROFINET interface and click the "Assign name" button. Enter the IP address (e.g. 169.254.11.22) in the IP configuration and specify the subnet screen (e.g. 255.255.0.0). Then click the "Assign IP configuration" button. Close the screen.
- The "Update (F5)" button displays the IP address and name in the entry for the bus node. If not, close the "Accessible nodes" screen and perform another search for accessible nodes.
- If the PROFINET interface is displayed as bus node, mark the entry and click the "Accept" button.
- The SINAMICS drive with CBE20 is displayed as drive object in the project tree.
- Further configurations can be performed for the drive object.
- Click "Connect to target system" and load the project to the Control Unit's memory card with Target system -> Load -> To target device.

Note

The IP address and device name for the Control Unit are stored on the memory card (non-volatile).

6.8.2 General information about PROFINET IO

6.8.2.1 General information about PROFINET IO for SINAMICS

General information

PROFINET IO is an open Industrial Ethernet standard for a wide range of production and process automation applications. PROFINET IO is based on Industrial Ethernet and observes TCP/IP and IT standards.

The following standards ensure open, multi-vendor systems:

- International standard IEC 61158

PROFINET IO is optimized for high-speed, time-critical data communication at field level.

6.8 PROFINET IO

PROFINET

Within the context of Totally Integrated Automation (TIA), PROFINET IO is the systematic development of the following systems:

- PROFIBUS DP, the established field bus, and
- Industrial Ethernet, the communications bus for the cell level.

Experience gained from both systems was and is being integrated into PROFINET IO. As an Ethernet-based automation standard defined by PROFIBUS International (PROFIBUS user organization), PROFINET IO is a manufacturer-independent communication and engineering model.

PROFINET IO defines every aspect of the data exchange between IO controllers (devices with so-called "master functionality" and the IO devices (those with so-called "slave functionality") as well as parameterization and diagnostic processes. An IO system is configured by virtually the same method used for PROFIBUS.

A PROFINET IO system is made up of the following devices:

- The IO controller controls automation tasks.
- An IO device is controlled and monitored by an IO controller. An IO device consists of several modules and submodules.
- IO supervisor is an engineering tool typically based on a PC that is used to parameterize and diagnose individual IO devices (drive units).

IO devices: Drive units with PROFINET interface

- SINAMICS G150 with CU320-2 DP and inserted CBE20

SINAMICS G150 and CBE20 can be used for communication via PROFINET IO with RT.

Note

PROFINET for drive technology is standardized and described in the following document:

PROFIBUS Profile PROFIdrive – Profile Drive Technology

Version V4.1, May 2006,

PROFIBUS User Organization e. V.

Haid-und-Neu-Straße 7,

D-76131 Karlsruhe

<http://www.profibus.com>,

Order Number 3.172, spec. Chp. 6

- IEC 61800-7

CAUTION

Inserting the CBE20 Communication Board deactivates the cyclic PZD channel for PROFIBUS DP.

6.8.2.2 Real-time (RT) and isochronous real-time (IRT) communication

Real-time communication

When communication takes place via TCP/IP, the resultant transmission times may be too long and non-deterministic to meet production automation requirements. When communicating time-critical IO user data, PROFINET IO therefore uses its own real-time channel, rather than TCP/IP.

Determinism

Determinism means that a system will react in a predictable ("deterministic") manner. With PROFINET IO, it is possible to precisely determine (predict) transmission times.

PROFINET IO with RT (Real Time)

Real time means that a system processes external events over a defined period.

Process data and alarms are always transmitted in real time (RT) within the PROFINET IO system. RT communication provides the basis for data exchange with PROFINET IO. Real-time data are treated as a higher priority than TCP(UDP)/IP data. Transmission of time-critical data takes place at guaranteed time intervals.

PROFINET IO with IRT (Isochronous Real Time)

Isochronous Real Time Ethernet: Real time property of PROFINET IO where IRT telegrams are transmitted deterministically via planned communication paths in a defined sequence to achieve the best possible synchronism and performance between the IO controller and IO device (drive unit). This is also known as time-scheduled communication and uses knowledge about the network structure.

IRT requires special line components that support a planned data transfer.

Cycle times of minimum 500 μ s and a jitter accuracy of less than 1 μ s can be achieved when this transmission method is implemented.




Figure 6-36 Broadband distribution/reservation, PROFINET IO IRT

Note

Operation of S7-300 stations with SINAMICS drives: communication via PROFINET IO currently only possible with RT and IRT High Flexibility.

6.8 PROFINET IO

6.8.2.3 Addresses

Definition: MAC address

Each PROFINET device is assigned a worldwide unique device identifier in the factory. This 6-byte long device identifier is the MAC address. The MAC address is divided up as follows:

- 3 bytes manufacturer's ID and
- 3 bytes device identifier (consecutive number).

The MAC address is usually indicated on the front of the device.

e.g.: 08-00-06-6B-80-C0

IP address

To allow a PROFINET device to be addressed as a node on Industrial Ethernet, this device also requires an IP address that is unique within the network. The IP address is made up of 4 decimal numbers with a range of values from 0 through 255. The decimal numbers are separated by a period. The IP address is made up of

- The address of the (sub-) network and
- The address of the node (generally called the host or network node)

IP address assignment

The TCP/IP protocol is a prerequisite for establishing a connection and parameterization. This is the reason that an IP address is required.

The IP addresses of IO devices can be assigned by the IO controller and always have the same sub-network mask as the IO controller. In this case, the IP address is not stored permanently. The IP address entry is lost after POWER ON/OFF.

If the IP address is to be stored in a non-volatile memory, the address must be assigned using the Primary Setup Tool (PST) or STARTER.

This can also be carried out in HWConfig in STEP 7, where the function is called "Edit Ethernet node".

Note

If the network is part of an existing Ethernet company network, obtain the information (IP address) from your network administrator.

Device name (NameOfStation)

When it is shipped, an IO device does not have a device name. An IO device can only be addressed by an IO controller, for example, for the transfer of project engineering data (including the IP address) during startup or for user data exchange in cyclic operation, after it has been assigned a device name with the IO supervisor.

| |
|---|
| NOTICE |
| The device name must be saved in a non-volatile fashion either using the Primary Setup Tool (PST) or using HW Config from STEP 7. |

Replacing Control Unit (IO device)

If the IP address and device name are stored in a non-volatile memory, this data is also forwarded with the memory card (CF card) of the Control Unit.

If a complete Control Unit needs to be replaced due to a device or module defect, the new Control Unit automatically parameterizes and configures using the data on the memory card. Following this, cyclic exchange of user data is restarted. The memory card allows module exchange without an IO supervisor when a fault occurs in a PROFINET device.

6.8.2.4 Data transmission

Features

The Communication Board CBE20 supports:

- IRT – isochronous real-time Ethernet
- RT – real-time Ethernet
- Standard Ethernet services (TCP/IP, LLDP, UDP and DCP)

PROFIdrive telegram for cyclic data transmission and non-cyclic services

Telegrams to send and receive process data are available for each drive object of a drive unit with cyclic process data exchange.

In addition to cyclic data transfer, acyclic services can also be used for parameterizing and configuring the drive. These acyclic services can be utilized by the IO supervisor or IO controller.

6.8 PROFINET IO

Sequence of drive objects in the data transfer

The sequence of drive objects is displayed via a list in p0978[0...15] where it can also be changed.

Note

The sequence of drive objects in HW Config must be the same as that in the drive (p0978).

6.8.3 Further information about communication via PROFINET IO

Further information about communication via PROFINET IO

For more information about PROFINET IO communication, refer to "PROFINET IO communication" in the accompanying "SINAMICS S120 Function Manual".

6.9 SINAMICS Link

6.9.1 Basic principles of SINAMICS Link

SINAMICS Link enables data to be directly exchanged between several Control Units, which for this purpose must be equipped with the CBE20 supplementary module. Other nodes cannot be integrated into this communication. Possible applications include e.g.:

- Torque distribution for n drives
- Setpoint cascading for n drives
- Load distribution of drives coupled through a material web
- Master/slave function for infeed units

Send and receive data

The most frequently used node comprises a drive unit with a CU and a number of connected drive objects (DOs). A telegram of a SINAMICS Link has space retainers for 16 process data (PZD). Each PZD is precisely one word long. Slots that are not required are filled with zeros

| | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|
| 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
|---|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|

SINAMICS Link

Every node can send a telegram with 16 PZD. A drive object can receive up to 16 PZD from every other DO of the connected nodes as long as the transferred data within a telegram does not exceed 16 words. Single words and double words can be sent and received. Double words require 2 consecutive PZDs. It is not possible to read in your own send data.

Transmission time

A transmission time of 3.0 ms is possible when using SINAMICS Link (for a controller cycle, max. 0.5 ms; bus cycle, 2.0 ms).

6.9 SINAMICS Link

6.9.2 Topology

Only a line topology with the following structure is permitted for SINAMICS Link.




Figure 6-37 Maximum topology

- The numbers of the various nodes are entered into parameter p8836[0...63] in ascending order.
- Gaps in the numbering are not permitted.
- The node with the number 1 is automatically the sync master of the communication link.
- When configuring the communication, the **NameOfStation** (SINAMICSxLINKx001 ... SINAMICSxLINKx064) and the **IP address** (169.254.123.001 ... 169.254.123.064) of the particular node are automatically set up by allocating the node number and cannot be changed.
- For the CBE20 connection, the ports must be used as shown in the diagram above – this is mandatory. This means that Port 2 (P2) of node n is always connected with Port 1 (P1) of node $n+1$.

6.9.3 Configuring and commissioning

Commissioning

When commissioning, proceed as follows for the Control Unit:

- Set parameter p8835 to 3 (SINAMICS Link).
- Using parameter p8836, assign node numbers to the nodes (the first CU is always assigned the number 1). Observe the specifications under "Topology". Node number 0 means that SINAMICS Link is shut down.
- Perform a POWER ON (switch-off/switch-on).

Sending data

Proceed as follows to send data:

- In parameter p2051[x], for each drive object, define which data (PZDs) should be sent. p2061[x] must be used for double word quantities.
- In parameter p8871, for each drive object, assign the send parameter to the send slot of its own node. Double words (e.g. 2+3) are assigned two consecutive send slots, e.g. p8871[1] = 2 and p8871[2] = 3.

Receiving data

Proceed as follows to receive data:

Note

The first word of the receive data must be a control word, where bit 10 is set. If this is not the case, then you must deactivate the evaluation of bit 10 using p2037 = 2.

- Received data are saved in parameter r2050[x]/r2060[x].
- The address of the node from which the relevant PZD is to be read is defined in parameter p8872[0 ... 15] (0 $\hat{=}$ nothing is read in).
- In parameter p8870[0 ... 15], the PZD is defined which is read from the sent telegram and is to be stored in its own receive slot, r2050 for PZD or r2060 for double PZD (0 $\hat{=}$ no PZD selected).

Note

For double words, 2 PZD must be read; e.g.: Read in a 32-bit setpoint, which is located on PZD 2+3 for node 5 and map this to PZD 2+3 of its own node: p8872[1] = 5, p8870[1] = 2, p8872[2] = 5, p8870[2] = 3

Activation

To activate SINAMICS Link connections, perform a POWER ON for all nodes. The assignments of p2051[x]/2061[x] and the links of the read parameters r2050[x]/2060[x] can be changed without a POWER ON.

6.9 SINAMICS Link

6.9.4 Example

Task

Configure SINAMICS Link for two nodes (here, in example 2, SINAMICS S120) and transfer the following values:

- Send data from node 1 to node 2
 - r0898 CO/BO: Control word, drive object 1 (1 PZD), in the example PZD 1
 - r0079 CO: Total torque setpoint (2 PZD), in the example PZD 2
 - r1150 CO: Ramp-function generator speed setpoint at the output (2 PZD) in the example, PZD 3
- Send data from node 2 to node 1
 - r0899 CO/BO: Status word, drive object 1 (1 PZD), in the example, PZD 1

Procedure

1. For all nodes, set the SINAMICS Link mode:
p8835 = 3
2. Assign node numbers for the two devices:
 - Node 1: p8836 = 1 and
 - Node 2: p8836 = 2
3. Define the send data (node 1)
 - For node 1/DO VECTOR, define the PZD to be sent:
p2051.0 = Drive1:r0898, p2061.1 = Drive1:r0079, p2061.3 = Drive1:r1150
 - Assign this PZD to the send buffer (p8871) of its own DO:
p8871.0 = 1, p8871.1 = 2, p8871.2 = 3, p8871.3 = 4, p8871.4 = 5

This means that you have defined the position of the data in the 16-word telegram of the drive unit.

1. Define the send data (node 2)
 - For node 2/DO VECTOR, define the PZD to be sent:
p2051.0 = Drive1:r0898
 - Assign this PZD 1 to send buffer 0 (p8871) of its own DO:
p8871.0 = 1
2. Define the receive data (node 1)
 - Define that receive buffer 0 should be filled with data from node 2:
p8872.0 = 2
 - Define that PZD 1 of node 2 should be saved in this buffer:
p8870.0 = 1
 - r2050.0 now contains the value of PZD 1 of node 2.

3. Define the receive data (node 2)
 - Define that receive buffers 0 to 4 should be filled with data from node 1:
p8872.0 = 1, p8872.1 = 1, p8872.2 = 1, p8872.3 = 1, p8872.4 = 1
 - Define that PZD 1, PZD 2 and PZD 3 of node 1 should be saved in these buffers:
p8870.0 = 1, p8870.1 = 2, p8870.2 = 3, p8870.3 = 4, p8870.4 = 5
 - r2050.0, r2060.1 and r2060.3 now contain the values from PZD 1, PZD 2 and PZD 3 of node 1.
4. For both nodes, perform a POWER ON in order to activate the SINAMICS Link connections.




Figure 6-38 SINAMICS Link: Configuration example

6.9 SINAMICS Link

6.9.5 Diagnostics

Communication failure when booting or in cyclic operation

If at least one sender does not correctly boot after commissioning or fails in cyclic operation, then alarm A50005 is output to the other nodes: "Sender was not found on the SINAMICS Link."

The message contains the number of the faulted node. After you have resolved the fault at the node involved and the system has identified the node, the system automatically withdraws the alarm.

If several nodes are involved, the message occurs a multiple number of times consecutively with different node numbers. After you have resolved all of the faults, the system automatically withdraws the alarm.

When a node fails in cyclic operation, in addition to alarm A50005, fault F08501 is output: "COMM BOARD: Monitoring time, process data expired".

6.9.6 Parameter

- r2050[0...19] CO: IF1 PROFIdrive PZD receive word
- p2051[0...14] CI: IF1 PROFIdrive PZD send word
- r2060[0...18] CO: IF1 PROFIdrive PZD receive double word
- p2061[0...26] CI: IF1 PROFIdrive PZD send double word
- p8835 CBE20 firmware selection
- p8836 SINAMICS Link address
- p8870 SINAMICS Link telegram word PZD receive
- p8871 SINAMICS Link telegram word PZD send
- p8872 SINAMICS Link address PZD receive

6.10 Engineering Software Drive Control Chart (DCC)

Graphical configuring and expansion of the device functionality by means of available closed-loop control, arithmetic, and logic function blocks

Drive Control Chart (DCC) expands the facility for the simplest possible configuring of technological functions for both the SIMOTION motion control system and the SINAMICS drive system. This provides the user with a new dimension of system adaptability for specific machine functions.

DCC does not restrict the number of functions that can be used; the only restriction is the performance of the target platform.

The user-friendly DCC Editor enables easy graphical configuration and a clear representation of control loop structures as well as a high degree of reusability of existing diagrams.

The open-loop and closed-loop control functionality is defined by using multi-instance-enabled blocks (Drive Control Blocks (DCBs)) from a pre-defined library (DCB library) that are selected and graphically linked by dragging and dropping.

Test and diagnostic functions allow verification of the program behavior, and troubleshooting in the event of a fault.

The block library encompasses a large selection of closed-loop, arithmetic and logic function blocks, as well as comprehensive open-loop and closed-loop control functions.

For combining, analyzing and acquiring binary signals, all commonly used logic functions are available for selection (AND, XOR, on/off delay, RS flipflop, counter, etc.). Numerous computation functions are available for monitoring and evaluating numerical variables; for example absolute value generation, division, min/max evaluation.

Besides drive control functions, it is also a simple matter to configure axis winding functions, PI controllers, ramp-function generators, and wobble generators.

Almost unlimited programming of control structures is possible in conjunction with the SIMOTION motion control system. These can then be combined with other program sections to form an overall program.

Drive Control Chart for SINAMICS also provides a convenient basis for resolving drive-level open-loop and closed-loop control tasks directly in the drive. This results in further adaptability of SINAMICS for the task set. On-site processing in the drive supports modular machine concepts and results in increased overall machine performance.

Note

A detailed description of the DCC Editor and the available Drive Control Blocks is given in the relevant documentation. This documentation is available on the accompanying customer DVD.

6.10 Engineering Software Drive Control Chart (DCC)


7

Setpoint channel and closed-loop control

7.1 Chapter content

This chapter provides information on the setpoint channel and closed-loop control functions.

- Setpoint channel
 - Direction reversal
 - Skip speed
 - Minimum speed
 - Speed limitation
 - Ramp-function generator
- V/f control
- Vector speed control with / without encoder



7.2 Setpoint channel

Function diagrams

To supplement these operating instructions, the customer DVD contains simplified function diagrams describing the operating principle.

The diagrams are arranged in accordance with the chapters in the operating instructions. The page numbers (7xx) describe the functionality in the following chapter.

At certain points in this chapter, reference is made to function diagrams with a 4-digit number. These are stored on the customer DVD in the "SINAMICS G130/G150 List Manual", which provides experienced users with detailed descriptions of all the functions.

7.2 Setpoint channel

7.2.1 Setpoint addition

Description

The supplementary setpoint can be used to enter correction values from higher-level closed-loop controls. This can be implemented using the summing point of the main/supplementary setpoint in the setpoint channel. Both variables are imported simultaneously via two separate or one setpoint source and added in the setpoint channel.

Function diagram

FD 3030 Main/added setpoint, setpoint scaling, jogging

Parameters

- p1070 Main setpoint
- p1071 Main setpoint scaling
- r1073 Main setpoint effective
- p1075 Supplementary setpoint
- p1076 Supplementary setpoint scaling
- r1077 Supplementary setpoint effective
- r1078 Total setpoint effective

7.2.2 Direction reversal

Description

Due to the direction reversal in the setpoint channel the drive can be operated in both directions with the same setpoint polarity.

Use the p1110 or p1111 parameter to block negative or positive direction of rotation.

Note

If an incorrect rotating field was connected when the cables were installed, and the rotating field cannot be corrected by swapping the motor cables, it can be corrected when commissioning the drive via p1821 (rotating field direction reversal) by changing the rotating field and thus enabling a direction reversal (see section "Direction reversal").

Prerequisites

Direction reversal is triggered:

- via PROFIBUS by means of control word 1, bit 11
- via the cabinet operator panel (LOCAL mode) with the "Direction reversal" key.

Note

Note that only one direction of rotation is enabled in the delivery condition when control is carried out via the AOP30.

Function diagram

FP 3040 Direction of rotation limiting and direction of rotation changeover

Parameters

- p1110 Inhibit negative direction
- p1111 Inhibit positive direction
- p1113 Direction reversal

7.2 Setpoint channel

7.2.3 Suppression bandwidths and minimum speeds

Description

Variable-speed drives can generate critical whirling speeds within the control range of the entire drive train. This prevents steady-state operation in their proximity; in other words, although the drive can pass through this range, it must not remain within it because resonant oscillations may be excited. The skip frequency bands allow this range to be blocked for steady-state operation. Because the points at which critical whirling speeds occur in a drive train can vary depending on age or thermal factors, a broader control range must be blocked. To ensure that the speed does not constantly increase and decrease in the suppression bandwidth (speeds), the bands are assigned a hysteresis.

Specifying a minimum speed allows a specific range to be disabled around speed 0 rpm for steady-state operation.

Signal flow diagram




Figure 7-1 Signal flow diagram: Skip frequency speeds and minimum speeds

Function diagram

FP 3050 Skip frequency bands and speed limiting

Parameter

- p1080 Minimum speed
- p1091 Skip frequency speed 1
- p1092 Skip frequency speed 2
- p1093 Skip frequency speed 3
- p1094 Skip frequency speed 4
- p1101 Skip frequency speed bandwidth
- r1112 Speed setpoint after minimum limiting

7.2.4 Speed limitation

Description

Speed limitation aims to limit the maximum permissible speed of the entire drive train to protect the drive and load machine/process against damage caused by excessive speeds.

Signal flow diagram




Figure 7-2 Signal flow diagram: Speed limitation

Function diagram

FP 3050 Skip frequency bands and speed limiting

7.2 Setpoint channel

Parameters

- p1082 Maximum speed
- p1083 CO: Speed limit in positive direction of rotation
- r1084 CO: Speed limit positive effective
- p1085 CI: Speed limit in positive direction of rotation
- p1086 CO: Speed limit in negative direction of rotation
- r1087 CO: Speed limit negative effective
- p1088 CI: Speed limit in negative direction of rotation
- r1119 CO: Ramp-function generator setpoint at the input

7.2.5 Ramp-function generator

Description

The ramp-function generator limits the rate at which the setpoint changes when the drive is accelerating or decelerating. This prevents excessive setpoint step changes from damaging the drive train. Additional rounding times can also be set in the lower and upper speed ranges to improve control quality and prevent load surges, thereby protecting mechanical components, such as shafts and couplings.

The ramp-up and ramp-down times each refer to the maximum speed (p1082). The rounding times that can be set can prevent the actual speed value from being overshoot when the setpoint is approached, thereby improving control quality.

Notice: if rounding times are too long, this can cause the setpoint to be overshoot if the setpoint is reduced abruptly during ramp-up. Rounding is also effective in the zero crossover; in other words, when the direction is reversed, the ramp-function generator output is reduced to zero via initial rounding, the ramp-down time, and final rounding before the new, inverted setpoint is approached via start rounding, the ramp-up time, and end rounding. Rounding times that can be set separately are active in the event of a fast stop (OFF3). The actual ramp-up/ramp-down times increase with active rounding.

The rounding type can be set using p1134 and separately activated/deactivated using p1151.0 in the zero point.

Note

The effective ramp-up time increases when you enter initial and final rounding times.

Effective ramp-up time = $p1120 + (0.5 \times p1130) + (0.5 \times p1131)$

Signal flow diagram




Figure 7-3 Signal flow diagram: Ramp-function generator

Ramp-function generator tracking

If the drive is in range of the torque limits, the actual speed value moves away from the speed setpoint. The ramp-function generator tracking updates the speed setpoint in line with the actual speed value and so levels the ramp.

p1145 can be used to deactivate ramp-function generator tracking (p1145 = 0) or to set the permissible deviation (p1145 > 1). If the permissible deviation is reached, then the speed setpoint at the ramp-function generator output will only be increased further in proportion to the speed setpoint.

Parameter r1199.5 displays whether the ramp-function generator tracking is active.




Figure 7-4 Ramp-function generator tracking

7.2 Setpoint channel

Without ramp-function generator tracking

- p1145 = 0
- Drive accelerates to t2, although the setpoint after t1 is smaller than the actual value

With ramp-function generator tracking

- At p1145 > 1 (values between 0 and 1 are not applicable), ramp-function generator tracking is activated when the torque limit is approached. The ramp-function generator output thereby only exceeds the actual speed value by the deviation value defined in p1145.
- t1 and t2 are almost identical

Function diagram

| | |
|---------|--|
| FP 3060 | Simple ramp-function generator |
| FP 3070 | Extended ramp-function generator |
| FP 3080 | Ramp-function generator selection, status word, tracking |

Parameters

- r1119 Ramp-function generator setpoint at the input
- p1120 Ramp-function generator ramp-up time
- p1121 Ramp-function generator ramp-down time
- p1130 Ramp-function generator initial rounding time
- p1131 Ramp-function generator final rounding time
- p1134 Ramp-function generator rounding type
- p1135 OFF3 ramp-down time
- p1136 OFF3 initial rounding time
- p1137 OFF3 final rounding time
- p1145 Ramp-function generator tracking intensity
- r1150 Ramp-function generator speed setpoint at the output
- p1151 Ramp-function generator configuration

7.3 V/f control

Description

The simplest solution for a control procedure is the V/f characteristic, whereby the stator voltage for the induction motor or synchronous motor is controlled proportionately to the stator frequency. This method has proved successful in a wide range of applications with low dynamic requirements, such as:

- Pumps and fans
- Belt drives
- Multi-motor drives

V/f control aims to maintain a constant flux (Φ) in the motor, whereby the flux is proportional to the magnetization current (I_μ) or the ratio of voltage (U) to frequency (f).

$$\Phi \sim I_\mu \sim V/f$$

The torque (M) generated by the induction motors is, in turn, proportional to the product (or, more precisely, the vector product ($\Phi \times I$)) of the flux and current.

$$M \sim \Phi \times I$$

To generate as much torque as possible with a given current, the motor must function using the greatest possible constant flux. To maintain a constant flux (Φ), therefore, the voltage (V) must change in proportion to the frequency (f) to ensure a constant magnetization current (I_μ). V/f characteristic control is derived from these basic premises.

The field-weakening range is above the rated motor frequency, where the maximum voltage is reached. The flux and maximum torque decrease as the frequency increases; this is illustrated in the following diagram.








Figure 7-5 Operating areas and characteristic curves for the induction motor with converter supply

Several variations of the V/f characteristic exist, which are listed in the following table.

7.3 V/f control

Table 7- 1 p1300 V/f characteristics

| Parameter value | Meaning | Application / property |
|-----------------|---|---|
| 0 | Linear characteristic | Standard with variable voltage boost  |
| 1 | Linear characteristic with flux current control (FCC) | Characteristic that compensates for voltage losses in the stator resistance for static / dynamic loads (flux current control FCC). This is particularly useful for small motors, since they have a relatively high stator resistance.  |
| 2 | Parabolic characteristic | Characteristic that takes into account the motor torque curve (e.g. fan/pump). <ul style="list-style-type: none"> • Quadratic characteristic (f^2 characteristic) • Energy saving because the low voltage also results in small currents and losses.  |
| 3 | Programmable characteristic | Characteristic that takes into account the motor/machine torque characteristic.  |
| 4 | Linear characteristic and ECO | Characteristic (see parameter value 0) and ECO mode at constant operating point. <ul style="list-style-type: none"> • At constant operating point, the efficiency is optimized by varying the voltage. • Active slip compensation is necessary here; the scaling must be set so that the slip is fully compensated (p1335 = 100%). |

| Parameter value | Meaning | Application / property |
|-----------------|--|---|
| 5 | Precise frequency drives (textiles) | Characteristic (see parameter value 0) that takes into account the specific technological features of an application (e.g. textile applications). <ul style="list-style-type: none"> The current limitation (Imax controller) only affects the output voltage and not the output frequency. The slip compensation and resonance damping are disabled. |
| 6 | Precise frequency drives with flux current control (FCC) | Characteristic (see parameter value 1) that takes into account the specific technological features of an application (e.g. textile applications). <ul style="list-style-type: none"> The current limitation (Imax controller) only affects the output voltage and not the output frequency. The slip compensation and resonance damping are disabled. Voltage losses in the stator resistance for static / dynamic loads are also compensated (flux current control, FCC). This is particularly useful for small motors, since they have a relatively high stator resistance. |
| 7 | Parabolic characteristic and ECO | Characteristic (see parameter value 1) and ECO mode at constant operating point. <ul style="list-style-type: none"> At constant operating point, the efficiency is optimized by varying the voltage. Active slip compensation is necessary here; the scaling must be set so that the slip is fully compensated (p1335 = 100%). |
| 19 | Independent voltage setpoint | The user can define the output voltage of the Power Module independently of the frequency using BICO parameter p1330 via the interfaces (e.g., analog input AI0 of the TM31 → p1330 = r4055[0]). |

Function diagram

FP 6300 V/f characteristic and voltage boost

Parameters

- p1300 Open-loop/closed-loop control operating mode

7.3 V/f control

7.3.1 Voltage Boost

Description

With low output frequencies, the V/f characteristics yield only a small output voltage.

With low frequencies, too, the ohmic resistance of the stator windings has an effect and can no longer be ignored vis-à-vis the machine reactance. With low frequencies, therefore, the magnetic flux is no longer proportional to the magnetization current or the V/f ratio.

The output voltage may, however, be too low to:

- Magnetize the induction motor.
- Maintain the load.
- Compensate for the voltage losses (ohmic losses in the winding resistors) in the system.
- Induce a breakaway / accelerating / braking torque.

You can choose whether the voltage boost is to be active permanently (p1310) or only during acceleration (p1311). In addition, a one-off voltage boost in the first power up after pulse enable can be set via p1312.




Figure 7-6 Voltage boost total

Note

The voltage boost affects all V/f characteristics (p1300) from 0 to 7.

NOTICE

If the voltage boost value is too high, this can result in a thermal overload of the motor winding.

Permanent voltage boost (p1310)

The voltage boost is active across the entire frequency range up to the rated frequency f_n ; at higher frequencies, the value decreases continuously.




Figure 7-7 Permanent voltage boost (example: $p1300 = 0$, $p1310 > 0$, $p1311 = p1312 = 0$)

7.3 V/f control

Voltage boost during acceleration (p1311)

The voltage boost is only effective for one acceleration operation and only until the setpoint is reached.

Voltage boost is only effective if the signal "ramp-up active" (r1199.0 = 1) is present.

You can use parameter r0056.6 to observe whether the voltage boost is active during acceleration.




Figure 7-8 Voltage boost during acceleration (example: p1300 = 0, p1310 = 0, p1311 > 0)

Voltage boost at startup (p1312)

The voltage boost is only effective for the first acceleration operation after pulse enable and only until the setpoint is reached.

Voltage boost is only effective if the signal "ramp-up active" (r1199.0 = 1) is present.

You can use parameter r0056.5 to observe whether the voltage boost is active at startup.

Function diagram

FP 6300 V/f characteristic and voltage boost

Parameters

- r0056.5 Voltage boost at startup active/inactive
- r0056.6 Acceleration voltage active/inactive
- p0304 Rated motor voltage
- p0305 Rated motor current
- r0395 Stator resistance, actual
- p1310 Permanent voltage boost
- p1311 Voltage boost during acceleration
- p1312 Voltage boost at start up
- r1315 Voltage boost total

7.3.2 Resonance damping

Description

Resonance damping damps oscillations in the active current, which often occur during no-load operation. Resonance damping is active in the range between approximately 5% and 90% of the rated motor frequency (p0310), up to 45 Hz at most, however.




Figure 7-9 Resonance damping

Note

At p1349 = 0 the switching limit is automatically set to 95% of the rated motor frequency, up to 45 Hz at most, however.

7.3 V/f control

Function diagram

FP 6310 Resonance damping and slip compensation

Parameters

- r0066 Output frequency
- r0078 torque-generating actual current value
- p1338 Resonance damping gain
- p1339 Resonance damping filter time constant
- p1349 Resonance damping maximum frequency

7.3.3 Slip compensation

Description

Slip compensation essentially keeps the speed of induction motors constant irrespective of the load (M_1 or M_2).

For an increase in the load from M_1 to M_2 , the setpoint frequency is automatically increased so that the resulting frequency and therefore the motor speed remains constant. For a decrease in the load from M_2 to M_1 , the setpoint frequency is automatically decreased accordingly.

If a motor holding brake is applied, a setting value can be specified at the slip compensation output via p1351. If parameter $p1351 > 0$ then the slip compensation is switched on automatically ($p1335 = 100\%$).




Figure 7-10 Slip compensation

Function diagram

FP 6310 Resonance damping and slip compensation

Parameters

- r0330 Rated motor slip
- p1334 Slip compensation start frequency
- p1335 Slip compensation
p1335 = 0.0%: slip compensation is deactivated.
p1335 = 100.0%: slip is fully compensated.
- p1336 Slip compensation limit value
- r1337 Actual slip compensation
- p1351 CO: Motor holding brake start frequency

7.4 Vector speed/torque control with/without encoder

Description

Compared with V/f control, vector control offers the following benefits:

- Stability vis-à-vis load and setpoint changes
- Short rise times with setpoint changes (→ better command behavior)
- Short settling times with load changes (→ better disturbance characteristic)
- Acceleration and braking are possible with maximum adjustable torque
- Motor protection due to variable torque limitation in motor and regenerative mode
- Drive and braking torque controlled independently of the speed
- Maximum breakaway torque possible at speed 0

These benefits are available without speed feedback.

Vector control can be used with or without an encoder.

The following criteria indicate when an encoder is required:

- Maximum speed accuracy requirements
- Maximum dynamic response requirements
 - Better command behavior
 - Shortest settling times when disturbances occur
- Torque control is required in a control range greater than 1:10
- Allows a defined and/or variable torque for speeds below approx. 10% of the rated motor frequency (p0310) to be maintained.
- A speed controller is normally always required for applications in which an unknown speed can represent a safety risk (where a load can be dropped, e.g. lifting gear, elevators, etc).

With regard to setpoint input, vector control is divided into:

- Speed control
- Torque/current control (in short: torque control)

7.4.1 Vector control without encoder

Description

For sensorless vector control only (SLVC: Sensorless Vector Control), the position of the flux and actual speed must be determined via the electric motor model. The model is buffered by the incoming currents and voltages. At low frequencies (approx. 1 Hz), the model cannot determine the speed.

For this reason and due to uncertainties in the model parameters or inaccurate measurements, the system is switched from closed-loop to open-loop operation in this range.

The changeover between closed-loop/open-loop operation is controlled on the basis of time and frequency conditions (p1755, p1756, p1758 - only for induction motors). The system does not wait for the time condition to elapse if the setpoint frequency at the ramp-function generator input and the actual frequency are below $p1755 \times (1 - (p1756 / 100 \%)$ simultaneously.

Transition from open-loop to closed-loop operation always takes place when the changeover speed in p1755 (characteristic "1" in the figure below). If the speed increase is set very slow and a changeover delay time >0 is set in p1759, transition takes place after the changeover delay time (characteristic "2" in the figure below).




Figure 7-11 Changeover conditions

In open-loop operation, the calculated actual speed value is the same as the setpoint value. For vertical loads and acceleration processes, parameters p1610 (constant torque boost) and p1611 (acceleration torque boost) must be adjusted to the necessary maximum torque in order to generate the static or dynamic load torque of the drive. If, on induction motors, p1610 is set to 0%, only the magnetizing current r0331 is injected; at a value of 100%, the rated motor current p0305 is injected. For permanent-magnet synchronous motors, at p1610 = 0%, a pre-control absolute value derived from the supplementary torque r1515 remains instead of the magnetizing current. To ensure that the drive does not stall during acceleration, p1611 can be increased or acceleration pre-control for the speed controller can be used. This is also advisable to ensure that the motor is not subject to thermal overload at low speeds.

7.4 Vector speed/torque control with/without encoder

Vector control without a speed sensor has the following characteristics at low frequencies:

- Closed-loop operation up to approx. 1 Hz output frequency
- Starting in closed-loop operation (directly after the drive has been energized) (induction motors only)

Note

In this case, the speed setpoint upstream of the ramp-function generator must be greater than the changeover speed in p1755.

Closed-loop operation up to approx. 1 Hz (settable via parameter p1755) and the ability to start or reverse at 0 Hz directly in closed-loop operation (settable via parameter p1750) result in the following benefits:

- No changeover required within closed-loop control (smooth operation, no dips in frequency).
- Stationary speed–torque control up to approx. 1 Hz.

Note

When the motor is started or reversed in closed-loop control at 0 Hz, it is important to take into account that a switchover is made from closed-loop to open-loop control automatically if the system remains in the 0 Hz range for too long (> 2 s or $> p1758$, if $p1758 > 2$ s).

Closed-loop operation down to standstill for passive loads

By restricting to a passive load at the starting point, it is possible to maintain stationary closed-loop operation down to zero frequency (standstill) without having to change over to open-loop operation.

Parameter p1750.2 must be set to 1.

Closed-loop control without changeover is restricted to applications with passive load: These include applications in which the load cannot produce a regenerative torque on startup and the motor comes to a standstill when pulses are inhibited; for example, moments of inertia, brakes, pumps, fans, centrifuges, extruders, etc.

Standstill of any duration is possible without holding current, only the motor magnetization current is impressed.

Steady-state regenerative operation at a frequency close to zero is not possible.

It is also possible to select sensorless control for passive loads during commissioning by setting p0500 = 2 (technology application = passive loads (for sensorless control down to $f = 0$)).

This function is activated automatically if quick commissioning is exited with p3900 > 0, or if automatic calculation is called (p0340 = 1, 3, 5 or p0578 = 1).

Permanent-magnet synchronous motors

Standard procedure: open-loop controlled operation at low speeds

Normally, permanent-magnet synchronous motors are started and reversed in open-loop controlled operation. The changeover speeds are set to 10% or 5% of the rated motor speed. Changeover is not subject to any time condition (p1758 is not evaluated). Prevailing load torques (motor or regenerative) are adapted in open-loop operation, facilitating constant-torque crossover to closed-loop operation even under high static loads. Whenever the pulses are enabled, the rotor position is identified.




Figure 7-12 Zero crossing in open-loop controlled operation at low speeds

Extended procedure: closed-loop controlled operation to zero speed

By superimposing high-frequency pulses on the driving fundamental voltage and evaluating the resulting offset pulse in the machine current, it is possible to determine the continuous rotor position up to frequency zero (standstill).

1FW4 and 1PH8 series Siemens torque motors can be started from standstill with any load up to the rated torque or even hold the load at standstill.

The procedure is suitable for motors with internal magnets.

Note

If a sinewave filter is used, the open-loop controlled procedure should be used.

7.4 Vector speed/torque control with/without encoder

The following advantages are obtained by maintaining closed-loop controlled operation:

- No switchover required within closed-loop control (smooth switching, no discontinuities in the torque).
- Closed-loop speed and torque control without encoder (sensorless) up to and including 0 Hz.
- Higher dynamic performance when compared to open-loop controlled operation.
- Encoderless operation of drive line-ups (e.g. in the paper industry, master-slave operation).
- Active (including hanging/suspended) loads down to zero frequency.

Supplementary conditions for the use of third-party motors:

- Experience shows that the procedure is very suitable for motors with magnets within the rotor core (IPMSM - Interior Permanent Magnet Synchronous Motors).
- The ratio of stator quadrature reactance (L_{sq}): Stator direct-axis reactance (L_{sd}) must be > 1 (recommendation: at least > 1.5).
- The possible operating limits of the procedure depend upon up to what current the asymmetrical reactance ratio ($L_{sq}:L_{sd}$) is retained in the motor. If the procedure should be operable up to the rated motor torque, then the reactance ratio must be retained up to the rated motor current.

A prerequisite for optimum behavior is the entry of the following parameters:

- Enter the saturation characteristic: p0362 - p0369
- Enter the load characteristic: p0398, p0399

Commissioning sequence for closed-loop controlled operation to zero speed:

- Run through the commissioning with motor identification at standstill.
- Enter the parameters for the saturation characteristic and the load characteristic.
- Activate closed-loop controlled operation to zero speed via parameter p1750 bit 5.




Figure 7-13 Zero crossing in closed-loop controlled operation to zero speed

Function diagram

| | |
|---------|---|
| FP 6730 | Interface to Motor Module (ASM), p0300 = 1) |
| FP 6731 | Interface to Motor Module (PEM), p0300 = 2) |

Parameters

- p0305 Rated motor current
- r0331 Motor magnetizing current/short-circuit current
- p0362 Saturation characteristic flux 1
- ...
- p0365 Saturation characteristic flux 4
- p0366 Saturation characteristic I_mag 1
- ...
- p0369 Saturation characteristic I_mag 4
- p0398 Magnet angle. Decoupling (cross saturation) coefficient 1
- p0398 Magnet angle. Decoupling (cross saturation) coefficient 3
- p0500 Technology application
- p0578 Calculating technology/unit-dependent parameters
- p1605 Pulse technique pattern configuration
- r1606 CO: Actual pulse technique pattern
- p1607 Pulse technique stimulus
- r1608 CO: Pulse technique answer
- p1610 Torque setpoint static (SLVC)
- p1611 Supplementary accelerating torque (SLVC)
- p1750 Motor model configuration
- p1755 Motor model changeover speed encoderless operation
- p1756 Motor model changeover speed hysteresis
- p1758 Motor model changeover delay time, closed/open-loop control
- p1759 Motor model changeover delay time open/closed loop control
- r1762.1 Motor model deviation component 1 - deviation model 2
- p1798 Motor model pulse technique speed adaptation Kp
- p1810.3 Modulator configuration - current measurement oversampling activated (for pulse technique PEM)

7.4 Vector speed/torque control with/without encoder

7.4.2 Vector control with encoder

Description

Benefits of vector control with an encoder:

- The speed can be controlled right down to 0 Hz (standstill)
- Stable control response throughout the entire speed range
- Allows a defined and/or variable torque for speeds below approx. 10 % of the rated motor speed to be maintained
- Compared with speed control without an encoder, the dynamic response of drives with an encoder is significantly better because the speed is measured directly and integrated in the model created for the current components.

Motor model change

A model change takes place between the current model and the observer model within the speed range $p1752 \times (100 \% - p1756)$ and $p1752$. In the current-model range (i.e., at lower speeds), torque accuracy depends on whether thermal tracking of the rotor resistance is carried out correctly. In the observer-model range and at speeds of less than approx. 20% of the rated speed, torque accuracy depends primarily on whether thermal tracking of the stator resistance is carried out correctly. If the resistance of the supply cable is greater than 20% to 30 % of the total resistance, this should be entered in $p0352$ before motor data identification is carried out ($p1900/p1910$).

To deactivate thermal adaptation, set $p0620 = 0$. This may be necessary if adaptation cannot function accurately enough due to the following supplementary conditions: For example, if a KTY sensor is not used for temperature detection and the ambient temperatures fluctuate significantly or the overtemperatures of the motor ($p0626 \dots p0628$) deviate significantly from the default settings due to the design of the motor.

Function diagram

| | |
|---------|--|
| FP 4715 | Actual speed value and rotor position measurement, motor encoder |
| FD 6030 | Speed setpoint, droop |
| FP 6040 | Speed controller |
| FP 6050 | Kp_n-/Tn_n adaptation |
| FP 6060 | Torque setpoint |
| FP 6490 | Speed control configuration |

7.4.3 Speed controller

Description

Both closed-loop control techniques with and without encoder (SLVC, VC) have the same speed controller structure that contains the following components as kernel:

- PI controller
- Speed controller pre-control
- Droop Function

The torque setpoint is generated from the total of the output variables and reduced to the permissible magnitude by means of torque setpoint limitation.

The speed controller receives its setpoint (r0062) from the setpoint channel and its actual value (r0063) either directly from the speed actual value encoder (vector control with encoder) or indirectly via the motor model (encoderless vector control). The system difference is increased by the PI controller and, in conjunction with the pre-control, results in the torque setpoint.

When the load torque increases, the speed setpoint is reduced proportionately when the droop function is active, which means that the single drive within a group (two or more mechanically connected motors) is relieved when the torque becomes too great.




Figure 7-14 Speed controller

The optimum speed controller setting can be determined via the automatic speed controller optimization function (p1900 = 1, rotating measurement).

If the moment of inertia has been specified, the speed controller (K_p , T_n) can be calculated by means of automatic parameterization (p0340 = 4). The controller parameters are defined in accordance with the symmetrical optimum as follows:

$$T_n = 4 \times T_s$$

$$K_p = 0.5 \times r0345 / T_s = 2 \times r0345 / T_n$$

T_s = Sum of the short delay times (includes p1442 and p1452).

7.4 Vector speed/torque control with/without encoder

If vibrations occur with these settings, the speed controller gain (Kp) will need to be reduced manually. Actual-speed-value smoothing can also be increased (standard procedure for gearless or high-frequency torsion vibrations) and the controller calculation performed again because this value is also used to calculate Kp and Tn.

The following relationships apply for optimization:

- If Kp is increased, the controller becomes faster, although overshoot is increased. However, signal ripples and vibrations in the speed control loop will increase.
- Although reducing Tn will also speed up the controller, it will increase overshoot.

When setting speed control manually, you are advised to define the dynamic response via Kp (and actual-speed-value smoothing) first, so that the integral time can subsequently be reduced as much as possible. Please remember that closed-loop control must also remain stable in the field-weakening range.

To suppress any vibrations that occur in the speed controller, it is usually only necessary to increase the smoothing time in p1452 for operation without an encoder or p1442 for operation with an encoder, or reduce the controller gain.

The integral output of the speed controller can be monitored via r1482 and the limited controller output via r1508 (torque setpoint).

Note

In comparison with speed control with an encoder, the dynamic response of drives without an encoder is significantly reduced. The actual speed is derived by means of a model calculation based on the converter output variables for current and voltage that have a corresponding interference level. To this end, the actual speed must be adjusted by means of filter algorithms in the software.

Function diagram

FP 6040 Speed controller

Parameter

- r0062 CO: Speed setpoint after the filter
- r0063 CO: Actual speed value smoothed
- p0340 Automatic calculation, control parameters
- r0345 CO: Rated motor startup time
- p1442 Speed-actual-value smoothing time (VC)
- p1452 Speed-actual-value smoothing time (encoderless VC)
- p1460 Speed controller P gain with encoder
- p1462 Speed controller integral time with encoder
- p1470 Speed controller encoderless operation P gain
- p1472 Speed controller encoderless operation integral time

- r1482 CO: Torque output I speed controller
- r1508 CO: Torque setpoint before supplementary torque
- p1960 Speed controller optimization selection

Examples of speed controller settings

A few examples of speed controller settings with vector control without encoders (p1300 = 20) are provided below. These should not be considered to be generally valid and must be checked in terms of the control response required.

- **Fans (large centrifugal masses) and pumps**

K_p (p1470) = 2 ... 10

T_n (p1472) = 250 ... 500 ms

The $K_p = 2$ and $T_n = 500$ ms settings result in asymptotic approximation of the actual speed to the setpoint speed after a setpoint step change. During many simple control procedures, this is satisfactory for pumps and fans.

- **Stone mills, separators (large centrifugal masses)**

K_p (p1470) = 12 ... 20

T_n (p1472) = 500 ... 1000 ms

- **Kneader drives**

K_p (p1470) = 10

T_n (p1472) = 200 ... 400 ms

Note

We recommend checking the effective speed control gain (r1468) during operation. If this value changes during operation, the K_p adaptation is being used (p1400.5 = 1). K_p adaptation can if necessary be deactivated or its behavior changed.

- **When operating with encoder (p1300 = 21)**

A smoothing value for the actual speed value (p1442) = 5 ... 20 ms ensures quieter operations for motors with gear units.

7.4 Vector speed/torque control with/without encoder

7.4.3.1 Speed controller pre-control (integrated pre-control with balancing)

Description

The command behavior of the speed control loop can be improved by calculating the accelerating torque from the speed setpoint and connecting it on the line side of the speed controller. This torque setpoint mv is applied to the current controller/the current controller is pre-controlled using adaptation elements directly as additive reference variable (enabled via p1496).

The torque setpoint (mv) is calculated from:


$$mv = p1496 \times J \times (d\omega/dt) = p1496 \times p0341 \times p0342 \times (d\omega/dt), \omega = 2\pi f$$

The motor moment of inertia p0341 is calculated when commissioning the drive system. The factor p0342 between the total moment of inertia J and the motor moment of inertia must be determined manually or by optimizing the speed controller.

Note

When speed controller optimization is carried out, the ratio between the total moment of inertia and that of the motor (p0342) is determined and acceleration pre-control scaling (p1496) is set to 100 %.

If p1400.2 = p1400.3 = 0, then the pre-control balancing is automatically set.



- 1) only effective if p1400.2 = 1
- 2) only effective if p1400.2 = 0

Figure 7-15 Speed controller with pre-control

When correctly adapted, when accelerating, the speed controller only has to compensate disturbance variables in its control loop. This is achieved with a relatively minor controlled variable change at the controller output.

The effect of the pre-control variable can be adapted according to the application using the weighting factor p1496. For p1496 = 100%, pre-control is calculated according to the motor and load moment of inertia (p0341, p0342). A balancing filter is used automatically to prevent the speed controller acting against the injected torque setpoint. The time constant of the balancing filter corresponds to the equivalent delay time of the speed control loop. Speed controller pre-control is correctly set (p1496 = 100%, calibration using p0342) if the I component of the speed controller (r1482) does not change while ramping-up or ramping-down in the range $n > 20\% \times p0310$. Thus, pre-control allows a new speed setpoint to be approached without overshoot (prerequisite: torque limiting does switch in and the moment of inertia remains constant).

If the speed controller is pre-controlled by means of injection, the speed setpoint (r0062) is delayed with the same smoothing time (p1442 or p1452) as the actual value (r1445). This ensures that no target/actual difference (r0064) occurs at the controller input during acceleration, which would be attributable solely to the signal propagation time.

When speed pre-control is activated, the speed setpoint must be specified continuously or without a higher interference level (avoids sudden torque changes). An appropriate signal can be generated by smoothing the speed setpoint or activating ramp-function generator rounding p1130 – p1131.

The startup time r0345 ($T_{startup}$) is a measure for the total moment of inertia J of the machine and describes the time during which the unloaded drive can be accelerated with the rated motor torque r0333 ($M_{mot, rated}$) from standstill to the rated motor speed p0311 ($n_{mot, rated}$).

$$r0345 = T_{startup} = J \times (2 \times \pi \times n_{mot, rated}) / (60 \times M_{mot, rated}) = p0341 \times p0342 \times (2 \times \pi \times p0311) / (60 \times r0333)$$

The ramp-up and ramp-down times should always be set to values larger than the startup time.

Note

The ramp-up and ramp-down times (p1120; p1121) of the ramp-function generator in the setpoint channel should be set accordingly so that the motor speed can track the setpoint during acceleration and braking. This will optimize the function of speed controller pre-control.

Acceleration pre-control using a connector input (p1495) is activated by the parameter settings p1400.2 = 1 and p1400.3 = 0. p1428 (dead time) and p1429 (time constant) can be set for balancing purposes.

Function diagram

FP 6031 Pre-control balancing reference/acceleration model

7.4 Vector speed/torque control with/without encoder

Parameter

- p0311 Rated motor speed
- r0333 Rated motor torque
- p0341 Motor moment of inertia
- p0342 Ratio between the total and motor moment of inertia
- r0345 Rated motor startup time
- p1400.2 Acceleration pre-control source
- p1428 Speed pre-control balancing dead time
- p1429 Speed pre-control balancing time constant
- p1496 Acceleration pre-control scaling
- r1518 Acceleration torque

7.4.3.2 Reference model

Description

The reference model becomes operative when p1400.3 = 1 and p1400.2 = 0.

The reference model is used to emulate the speed control loop with a P speed controller.

The loop emulation can be set in p1433 to p1435. It becomes effective if p1437 is connected to the output of the model r1436.

The reference model delays the setpoint-actual value deviation for the integral component of the speed controller so that settling (stabilizing) operations can be suppressed.

The reference model can also be externally emulated and the external signal entered via p1437.




Figure 7-16 Reference model

Function diagram

FP 6031 Pre-control balancing reference/acceleration model

Parameters

- p1400.3 Reference model speed setpoint I component
- p1433 Speed controller reference model natural frequency
- p1434 Speed controller reference model damping
- p1435 Speed controller reference model dead time
- r1436 Speed controller reference model speed setpoint output
- p1437 Speed controller reference model I component input

7.4 Vector speed/torque control with/without encoder

7.4.3.3 Speed controller adaptation

Description

Two adaptation methods are available, namely free Kp_n adaptation and speed-dependent Kp_n/Tn_n adaptation.

Free Kp_n adaptation is also active in "operation without encoder" mode and is used in "operation with encoder" mode as an additional factor for speed-dependent Kp_n adaptation.

Speed-dependent Kp_n/Tn_n adaptation is only active in "operation with encoder" mode and also affects the Tn_n value.




Figure 7-17 Free Kp adaptation

A dynamic response reduction in the field-weakening range can be activated in encoderless operation (p1400.0). This is activated when the speed controller is optimized in order to achieve a greater dynamic response in the base speed range.

Example of speed-dependent adaptation

Note

This type of adaptation is only active in "operation with encoder" mode.




Figure 7-18 Example of speed-dependent adaptation

Function diagram

FP 6050 Kp_n-/Tn_n adaptation

Parameters

- p1400.5 Speed control configuration: Kp/Tn adaptation active
- Free Kp_n adaptation
- p1455 Speed controller P gain adaptation signal
 - p1456 Speed controller P gain adaptation lower starting point
 - p1457 Speed amplifier P gain adaptation upper starting point
 - p1458 Adaptation factor lower
 - p1459 Adaptation factor upper
 - p1470 Speed controller encoderless operation P gain
- Speed-dependent Kp_n-/Tn_n adaptation (VC only)
- p1460 Speed controller P gain adaptation speed lower
 - p1461 Speed controller P gain adaptation speed upper
 - p1462 Speed controller integral time adaptation speed lower
 - p1463 Speed controller integral time adaptation speed upper
 - p1464 Speed controller adaptation speed lower
 - p1465 Speed controller adaptation speed upper
 - p1466 Speed controller P gain scaling
- Dynamic response reduction field weakening (encoderless VC only)
- p1400.0 Speed control configuration: Automatic Kp/Tn adaptation active

7.4 Vector speed/torque control with/without encoder

7.4.3.4 Droop Function

Description

Droop (enabled via p1492) ensures that the speed setpoint is reduced proportionally as the load torque increases.

The droop function has a torque limiting effect on a drive that is mechanically coupled to a different speed (e.g. guide roller on a goods train). In this way, a very effective load distribution can also be realized in connection with the torque setpoint of a leading speed-controlled drive. In contrast to torque control or load distribution with overriding and limitation, with the appropriate setting, such a load distribution controls even a smooth mechanical connection.

This method is only suitable to a limited extent for drives that are accelerated and braked with significant changes in speed.

The droop feedback is used, for example, in applications in which two or more motors are connected mechanically or operate with a common shaft and fulfill the above requirements. It limits the torque differences that can occur as a result of the mechanical connection between the motors by modifying the speeds of the individual motors (drive is relieved when the torque becomes too great).




Figure 7-19 Speed controller with droop

Requirement

- All connected drives must be operated with vector and speed control (with or without speed actual value encoder).
- The setpoints at the ramp function generators of the mechanically connected drives must be identical; the ramp function generators must have identical ramp-up and ramp-down times.

Function diagram

FP 6030 Speed setpoint, droop

Parameter

- r0079 Total speed setpoint
- r1482 Speed controller I torque output
- p1488 Droop input source
- p1489 Droop feedback scaling
- r1490 Droop feedback speed reduction
- p1492 Droop feedback enable
- r1508 Torque setpoint before supplementary torque

7.4.3.5 Open actual speed value

Description

The signal source for the open actual speed value of the speed controller is specified via parameter p1440 (CI: speed controller actual speed value). The unsmoothed actual speed value r0063[0] has been preset as the signal source in the factory.

Depending on the machine, parameter p1440 can be used, for example, to switch on a filter in the actual value channel or feed in an external actual speed value.

Parameter r1443 is used to display the actual speed value present at p1440.

Note

When infeeding an external actual speed value, care should be taken that the monitoring functions continue to be derived from the motor model.

Behavior for speed control with an encoder (p1300 = 21)

A motor encoder must always be available for the speed or position signal of the motor model (e.g. evaluation via SMC, see p0400). The actual speed of the motor (r0061) and the position information for synchronous motors still come from this motor encoder and are not influenced by the setting in p1440.

Interconnection of p1440:

When interconnecting connector input p1440 with an external actual speed value, take care that the scaling of the speed is the same (p2000).

The external speed signal should correspond to the average speed of the motor encoder (r0061).

7.4 Vector speed/torque control with/without encoder

Behavior for speed control without an encoder (p1300 = 20)

Depending on the transmission route of the external speed signal, dead times occur which must be taken into account in the parameterization of the speed controller (p1470, p1472) and correspondingly may lead to dynamic losses.

For this reason, the signal transmission times must be kept as small as possible.

p1750.2 = 1 should be set so that the speed controller is also able to work at standstill (closed-loop controlled operation to zero frequency for passive loads). Otherwise, at low speeds it switches over to speed-controlled operation, so that the speed controller is switched off and the measured actual speed no longer has an influence.

Monitoring of the speed deviation between motor model and external speed

The external actual speed (r1443) is compared with the actual speed of the motor model (r2169). Should the deviation be larger than the tolerance threshold set in p3236, after the switch-off delay time in p3238 has expired the fault F07937 (Drive: Speed deviation motor model to external speed) is generated and the drive is switched off according to the reaction set (factory setting: OFF2).




Figure 7-20 Monitoring "Speed deviation model / external in tolerance"

Function diagram

| | |
|---------|--|
| FP 6040 | Vector control – speed controller with/without encoder |
| FP 8012 | Signals and monitoring function – Torque messages, motor blocked/stalled |

Parameters

- r0063[0] Actual speed value unsmoothed
- p1440 CI: Speed controller actual speed value
- p1443 CO: Actual speed value at speed controller actual speed value input
- r2169 CO: Actual speed value smoothed messages
- r2199.7 Speed deviation model / external in tolerance
- p3236 Speed threshold 7
- p3237 Hysteresis speed 7
- p3238 Switch-off delay $n_{act_motor\ model} = n_{act_external}$

7.4.4 Closed-loop torque control

Description

For sensorless closed-loop speed control (p1300 = 20) or closed-loop speed control with encoder VC (p1300 = 21), it is possible to change over to closed-loop torque control using BICO parameter p1501. It is not possible to change over between closed-loop speed and torque control if closed-loop torque control is directly selected with p1300 = 22 or 23. The torque setpoint and/or supplementary setpoint can be entered using BICO parameter p1503 (CI: torque setpoint) or p1511 (CI: supplementary torque setpoint). The supplementary torque acts both for closed-loop torque as well as for the closed-loop speed control. As a result of this characteristic, a pre-control torque can be implemented for the closed-loop speed control using the supplementary torque setpoint.

Note

For safety reasons, assignments to fixed torque setpoints are currently not possible.

If energy is regenerated and cannot be injected back into the line supply, then a Braking Module with connected braking resistor must be used.




Figure 7-21 Closed-loop speed/torque control

The total of the two torque setpoints is limited in the same way as the speed control torque setpoint. Above the maximum speed (p1082), a speed limiting controller reduces the torque limits in order to prevent the drive from accelerating any further.

7.4 Vector speed/torque control with/without encoder

A "real" closed-loop torque control (with a speed that automatically sets itself) is only possible in the closed-loop control range but not in the open-loop control range of the sensorless closed-loop vector control. In the open-loop controlled range, the torque setpoint changes the setpoint speed via a ramp-up integrator (integrating time $\sim p1499 \times p0341 \times p0342$). This is the reason that sensorless closed-loop torque control close to standstill is only suitable for applications that require an accelerating torque there and no load torque (e.g. traversing drives). Closed-loop torque control with encoder does not have this restriction.

OFF responses

- OFF1 and p1300 = 22, 23
 - Response as for OFF2
- OFF1, p1501 = "1" signal and p1300 \neq 22, 23
 - No separate braking response; the braking response is provided by a drive that specifies the torque.
 - The pulses are inhibited when the brake application time (p1217) expires. Standstill is detected when the speed actual value of the speed threshold (p1226) is undershot or when the monitoring time (p1227) started when speed setpoint \leq speed threshold (p1226) expires.
 - Switching on inhibited is activated.
- OFF2
 - Immediate pulse suppression, the drive coasts to standstill.
 - The motor brake (if parameterized) is closed immediately.
 - Switching on inhibited is activated.
- OFF3
 - Switch to speed-controlled operation
 - n_set = 0 is input immediately to brake the drive along the OFF3 deceleration ramp (p1135).
 - When standstill is detected, the motor brake (if parameterized) is closed.
 - The pulses are inhibited when the motor brake closing time (p1217) has elapsed. Standstill is detected when the speed actual value of the speed threshold (p1226) is undershot or when the monitoring time (p1227) started when speed setpoint \leq speed threshold (p1226) expires.
 - Switching on inhibited is activated.

Function diagram

FP 6060 Torque setpoint

Parameters

- p0341 Motor moment of inertia
- p0342 Ratio between the total and motor moment of inertia
- p1300 Open-loop/closed-loop control mode
- p1499 Accelerating for torque control, scaling
- p1501 Change over between closed-loop speed/torque control
- p1503 Torque setpoint
- p1511 Supplementary torque 1
- p1512 Supplementary torque 1 scaling
- p1513 Supplementary torque 2
- p1514 Supplementary torque 2 scaling
- r1515 Supplementary torque total

7.4 Vector speed/torque control with/without encoder

7.4.5 Torque limiting

Description




Figure 7-22 Torque limiting

The value specifies the maximum permissible torque whereby different limits can be parameterized for motor and regenerative mode.

- p0640 Current limit
- p1520 CO: Torque limit, upper/motoring
- p1521 CO: Torque limit, lower/regenerative
- p1522 CI: Torque limit, upper/motoring
- p1523 CI: Torque limit, lower/regenerative
- p1524 CO: Torque limit, upper/motoring, scaling
- p1525 CO: Torque limit, lower/regenerative scaling
- p1530 Power limit, motoring
- p1531 Power limit, regenerating

The currently active torque limit values are displayed in the following parameters:

- r0067 Maximum drive output current
- r1526 Torque limit, upper/motoring without offset
- r1527 Torque limit, lower/regenerative without offset

All of the following limits act on the torque setpoint – that is either available at the speed controller output for closed-loop speed control or as torque input, for closed-loop torque control. The minimum or the maximum is used for the various limits. This minimum or maximum is cyclically calculated and is displayed in r1538 or r1539.

- r1538 Upper effective torque limit
- r1539 Lower effective torque limit

These cyclical values therefore limit the torque setpoint at the speed controller output/torque input or indicate the instantaneous max. possible torque. If the torque setpoint is limited, then this is displayed using parameter p1407.

- r1407.8 Upper torque limit active
- r1407.9 Lower torque limit active

Function diagram

| | |
|---------|-----------------------------|
| FP 6060 | Torque setpoint |
| FP 6630 | Upper/lower torque limit |
| FP 6640 | Current/power/torque limits |

7.4.6 Permanent-magnet synchronous motors

Description

Permanent-magnet synchronous motors without encoders are supported during operations without encoders.

Typical applications include direct drives with torque motors which are characterized by high torque at low speeds, e.g. Siemens complete torque motors of the 1FW3 series. When these drives are used, gear units and mechanical parts subject to wear can be dispensed with if the application allows this.



WARNING

As soon as the motor starts to rotate, a voltage is generated. When work is carried out on the converter, the motor must be safely disconnected. If this is not possible, the motor must be locked by a holding brake, for example.

Features

- Field weakening of up to approx. 1.2 x rated speed (depending on the supply voltage of the converter and motor data, also see supplementary conditions)
- Capture (only when using a VSM module to record the motor speed and phase angle (option K51))
- Speed and torque control vector
- V/f control for diagnostics vector
- Motor identification
- Speed controller optimization (rotary measurement)

7.4 Vector speed/torque control with/without encoder

Supplementary conditions

- Maximum speed or maximum torque depend on the converter output voltage available and the back EMF of the motor (calculation specifications: EMF must not exceed $U_{rated, converter}$).
- Calculating the maximum speed:

$$n_{max} = n_n \cdot \sqrt{\frac{3}{2} \cdot \frac{U_{DC \text{ link max}} \cdot I_n}{P_n}}$$
- Depending on the terminal voltage and load cycle, the maximum torque can be taken from the motor data sheets / configuration instructions.
- No thermal model is available for the closed-loop control of a permanent-magnet synchronous motor. The motor can only be protected against overheating by using temperature sensors (PTC, KTY). To achieve a high level of torque accuracy, we recommend the use of a temperature sensor (KTY) to measure the motor temperature.

Commissioning

The following sequence is recommended for commissioning:

- Configure the drive

When the drive is being commissioned using STARTER or the AOP30 operator panel, the permanent-magnet synchronous motor must be selected. The motor data specified in the table below must then be entered. Finally, the motor identification routine and speed optimization (p1900) are activated. Encoder adjustment is activated automatically together with the motor identification routine.

- Motor identification (standstill measurement, p1910)
- Speed controller optimization (rotary measurement, p1960)

Motor data for permanent-magnet synchronous motors

Table 7- 2 Motor data type plate

| Parameters | Description | Comment |
|------------|------------------------|---|
| p0304 | Rated motor voltage | If this value is not known, the value "0" can also be entered. Entering the correct value, however, means that the stator leakage inductance (p0356, p0357) can be calculated more accurately. |
| p0305 | Rated motor current | |
| p0307 | Rated motor power | |
| p0310 | Rated motor frequency | |
| p0311 | Rated motor speed | |
| p0314 | Motor pole pair number | If this value is not known, the value "0" can also be entered. |
| p0316 | Motor torque constant | If this value is not known, the value "0" can also be entered. |

7.4 Vector speed/torque control with/without encoder

If the torque constant k_T is not stamped on the rating plate or specified in the data sheet, you can calculate this value from the rated motor data or from the stall current I_0 and stall torque M_0 as follows:

$$k_T = \frac{M_N}{I_N} = \frac{60 \frac{s}{min} \times P_N}{2\pi \times n_N \times I_N} \quad \text{or} \quad k_T = \frac{M_0}{I_0}$$

The optional motor data can be entered if it is known. Otherwise, this data is estimated from the type plate data or determined by means of motor identification or speed controller optimization.

Table 7- 3 Motor data type plate

| Parameters | Description | Comment |
|------------|--|---|
| p0320 | Rated motor short-circuit current | This is used for the field weakening characteristic |
| p0322 | Maximum motor speed | Maximum mechanical speed |
| p0323 | Maximum motor current | De-magnetization protection |
| p0325 | Rotor position identification current, 1st phase | - |
| p0327 | Optional load angle | Optional otherwise leave at 90° |
| p0328 | Reluctance torque constant | - |
| p0329 | Rotor position identification current | - |
| p0341 | Motor moment of inertia | For speed controller pre-control |
| p0344 | Motor weight | - |
| p0350 | Stator resistance, cold | - |
| p0356 | Quadrature axis stator inductance Lq | - |
| p0357 | In-line stator inductance Ld | - |

Short-circuit protection

For short circuits that can occur in the drive converter or in the motor cable, the rotating machine would supply the short-circuit until it comes to a standstill. An output contactor can be used for protection. This should be located as close as possible to the motor. This is particularly necessary if the motor can still be driven by the load when a fault develops. The contactor must be provided with a protective circuit against overvoltage on the motor side so that the motor winding is not damaged as a result of the shutdown.

Control signal r0863.1 (VECTOR) is used to control the contactor via a free digital output; the checkback contact of the contactor is connected to parameter p0864 via a free digital input.

This means that if the drive converter develops a fault with a shutdown response, at the instant in time that the pulses are inhibited, the motor is isolated from the drive converter so that energy is not fed back to the fault location.

Function diagram

- FP 6721 Current control - Id setpoint (PEM, p0300 = 2)
- FP 6724 Current control – field weakening controller (PEM, p0300 = 2)
- FP 6731 Current control - interface to Motor Module (PEM, p0300 = 2)

7.4 Vector speed/torque control with/without encoder


8

Output terminals

8.1 Chapter content

This chapter provides information on:

- Analog outputs
- Digital outputs



Function diagrams

To supplement these operating instructions, the customer DVD contains simplified function diagrams describing the operating principle.

The diagrams are arranged in accordance with the chapters in the operating manual. The page numbers (8xx) describe the functionality in the following chapter.

At certain points in this chapter, reference is made to function diagrams with a 4-digit number. These are stored on the customer DVD in the "SINAMICS G130/G150 List Manual", which provides experienced users with detailed descriptions of all the functions.

8.2 Analog outputs

8.2 Analog outputs

Description

The Customer Terminal Block features two analog outputs for outputting setpoints via current or voltage signals.

Delivery condition:

- AO0: Actual speed value: 0 – 20 mA
- AO1: Actual motor current: 0 – 20 mA

Signal flow diagram




Figure 8-1 Signal flow diagram: analog output 0

Function diagram

FP 1840, TM31 - analog outputs (AO 0 ... AO 1)
FP 9572

Parameters

- p4071 Analog outputs, signal source
- p4073 Analog outputs, smoothing time constant
- r4074 Analog outputs, actual output voltage/current
- p4076 Analog outputs, type
- p4077 Analog outputs, characteristic value x1
- p4078 Analog outputs, characteristic value y1
- p4079 Analog outputs, characteristic value x2
- p4080 Analog outputs, characteristic value y2

8.2.1 List of signals for the analog signals

List of signals for the analog outputs

Table 8- 1 List of signals for the analog outputs

| Signal | Parameters | Unit | Scaling (100 %=...) See table below |
|---|------------|------|--|
| Speed setpoint before the setpoint filter | r0060 | rpm | p2000 |
| Motor speed unsmoothed | r0061 | rpm | p2000 |
| Actual speed smoothed | r0063 | rpm | p2000 |
| Output frequency | r0066 | Hz | Reference frequency |
| Output current | r0068 | Aeff | p2002 |
| DC link voltage | r0070 | V | p2001 |
| Torque setpoint | r0079 | Nm | p2003 |
| Output power | r0082 | kW | r2004 |
| For diagnostic purposes | | | |
| Control deviation | r0064 | rpm | p2000 |
| Modulation depth | r0074 | % | Reference modulation depth |
| Torque-generating current setpoint | r0077 | A | p2002 |
| Torque-generating actual current | r0078 | A | p2002 |
| Flux setpoint | r0083 | % | Reference flux |
| Actual flux | r0084 | % | Reference flux |
| For further diagnostic purposes | | | |
| Speed controller output | r1480 | Nm | p2003 |
| I component of speed controller | r1482 | Nm | p2003 |


Scaling

Table 8- 2 Scaling


| Size | Scaling parameter | Default for quick commissioning |
|----------------------------|---|----------------------------------|
| Reference speed | 100 % = p2000 | p2000 = Maximum speed (p1082) |
| Reference voltage | 100 % = p2001 | p2001 = 1000 V |
| Reference current | 100 % = p2002 | p2002 = Current limit (p0640) |
| Reference torque | 100 % = p2003 | p2003 = 2 x rated motor torque |
| Reference power | 100 % = r2004 | r2004 = (p2003 x p2000 x π) / 30 |
| Reference frequency | 100 % = p2000/60 | |
| Reference modulation depth | 100 % = Maximum output voltage without overload | |
| Reference flux | 100 % = Rated motor flux | |
| Reference temperature | 100% = 100°C | |

8.2 Analog outputs

Example: changing analog output 0 from current to voltage output -10 V ... +10 V



Example: changing analog output 0 from current to voltage output -10 V ... +10 V and setting the characteristic



8.3 Digital outputs

Description

Four bi-directional digital outputs (terminal X541) and two relay outputs (terminal X542) are available. These outputs are, for the most part, freely parameterizable.

Signal flow diagram




Figure 8-2 Signal flow diagram: Digital outputs

Delivery condition

Table 8- 3 Digital outputs, delivery condition

| Digital output | Terminal | Delivery condition |
|----------------|-----------|--------------------|
| DO0 | X542: 2.3 | "Enable pulses" |
| DO1 | X542: 5.6 | "No fault" |
| DI/DO8 | X541: 2 | "Ready to start" |
| DI/DO9 | X541: 3 | |
| DI/DO10 | X541: 4 | |
| DI/DO11 | X541: 5 | |

8.3 Digital outputs

Selection of possible connections for the digital outputs

Table 8- 4 Selection of possible connections for the digital outputs

| Signal | Bit in status word 1 | Parameters |
|---|----------------------|------------|
| 1 = Ready to start | 0 | r0889.0 |
| 1 = Ready to operate (DC link loaded, pulses blocked) | 1 | r0889.1 |
| 1 = Operation enabled (drive follows n_set) | 2 | r0889.2 |
| 1 = Fault present | 3 | r2139.3 |
| 0 = Coast to stop active (OFF2) | 4 | r0889.4 |
| 0 = Fast stop active (OFF3) | 5 | r0889.5 |
| 1 = Power-on disable | 6 | r0889.6 |
| 1 = Alarm present | 7 | r2139.7 |
| 1 = Speed setpoint/actual deviation in the tolerance bandwidth (p2163, p2166) | 8 | r2197.7 |
| 1 = Control required to PLC | 9 | r0899.9 |
| 1 = f or n comparison value reached or exceeded (p2141, p2142) | 10 | r2199.1 |
| 1 = I, M, or P limit reached (p0640, p1520, p1521) | 11 | r1407.7 |
| Reserved | 12 | |
| 0 = Alarm motor overtemperature (A7910) | 13 | r2129.14 |
| Reserved | 14 | |
| 0 = Alarm thermal overload in power unit (A5000) | 15 | r2129.15 |
| | | |
| 1 = Pulses enabled (inverter is clocking, drive is carrying current) | | r0899.11 |
| 1 = n_act ≤ p2155 | | r2197.1 |
| 1 = n_act > p2155 | | r2197.2 |
| 1 = Ramp-up/ramp-down completed | | r2199.5 |
| 1 = n_act < p2161 (preferably as n_min or n=0 message) | | r2199.0 |
| 1 = Torque setpoint < p2174 | | r2198.10 |
| 1 = LOCAL mode active (control via operator panel or control panel) | | r0807.0 |
| 0 = Motor blocked | | r2198.6 |


9

Functions, Monitoring, and Protective Functions

9.1 Chapter content

This chapter provides information on:

- Drive functions:
Motor identification, Vdc control, automatic restart, flying restart, motor changeover, friction characteristic, increase in the output frequency, runtime, simulation operation, direction reversal, unit changeover
- Extended functions:
Technology controller, bypass function, extended brake control, extended monitoring functions
- Monitoring and protective functions:
Power unit protection, thermal monitoring functions and overload responses, blocking protection, stall protection, thermal motor protection.



Function diagrams

To supplement these operating instructions, the customer DVD contains simplified function diagrams describing the operating principle.

The diagrams are arranged in accordance with the chapters in the operating instructions. The page numbers (9xx) describe the functionality in the following chapter.

At certain points in this chapter, reference is made to function diagrams with a 4-digit number. These are stored on the customer DVD in the "SINAMICS G130/G150 List Manual", which provides experienced users with detailed descriptions of all the functions.

9.2 Drive Functions

9.2.1 Motor identification and automatic speed controller optimization

Description

Two motor identification options, which are based on each other, are available:

- Standstill measurement with p1910 (motor identification)
- Rotating measurement with p1960 (speed controller optimization)

These can be selected more easily via p1900. p1900 = 2 selects the standstill measurement (motor not rotating). p1900 = 1 also activates the rotating measurement; setting p1910 = 1 and p1960 depending on the current control type (p1300).

Parameter p1960 is set depending on p1300 as follows:


- p1960 = 1, if p1300 = 20 or 22 (encoderless control)
- p1960 = 2, if p1300 = 21 or 23 (control with encoder)

The measurements parameterized using p1900 are started in the following sequence after the corresponding drive has been enabled:

- Standstill (static) measurement - after the measurement has been completed, the pulses are inhibited and parameter p1910 is reset to 0.
- Encoder adjustment - after the measurement has been completed, the pulses are inhibited and parameter p1990 is reset to 0.
- Rotating measurement - after the measurement has been completed, the pulses are inhibited and parameter p1960 is reset to 0.
- After all of the measurements activated using p1900 have been successfully completed, p1900 itself is set to 0.

Note

To set the new controller setting permanently, the data must be saved with p0977 or p0971 in a non-volatile memory.

| |
|--|
|  DANGER |
| <p>During motor identification, the drive might set the motor in motion.</p> <p>The EMERGENCY OFF functions must be fully operational during commissioning. To protect the machines and personnel, the relevant safety regulations must be observed.</p> |

9.2.1.1 Standstill measurement

Description

Motor identification with p1910 is used for determining the motor parameters at standstill (see also p1960: speed controller optimization):

- Equivalent circuit diagram data p1910 = 1
- Magnetization characteristic p1910 = 3

For control engineering reasons, you are strongly advised to carry out motor identification because the equivalent circuit diagram data, motor cable resistance, IGBT on-state voltage, and compensation for the IGBT lockout time can only be estimated if the data on the type plate is used. For this reason, the stator resistance for the stability of sensorless vector control or for the voltage boost with the V/f characteristic is very important.

Motor identification is essential if long supply cables or third-party motors are used. When motor data identification is started for the first time, the following data is determined with p1910 = 1 on the basis of the data on the type plate (rated data):

Table 9- 1 Data determined using p1910

| | Induction motor | Permanent-magnet synchronous motor |
|-----------|---|--|
| p1910 = 1 | <ul style="list-style-type: none"> • Stator resistance (p0350) • Rotor resistance (p0354) • Stator leakage inductance (p0356) • Rotor leakage inductance (p0358) • Magnetizing inductance (p0360) • Drive converter valve threshold voltage (p1825) • Converter valve interlocking times (p1828 ... p1830) | <ul style="list-style-type: none"> • Stator resistance (p0350) • Stator resistance q axis (p0356) • Stator inductance d axis (p0357) • Drive converter valve threshold voltage (p1825) • Converter valve interlocking times (p1828 ... p1830) |
| p1910 = 3 | <ul style="list-style-type: none"> • Saturation characteristics (p0362 ... p0366) | <p>not recommended</p> <p>Notice: When encoder adjustment is complete, the motor is automatically rotated approx. one revolution in order to determine the zero marker of the encoder.</p> |

Since the type plate data provides the initialization values for identification, you must ensure that it is entered correctly and consistently (taking into account the connection type (star/delta)) so that the above data can be determined.

9.2 Drive Functions

It is advisable to enter the motor supply cable resistance (p0352) before the standstill measurement (p1910) is performed, so that it can be subtracted from the total measured resistance when the stator resistance is calculated (p0350).

Entering the cable resistance improves the accuracy of thermal resistance adaptation, particularly when long supply cables are used. This governs behavior at low speeds, particularly during encoderless vector control.




Figure 9-1 Equivalent circuit diagram for induction motor and cable

If an output filter (see p0230) or series inductance (p0353) is used, its data must also be entered before the standstill measurement is carried out.

The inductance value is then subtracted from the total measured value of the leakage. With sine-wave filters, only the stator resistance, valve threshold voltage, and valve interlocking time are measured.

Note

Leakage values in excess of 35 to 40% of the rated motor impedance will restrict the dynamic response of speed and current control in the voltage limit range and in field-weakening operation.

Note

Standstill measurement must be carried out when the motor is cold. In p0625, enter the estimated ambient temperature of the motor during the measurement (with KTY sensor: set p0600, p0601 and read r0035). This is the reference point for the thermal motor model and thermal R_S/R_R adaptation.

In addition to the equivalent circuit diagram data, motor data identification (p1910 = 3) can be used for induction motors to determine the magnetization characteristic of the motor. Due to the higher accuracy, the magnetization characteristic should, if possible, be determined during rotating measurement (without encoder: p1960 = 1, 3; with encoder: p1960 = 2, 4). If the drive is operated in the field-weakening range, this characteristic should be determined for vector control in particular. The magnetization characteristic can be used to calculate the field-generating current in the field-weakening range more accurately, thereby increasing torque accuracy.

Note

In comparison with standstill measurement (p1910) for induction motors, rotating measurement (p1960) allows the rated magnetization current and saturation characteristic to be determined more accurately.




Figure 9-2 Magnetization characteristic

Carrying out motor identification

- Enter p1910 > 0. Alarm A07991 is displayed.
- Identification starts when the motor is switched on.
- p1910 resets itself to "0" (successful identification) or fault F07990 is output.
- r0047 displays the current status of the measurement.

Note

To set the new controller setting permanently, the data must be saved with p0977 or p0971 in a non-volatile memory.

WARNING

During motor identification, the drive might set the motor in motion.

The EMERGENCY OFF functions must be fully operational during commissioning. To protect the machines and personnel, the relevant safety regulations must be observed.

9.2 Drive Functions

9.2.1.2 Rotating measurement and speed controller optimization

Description

"Rotating measurement" can be activated via p1960 or p1900 = 1.

The main difference between rotating measurement and standstill measurement is speed control optimization, with which the drive's moment of inertia is ascertained and speed controller is set. On induction motors, the saturation characteristic and rated magnetization current are also measured.

If rotating measurement is not to be carried out at the speed set in p1965, this parameter can be changed before the measurement is started. Higher speeds are recommended.

The same applies to the speed in p1961, at which the saturation characteristic is determined and the encoder test is carried out.

The speed controller is set to the symmetrical optimum in accordance with dynamic factor p1967. p1967 must be set before the optimization run and only affects the calculation of the controller parameters.

If, during the measurement, it becomes clear that the the drive cannot operate in a stable manner with the specified dynamic factor or that the torque ripples are too great, the dynamic response is reduced automatically and the result displayed in r1968. The drive must also be checked to ensure that it is stable across the entire range. The dynamic response might need to be reduced or Kp/Tn adaptation for the speed controller parameterized accordingly.

When commissioning induction machines, you are advised to proceed as follows:

- Before connecting the load, a complete "rotating measurement" (without encoder: p1960 = 1; with encoder: p1960 = 2) should be carried out. Since the induction machine is idling, you can expect highly accurate results for the saturation characteristic and the rated magnetization current.
- When the load is connected, speed controller optimization should be repeated because the total moment of inertia has changed. This is realized by selecting parameter p1960 (without encoder: p1960 = 3; with encoder: p1960 = 4).
During the speed optimization, the saturation characteristic recording is automatically deactivated in parameter p1959.

When permanent-magnet synchronous motors are commissioned, the speed controller should be optimized (p1960 = 2/4) when the load is connected.

Carrying out the rotating measurement (p1960 = 1, 2)

The following measurements are carried out when the enable signals are set and a switch-on command is issued in accordance with the settings in p1959 and p1960.

- Encoder test
If a speed encoder is used, the direction of rotation and the pulse number are checked.
- Only for induction motors:
 - Measurement of the magnetization characteristic (p0362 to p0369)
 - Measurement of the magnetization current (p0320) and determination of the offset voltage of the converter for offset compensation
 - Measurement of the saturation of the leakage inductance and setting of the current controller adaptation (p0391...p0393)
This is automatically activated with 1LA1 and 1LA8 motors (p0300 = 11, 18) (see p1959.5).
- Speed controller optimization
 - p1470 and p1472, if p1960 = 1 (encoderless operation)
 - p1460 and p1462, if p1960 = 2 (operation with encoder)
 - Kp adaptation switch-off
- Acceleration pre-control setting (p1496)
- Setting for ratio between the total moment of inertia and that of the motor (p0342)

Note

To set the new controller setting permanently, the data must be saved with p0977 or p0971 in a non-volatile memory.

| |
|---|
|  DANGER |
|---|

| |
|---|
| During speed controller optimization, the drive triggers movements in the motor that can reach the maximum motor speed. |
|---|

| |
|--|
| The EMERGENCY OFF functions must be fully operational during commissioning. To protect the machines and personnel, the relevant safety regulations must be observed. |
|--|

Note

If speed controller optimization is carried out for operation with an encoder, the control mode will be changed over to encoderless speed control automatically, in order to be able to carry out the encoder test.

9.2 Drive Functions

Parameters

- r0047 Status identification
- p1300 Open-loop/closed-loop control operating mode
- p1900 Motor data identification and rotating measurement
- p1959 Speed controller optimization configuration
- p1960 Speed controller optimization selection
- p1961 Saturation characteristic speed to determine
- p1965 Speed controller optimization speed
- p1967 Speed controller optimization dynamic factor
- r1968 Speed controller optimization actual dynamic factor
- r1969 Speed controller optimization inertia identified
- r1973 Speed controller optimization encoder test pulse number determined
- p1980 Pole position identification procedure
- r3925 Identification complete indicator
- r3927 MotId control word
- r3928 Rotating measurement configuration

9.2.2 Efficiency optimization

Description

The following can be achieved when optimizing efficiency using p1580:

- Lower motor losses in the partial load range
- Minimization of noise in the motor




Figure 9-3 Efficiency optimization

It only makes sense to activate this function if the dynamic response requirements of the speed controller are low (e.g. pump and fan applications).

For p1580 = 100%, the flux in the motor under no-load operating conditions is reduced to half of the setpoint (reference flux) ($p1570/2$). As soon as load is connected to the drive, the setpoint (reference) flux increases linearly with the load and, reaching the setpoint set in p1570 at approx. $r0077 = r0331 \times p1570$.

In the field-weakening range, the final value is reduced by the actual degree of field weakening. The smoothing time (p1582) should be set to approx. 100 to 200 ms. Flux differentiation (see also p1401.1) is automatically deactivated internally following magnetization.

Function diagram

- | | |
|---------|---|
| FP 6722 | Field weakening characteristic, Id setpoint (ASM, p0300 = 1) |
| FP 6723 | Field weakening controller, flux controller for induction motor (p0300 = 1) |

Parameters

- r0077 Current setpoints, torque-generating
- r0331 Motor magnetizing current/short-circuit current (actual)
- p1570 Flux setpoint
- p1580 Efficiency optimization

9.2.3 Fast magnetization for induction motors

Description

Fast magnetization for induction motors is used to reduce delay time during magnetization.

Features

- Rapid flux build-up by impressing a field-producing current at the current limit, which considerably reduces the magnetization time.
- If the "Flying restart" function is activated, the excitation build-up time set in p0346 is still used.

Commissioning

Parameter setting p1401.6 = 1 is necessary to activate fast magnetization.

This setting initiates the following sequence during motor starting:

- The field-producing current setpoint jumps to its limit value: $0.9 \cdot r0067$ (I_{max}).
- The flux increases as fast as physically possible with the specified current.
- The flux setpoint r0083 is made to follow accordingly.
- As soon as the flux threshold value, set via p1573, is reached (default value 100%, min. 10% and max. 200%), the excitation is finished and the speed setpoint enabled. The flux threshold value must not be set too low for a large load because the torque-producing current is limited during magnetization.

Note

The flux threshold value set in parameter p1573 is effective only if the actual flux during magnetization reaches the value programmed in p1573 before the timer set in p0346 runs down.

- The flux is increased further until the flux setpoint in p1570 has been reached.
- The field-producing current setpoint is reduced by means of a flux controller with P gain (p1590) and the parameterized smoothing factor (p1616).

Notes

When quick magnetization is selected (p1401.6 = 1), smooth starting is deactivated internally and alarm A07416 displayed.

When the stator resistance identification function is active (see p0621 "Identification of stator resistance after restart") is active, quick magnetization is deactivated internally and alarm A07416 displayed.

The parameter does not work when combined with the "flying restart" function (see p1200), i.e. flying restart is performed without quick magnetization.

Function diagram

| | |
|---------|--|
| FP 6491 | Flux control configuration |
| FP 6722 | Field weakening characteristic, Id setpoint (ASM, p0300 = 1) |
| FP 6723 | Field weakening controller, flux controller (ASM, p0300 = 1) |

Parameters

- p0320 Motor rated magnetization current/short-circuit current
- p0346 Motor excitation build-up time
- p0621 Stator resistance identification after restart
- p0640 Current limit
- p1401 Flux control configuration
- p1570 Flux setpoint
- p1573 Flux threshold value magnetization
- p1590 Flux controller P gain
- p1616 Current setpoint smoothing time

9.2.4 Vdc control

Description

The “Vdc control” function can be activated using the appropriate measures if an overvoltage or undervoltage is present in the DC link.

- Overvoltage in the DC link
 - Typical cause:
The drive is operating in regenerative mode and is supplying too much energy to the DC link.
 - Remedy:
Reduce the regenerative torque to maintain the DC link voltage within permissible limits.

Note

When switching off or during rapid load changes, if failure often arises and fault F30002 "DC link overvoltage" is reported, you may be able to improve the situation by increasing the gain factor for the Vdc controller p1250 (p1290), e.g. from "1.00" to "2.00".

- Undervoltage in the DC link
 - Typical cause:
Failure of the supply voltage or supply for the DC link.
 - Remedy:
Specify a regenerative torque for the rotating drive to compensate the existing losses, thereby stabilizing the voltage in the DC link. This process is known as kinetic buffering.
Kinetic buffering is only possible as long as energy is generated by the movement of the drive.

Characteristics

- Vdc control
 - This comprises Vdc_max control and Vdc_min control (kinetic buffering), which are independent of each other.
 - It contains a joint PI controller. The dynamic factor is used to set Vdc_min and Vdc_max control independently of each other.
- Vdc_min control (kinetic buffering)
 - With this function, the kinetic energy of the motor is used for buffering the DC link voltage in the event of a momentary power failure, thereby delaying the drive.
- Vdc_max control
 - This function can be used to control momentary regenerative load without shutdown using "overvoltage in the DC link".
 - Vdc_max control is only recommended for a supply without active closed-loop control for the DC link and without feedback.

Description of Vdc_min control (kinetic buffering)




Figure 9-4 Switching Vdc_min control on/off (kinetic buffering)

Note

Kinetic buffering must only be activated in version A in conjunction with an external power supply.

When Vdc_min control is enabled with p1240 = 2.3 (p1280), it is activated if the power fails when the Vdc_min switch-in level (r1246 (r1286)) is undershot. In general, the regenerative power (braking energy) of the drive machine generated when the motor speed is reduced is used to buffer the DC link voltage of the converter; in other words, when Vdc_min control is active, the motor speed no longer follows the main setpoint and can be reduced to zero. The SINAMICS system continues operating until the shutdown threshold of the DC link voltage is undershot (see "Switching Vdc_min control on/off" <1>).

Note

All parameter specifications in parentheses refer to V/f control.

9.2 Drive Functions

- V/f control
The Vdc_min controller acts on the speed setpoint channel. When Vdc_min control is active, the drive setpoint speed is reduced so that the drive becomes regenerative.
- Speed control
The Vdc_min controller acts on the speed controller output and affects the torque-generating current setpoint. When Vdc_min control is active, the torque-generating current setpoint is reduced so that the drive becomes regenerative.

If the power fails, the DC link voltage decreases due to the lack of power from the supply system. When the DC link voltage threshold set via parameter p1245 (p1285) is reached, the Vdc_min controller is activated. Due to the PID properties of the controller, the motor speed is reduced to the extent that the regenerative drive energy maintains the DC link voltage at the level set in p1245 (p1285). The kinetic energy of the drive governs the dropout characteristic of the motor speed and, in turn, the buffering duration. In centrifugal mass drives (e.g. fans), buffering can last a few seconds. In drives with a low centrifugal mass (e.g. pumps), however, buffering can last just 100 – 200 ms. When the power is restored, the Vdc_min controller is deactivated and the drive is ramped up to its setpoint speed at the ramp-function generator ramp. An alarm A7402 (drive: DC link voltage minimum controller active) will be issued while the Vdc_min controller is active.

If the drive can no longer generate any regenerative energy (because, for example, it is almost at a standstill), the DC link voltage continues to drop. If the minimum DC link voltage is undershot (see "Switching Vdc_min control on/off" <1>), the drive will shut down with fault F30003 (power unit: DC link undervoltage).

If, during active Vdc_min control, a speed threshold set with parameter p1257 (p1297) (see "Switching Vdc_min control on/off" <2>) is undershot, the drive will shut down with F7405 (drive: kinetic buffering minimum speed not reached).

If a shutdown with undervoltage in the DC link (F30003) occurs without the drive coming to a standstill despite the fact that Vdc_min control is active, the controller may have to be optimized via dynamic factor p1247 (p1287). Increasing the dynamic factor in p1247 (p1287) causes the controller to intervene more quickly. The default setting for this parameter, however, should be sufficient for most applications.

Parameter p1256 = 1 (p1296) can be used to activate time monitoring for kinetic buffering. The monitoring time can be set in parameter p1255 (p1295). If buffering (i.e., the power failure) lasts longer than the time set here, the drive will shut down with fault F7406 (drive: kinetic buffering maximum time exceeded). The standard fault reaction for this fault is OFF3, which means that this function can be used for controlled drive deceleration in the event of a power failure. In this case, excess regenerative energy can only be dissipated via an additional braking resistor.

Description of Vdc_max control




Figure 9-5 Activating/deactivating the Vdc_max control

The switch-on level of the Vdc_max control (r1242 or r1282) is calculated as follows:

- when the automatic switch-on level sensing is disabled (p1254 (p1294) = 0)
 - ACAC device: $r1242 (r1282) = 1.15 \times \sqrt{2} \times p0210$ (device supply voltage)
 - DCAC device: $r1242 (r1282) = 1.15 \times p0210$ (device supply voltage)
- when the automatic switch-on level sensing is enabled (p1254 (p1294) = 1)
 - $r1242 (r1282) = V_{dc_max} - 50 \text{ V}$ (V_{dc_max} : overvoltage threshold of the converter)

Function diagram

FP 6220 (FP 6320) Vdc_max controller and Vdc_min controller

9.2 Drive Functions

Parameters

- p1240 (p1280) Vdc controller configuration
- r1242 (r1282) Vdc_min controller switch-in level
- p1243 (p1283) Vdc_max controller dynamic factor
- p1245 (p1285) Vdc_min controller switch-in level
- r1246 (r1286) Vdc_min controller switch-in level
- p1247 (p1287) Vdc_min controller dynamic factor
- (p1288) Vdc_max controller ramp-function generator feedback factor (V/f)
- p1249 (p1289) Vdc_max controller speed threshold
- p1250 (p1290) Vdc controller proportional gain
- p1251 (p1291) Vdc controller integral action time
- p1252 (p1292) Vdc controller derivative-action time
- (p1293) Vdc_min controller output limit (V/f)
- p1254 (p1294) Vdc_max controller automatic ON level detection
- p1255 (p1295) Vdc_min controller time threshold
- p1256 (p1296) Vdc_min controller response
- p1257 (p1297) Vdc_min controller speed threshold
- r1258 (r1298) Vdc controller output

9.2.5 Automatic restart function

Description


The automatic restart function automatically restarts the cabinet unit after an undervoltage or a power failure. The alarms present are acknowledged and the drive is restarted automatically.

The drive can be restarted using:

- The standard procedure starting from standstill, or
- The flying restart function.
For drives with low moments of inertia and load torques facilitating the stopping of the drive within a matter of seconds (e.g., pump drives with water gauges), starting from standstill is recommended.

Note

The flying restart function can also be activated for drives with large moments of inertia (such as fan drives). This enables you to switch to the motor that is still rotating.

| |
|--|
|  WARNING |
| <p>If p1210 is set to values >1, the motor can be restarted automatically without the need to issue the ON command.</p> <p>In the event of prolonged power failures and when the automatic restart function is activated (p1210 > 1), the drive may have been at a standstill for a long time and mistakenly considered to have been switched off.</p> <p>For this reason, entering the area around the drive when it is in this condition can cause death, serious injury, or considerable material damage.</p> |

Automatic restart mode

Table 9- 2 Automatic restart mode

| p1210 | Mode | Meaning |
|-------|--|---|
| 0 | Disables automatic restart | Automatic restart inactive |
| 1 | Acknowledges all faults without restarting | If p1210 = 1, pending faults will be acknowledged automatically once their cause has been rectified. If further faults occur after faults have been acknowledged, these will also be acknowledged automatically. A minimum time of p1212 + 1 s must expire between successful fault acknowledgement and a fault re-occurring if the signal ON/OFF1 (control word 1, bit 0) is at a HIGH signal level. If the ON/OFF1 signal is set to LOW, the time between when a fault is acknowledged and another one occurs must be at least 1 s. If p1210 = 1, fault F07320 will not be generated if the acknowledge attempt fails (e.g., because the faults occurred too frequently). |
| 4 | Automatic restart after power failure, without additional startup attempts | If p1210 = 4, an automatic restart will only be performed if in addition fault F30003 occurs on the Motor Module or there is a high signal at binector input p1208[1], or in the case of an infeed drive object (A_Infeed), F06200 is pending. If additional faults are pending, then these faults will also be acknowledged; if this is successful, the startup attempt will be resumed. The failure of the CU's 24 V power supply will be interpreted as a line supply failure. |
| 6 | Restart after fault with additional startup attempts | If p1210 = 6, an automatic restart will be performed after any fault or at p1208[0] = 1. If the faults occur one after the other, then the number of startup attempts is defined using p1211. Monitoring over time can be set using p1213. |
| 14 | Restart after power failure after manual acknowledgement | As for p1210 = 4. But pending faults must be acknowledged manually. |
| 16 | Restart after fault after manual acknowledgement | As for p1210 = 6. But pending faults must be acknowledged manually. |

Startup attempts (p1211) and waiting time (p1212)

p1211 is used to specify the number of startup attempts. The number is decremented internally after each successful fault acknowledgement (line supply voltage must be restored or the infeed signals that it is ready). Fault F07320 is output when the number of parameterized startup attempts is reached.

If $p1211 = x$, $x + 1$ startup attempts will be made.

Note

A startup attempt starts immediately when the fault occurs.

The faults are acknowledged automatically at intervals of half the waiting time p1212.

Following successful acknowledgement and restoration of the voltage, the system is automatically powered up again.

The startup attempt has been completed successfully once the flying restart and magnetization of the motor (induction motor) has been completed ($r0056.4 = 1$) and one additional second has expired. The startup counter is not reset to the initial value p1211 until this point.

If additional faults occur between successful acknowledgement and the end of the startup attempt, then the startup counter, when it is acknowledged, is also decremented.

Automatic restart monitoring time (p1213)

- p1213[0] = Monitoring time for restart

The monitoring time starts when the faults are detected. If the automatic acknowledgements are not successful, the monitoring time will continue. If the drive has not successfully restarted by the time the monitoring time expires (flying restart and motor magnetization must have been completed: $r0056.4 = 1$), fault F07320 is output. Monitoring is deactivated by setting p1213 = 0.

If p1213 is set to a value lower than the sum of p1212, the magnetization time r0346 and the additional delay time due to flying restart, then fault F07320 will be generated on every restart attempt. If, for p1210 = 1, the time in p1213 is set to a value lower than p1212, then fault F07320 will also be generated on every restart attempt. The monitoring time must be extended if the faults that occur cannot be immediately and successfully acknowledged.

For p1210 = 14, 16 manual acknowledgement of the pending fault must take place within the time in p1213 index 0. Otherwise the fault F07320 is generated after the time set.

- p1213[1] = Monitoring time for resetting the starting counter

The starting counter (see r1214) is only reset to starting value p1211 once the time in p1213 index[1] has expired after a successful restart. The delay time is not effective for error acknowledgment without an automatic restart (p1210 = 1). If the power supply fails (blackout), the wait time only starts once the power has been restored and the Control Unit is ramped up. The starting counter is reset to the starting value p1211, if F07320 occurred, the switch-on command is recalled and the fault acknowledged.

If starting value p1211 or mode p1210 is changed, the starting counter is immediately updated.

Set fault number without automatic restart (p1206)

Up to 10 fault numbers for which the automatic restart should not be effective can be selected via p1206[0...9].

The parameter is only effective if p1210 = 6 and p1210 = 16.

Parameters

- p1206 [0...9] Set fault number without automatic restart
- p1210 Automatic restart mode
- p1211 Automatic restart, start attempts
- p1212 Automatic restart, delay time start attempts
- p1213 Automatic restart monitoring time
- r1214 Automatic restart status

Settings

To prevent the motor from switching to phase opposition when the drive is being restarted, there is a delay while the motor demagnetizes ($t = 2.3 \times$ motor magnetization time constant). Once this time has elapsed, the inverter is enabled and the motor is supplied with power.

9.2.6 Flying restart

Description

The "Flying restart" function (enabled via p1200) allows the converter to switch to a motor that is still rotating. Switching on the converter without the flying restart function would not allow any flux to build up in the motor while it is rotating. Since the motor cannot generate any torque without flux, this can cause it to switch off due to overcurrent (F07801).

The flying restart function first determines the speed of the drive with which V/f or vector control is initialized so that the converter and motor frequency can be synchronized.

During the standard start-up procedure for the converter, the motor must be at a standstill. The converter then accelerates the motor to the setpoint speed. In many cases, however, the motor is not at a standstill.

9.2 Drive Functions

Two different situations are possible here:

1. The drive rotates as a result of external influences, such as water (pump drives) or air (fan drives). In this case, the drive can also rotate against the direction of rotation.
2. The drive rotates as a result of a previous shutdown (e.g. OFF 2 or a power failure). The drive slowly coasts to a standstill as a result of the kinetic energy stored in the drive train (example: induced-draft fan with a high moment of inertia and a steeply descending load characteristic in the lower speed range).

In accordance with the setting chosen (p1200), the flying restart function is activated in the following situations:

- Once power has been restored and the automatic restart function is active
- After a shutdown with the OFF2 command (pulse inhibit) when the automatic restart function is active
- When the ON command is issued.

Note

The flying restart function must be used when the motor may still be running or is being driven by the load to prevent shutdowns due to overcurrent (F7801).

Note

If the value set for parameter p1203 (search speed factor) is higher, the search curve is flatter and, as a result, the search time is longer. A lower value has the opposite effect.

In motors with a low moment of inertia, the flying restart function can cause the drive to accelerate slightly.

In group drives, the flying restart function should not be activated due to the different coasting properties of the individual motors.

9.2.6.1 Flying restart without encoder

Description

Depending on parameter p1200, the flying restart function is started with the maximum search speed $n_{\text{search,max}}$ once the de-excitation time (p0347) has elapsed (see diagram "Flying restart").

$$n_{\text{Search,max}} = 1.25 \times n_{\text{max}} \text{ (p1082)}$$

The flying restart function behaves differently with V/f control and vector control:

- V/f characteristic ($p1300 < 20$):
The search speed yielded from parameter p1203 reduces the search frequency in accordance with the motor current. The parameterizable search current (p1202) is injected here. If the search frequency is similar to the rotor frequency, a current minimum occurs. Once the frequency has been found, the motor is magnetized. The output voltage during the magnetization time (p0346) is increased to the voltage value yielded from the V/f characteristic (see "Flying restart").
- Vector control without encoder:
The motor speed is determined using the speed adaptation control loop for the electric motor model. To begin with, the search current (p1202) is injected and then the controller is activated starting from the maximum search frequency. The dynamic response of the controller can be altered using the search speed factor (p1203). If the deviation of the speed adaptation controller is not too great, the motor continues to be magnetized for the duration parameterized in p0346.

Once the excitation build-up time (p0346) has elapsed, the ramp-function generator is set to the actual speed value and the motor ramped up to the current setpoint frequency.





Figure 9-6 Flying restart

| |
|---|
|  WARNING |
| <p>When the flying restart (p1200) function is active, the drive may still be accelerated by the detection current despite the fact that it is at standstill and the setpoint is 0!</p> <p>For this reason, entering the area around the drive when it is in this condition can cause death, serious injury, or considerable material damage.</p> |

9.2 Drive Functions

9.2.6.2 Flying restart with encoder

Description

The flying restart function behaves differently with V/f control and vector control:

- V/f characteristic (p1300 < 20):
Flying restart without encoder (see "Flying restart without encoder")
- Vector control with encoder:
Since the speed is known from the start, the motor can be magnetized immediately at the appropriate frequency. The duration of magnetization is specified in p0346. Once the excitation build-up time has elapsed, the ramp-function generator is set to the actual speed value and the motor ramped up to the current setpoint speed.

WARNING

When the flying restart (p1200) function is active, the drive may still be accelerated by the detection current despite the fact that it is at standstill and the setpoint is 0.

For this reason, entering the area around the drive when it is in this condition can cause death, serious injury, or considerable material damage.

9.2.6.3 Parameters

- p1200 Flying restart operating mode
 - 0: Flying restart inactive
 - 1: Flying restart always active (start in setpoint direction)
 - 2: Flying restart active after On, error, OFF2 (start in setpoint direction)
 - 3: Flying restart active after error, OFF2 (start in setpoint direction)
 - 4: Flying restart always active (start only in setpoint direction)
 - 5: Flying restart active after On, error, OFF2 (start only in setpoint direction)
 - 6: Flying restart active after error, OFF2 (start only in setpoint direction)
- p1202 Flying restart search current
- p1203 Flying restart search speed factor
- r1204 Flying restart, V/f control status
- r1205 Flying restart, vector control status

Note

For p1200 = 1, 2, 3, the following applies: Search in both directions, start only in the setpoint direction.

For p1200 = 4, 5, 6, the following applies: Search only in the setpoint direction.

9.2.7 Motor changeover/selection

9.2.7.1 Description

The motor data set changeover is, for example, used for:

- Changing over between different motors
- Motor data adaptation

Note

To switch to a rotating motor, the "flying restart" function must be activated.

9.2.7.2 Example of changing over between two motors

Prerequisites

- The drive has been commissioned for the first time.
- 2 motor data sets (MDS), p0130 = 2
- 2 drive data sets (DDS), p0180 = 2
- 2 digital outputs to control the auxiliary contactors
- 2 digital inputs to monitor the auxiliary contactors
- 1 digital input to select the data set
- 2 auxiliary contactors with auxiliary contacts (1 NO contact)
- 2 motor contactors with positively-driven auxiliary contacts (1 NC contact, 1 NO contact)




Figure 9-7 Example of motor changeover

9.2 Drive Functions

Table 9- 3 Settings for the motor changeover example

| Parameters | Settings | Comment |
|---------------------|---------------------------------------|--|
| p0130 | 2 | Configure 2 MDS |
| p0180 | 2 | Configure 2 DDS |
| p0186[0..1] | 0, 1 | The MDS are assigned to the DDS. |
| p0820 | Digital input, DDS selection | The digital input to change over the motor is selected via the DDS. Binary coding is used (p0820 = bit 0, etc.). |
| p0821 to p0824 | 0 | |
| p0826[0..1] | 1, 2 | Different numbers mean different thermal models. |
| p0827[0..1] | 0, 1 | The bits of r0830 are assigned to the MDSs. If p0827[0] = 0, for example, bit r0830.0 is set via DDS0 when MDS0 is selected. |
| r0830.0 and r0830.1 | Digital outputs, auxiliary contactors | The digital outputs for the auxiliary contactors are assigned to the bits. |
| p0831[0..1] | Digital inputs, auxiliary contacts | The digital inputs for the feedback signal of the motor contactors are assigned. |
| p0833.00 and .01 | 0, 0 | The drive controls the contactor circuit and pulse inhibition. |

Motor changeover sequence

1. Pulse suppression:
The pulses are suppressed following the selection of a new drive data set using p0820 to p0824.
2. Open motor contactor:
Motor contactor 1 is opened (r0830 = 0) and the status bit "Motor changeover active" (r0835.0) is set.
3. Change over drive data set:
The requested data set is activated (r0051 = data set currently effective, r0837 = requested data set).
4. Energize motor contactor:
After the feedback signal (motor contactor opened) from motor contactor 1, the appropriate bit of r0830 is set and motor contactor 2 is energized.
5. Enable pulses:
After the feedback signal (motor contactor closed) from motor contactor 2, the bit "motor data set changeover active" (r0835.0) is reset and the pulses are enabled. The motor has now been changed over.

9.2.7.3 Function diagram

- FP 8565 Drive Data Set (DDS)
FP 8575 Motor Data Sets (MDS)

9.2.7.4 Parameters

- r0051 Drive data set DDS effective
- p0130 Motor data sets (MDS) number
- p0180 Drive data set (DDS) number
- p0186 Motor data sets (MDS) number
- p0819[0...2] Copy drive data set DDS
- p0820 BI: Drive data set selection DDS, bit 0
- p0821 BI: Drive data set selection DDS, bit 1
- p0822 BI: Drive data set selection DDS, bit 2
- p0823 BI: Drive data set selection DDS, bit 3
- p0824 BI: Drive data set selection DDS, bit 4
- p0826 Motor changeover, motor number
- p0827 Motor changeover status word bit number
- p0828 Motor changeover, feedback signal
- r0830 Motor changeover, status
- p0831 Motor changeover, contactor feedback signal
- p0833 Data set changeover configuration

9.2.8 Friction characteristic curve

Description

The friction characteristic is used to compensate for the frictional torque of the motor and driven load. A friction characteristic allows the speed controller to be pre-controlled and improves the control response..

10 points along the characteristic are used for the friction characteristic. The coordinates of every point along the characteristic are defined by a speed parameter (p382x) and a torque parameter (p383x) (point 1 = p3820 and p3830).

Features

- There are 10 points along the characteristic to represent the friction characteristic.
- An automatic function supports the friction characteristic plot.
- A connector output (r3841) can be interconnected as friction torque (p1569).
- The friction characteristic can be activated and de-activated (p3842).

9.2 Drive Functions

Commissioning

Speeds for making measurements as a function of the maximum speed p1082 are pre-assigned in p382x when commissioning the drive system for the first time. These can be appropriately changed corresponding to the actual requirements.

The automatic friction characteristic plot can be activated using p3845. The characteristic is then plotted the next time that it is enabled.

The following settings are possible:

- p3845 = 0 Friction characteristic plot de-activated
- p3845 = 1 Friction characteristic plot activated, all directions
The friction characteristic is plotted in both directions of rotation. The result of the positive and negative measurement is averaged and entered into p383x.
- p3845 = 2 Friction characteristic plot activated, positive direction
- p3845 = 3 Friction characteristic plot activated, negative direction

p3847 (friction characteristic plot warm-up period) can be used to set a time for the drive to warm up to the specified operating temperature. During this time, the drive is brought up to and kept at the greatest speed set for plotting the friction characteristic, so that the drive warms up to the operating temperature. Then measurement is started with the highest speed.

DANGER

When the friction characteristic is plotted, the drive can cause the motor to move. As a result, the motor may reach maximum speed.

When commissioning the drive, the EMERGENCY STOP functions must function perfectly. To protect the machines and personnel, the relevant safety regulations must be observed.

Function diagram

FD 7010 Friction characteristic curve

Parameters

- p3820 Friction characteristic, value n0
- ...
- p3839 Friction characteristic, value M9
- r3840 Friction characteristic status word
- r3841 Friction characteristic, output
- p3842 Activate friction characteristic
- p3845 Activate friction characteristic plot
- p3846 Friction characteristic plot ramp-up/ramp-down time
- p3847 Friction characteristic plot warm-up period

9.2.9 Armature short-circuit brake, internal voltage protection, DC brake

9.2.9.1 General

The "External armature short-circuit" function for permanent-magnet synchronous motors initiates an external contactor which short-circuits the motor via resistors when the pulses are canceled. This reduces the kinetic energy of the motor.

The "Internal armature short-circuit braking" function for permanent-magnet synchronous motors short-circuits a half-bridge in the power unit to control the motor power consumption, thus braking the motor.

The "Internal voltage protection" function for permanent-magnet synchronous motors protects the DC link capacitors when the pulses are cancelled by short-circuiting a half-bridge in the power unit.

The "DC braking" function for induction motors injects a direct current into the motor, thus braking the motor.

9.2.9.2 External armature short-circuit brake

Description

External armature short-circuit braking is only available for synchronous motors. It is mainly required when braking in a hazardous situation, if controlled braking using the drive converter is no longer possible, (e.g. in the case of power failure, EMERGENCY OFF etc.) or if no regenerative infeed is used. In this case, the motor stator windings are short-circuited via external braking resistors. This means that an additional resistance is inserted in the motor circuit that supports reducing the kinetic energy of the motor.

The external armature short-circuit is activated via p1231 = 1 (with contactor feedback signal) or p1231 = 2 (without contactor feedback signal). It is initiated when the pulses are canceled.

This function controls an external contactor via output terminals, which then short-circuits the motor through resistors when the pulses are canceled.

A permanent-magnet synchronous motor (p0300 = 2xx) is required in order to use the external armature short-circuit.

| |
|---|
| CAUTION |
| Only short-circuit proof motors may be used, or suitable resistances must be used for short-circuiting the motor. |

Note

In case of incorrect parameterization (e.g. induction motor and external armature short-circuit selected), the fault F07906 "Armature short-circuit / internal voltage protection: parameterization error" is generated.

9.2 Drive Functions

Function diagram

FP 7014 Technology functions - External armature short circuit

Parameters

- p0300: Mot type selection
- p1230 BI: Armature short-circuit/DC brake activation
- p1231 Armature short-circuit/DC brake configuration
 - 1: External armature short-circuit with contactor feedback signal
 - 2: External armature short-circuit without contactor feedback signal
- p1235 BI: External armature short-circuit, contactor feedback signal
- p1236 External armature short-circuit, contactor feedback signal monitoring time
- p1237 External armature short-circuit, delay time when opening
- r1238 CO: External armature short-circuit state
- r1239 CO/BO: Armature short-circuit / DC brake status word

9.2.9.3 Internal armature short-circuit brake

Description

Internal armature short-circuit braking is only available for synchronous motors. It is mainly required when braking in a hazardous situation, if controlled braking using the drive converter is no longer possible, (e.g. in the case of power failure, EMERGENCY OFF etc.) or if no regenerative infeed is used. In this case, the motor stator windings are short-circuited via a half-bridge in the power unit. This means that an additional resistance is inserted in the motor circuit that supports reducing the kinetic energy of the motor.

The internal armature short-circuit is configured p1231 = 4 and activated via p1230. It is initiated when the pulses are canceled.

A permanent-magnet synchronous motor (p0300 = 2xx) is required in order to use the internal armature short-circuit.



! DANGER

When the armature short-circuit is active, after the pulses have been cancelled all the motor terminals are at half the DC-link potential.

CAUTION

Only short-circuit proof motors may be used.

The Power Module / Motor Module must be designed to handle 1.8 times the short-circuit current of the motor.

Function diagram

FP 7016 Technology functions - Internal armature short circuit

Parameters

- p0300: Mot type selection
- p1230 BI: Armature short-circuit/DC brake activation
- p1231 Armature short-circuit/DC brake configuration
 - 4: Internal armature short-circuit/DC brake
- r1239 CO/BO: Armature short-circuit / DC brake status word

9.2.9.4 Internal voltage protection

Description

The internal voltage protection prevents the DC link capacitance from being loaded into a field weakening operated motor if the energy regeneration capability from the source voltage is missing.

Depending on the DC link voltage, the Power Module / Motor Module automatically decides whether the armature short-circuit is to be engaged. In this case, the protection remains operative even if the DRIVE-CLiQ connection between the Control Unit and the Power Module / Motor Module is interrupted.

The internal armature short-circuit is configured and activated via p1231 = 3 and activated when a device-specific DC link voltage threshold is reached. It is initiated when the pulses are canceled.

A permanent-magnet synchronous motor (p0300 = 2xx) is required in order to use the internal voltage protection.



DANGER

When the internal voltage protection is active, after the pulses have been cancelled all the motor terminals are at half the DC-link potential.

CAUTION

Only short-circuit proof motors may be used.

The Power Module / Motor Module must be designed to handle 1.8 times the short-circuit current of the motor.

The internal voltage protection function cannot be interrupted by a fault response. If an overcurrent occurs while internal voltage protection is active, the Power Module / Motor Module and/or the motor may sustain irreparable damage!

With the internal voltage protection active, the motor must not be powered by an external source for an extended period of time (e.g. by pulling loads or another coupled motor).

Note

In case of incorrect parameterization (e.g. induction motor and internal voltage protection selected), the fault F07906 "Armature short-circuit / internal voltage protection: parameterization error" is generated.

Parameters

- p0300: Mot type selection
- p1231 Armature short-circuit/DC brake configuration
 - 3: Internal voltage protection

9.2.9.5 DC brake

Description

DC braking is only supported for induction motors. It is mainly required when braking in a hazardous situation, if controlled braking using the drive converter is no longer possible, (e.g. in the case of power failure, EMERGENCY OFF etc.) or if no regenerative infeed is used. .

The DC brake is activated via p1231 = 4 or via p1231 = 14. It can be triggered via an input signal p1230 (signal = 1) or a fault response.

Activation of the DC brake via input signal

p1231 = 4

If the DC brake is activated by the digital input signal, the first step is that the pulses are blocked for the demagnetization time (p0347) of the motor in order to demagnetize the motor - the parameter p1234 (Speed at the start of DC braking) is ignored.

Then the braking current (p1232) is applied as long as the input is initiated in order to brake the motor or hold it at standstill.

p1231 = 14

The DC brake is released, if during operation a 1-signal is pending at the binector input p1230 and the actual speed is below the starting speed (p1234).

After the preceding demagnetization (p0347) of the motor for the period set in p1233, the braking current p1232 is applied and subsequently switched off automatically.

Cancellation of the input signal for DC braking

If the DC brake is removed, the drive returns to its selected operating mode.

The following applies:

- With vector control (closed-loop controlled with or without encoder):
The drive is synchronized with the motor frequency if the "Flying restart" function is activated, and then returns to closed-loop controlled mode. If the "Flying restart" function is not active, the drive can only be restarted from standstill without overcurrent fault.
- In V/f mode:
With the "Flying restart" function activated, the converter frequency is synchronized with the motor frequency, and the drive will then return to V/f mode. If the "Flying restart" function is not activated, the drive can only be restarted from standstill without overcurrent fault.

9.2 Drive Functions

DC brake as a fault response

If the DC brake is activated as a fault response, the motor is initially braked in field-oriented mode along the braking ramp up to the threshold set in p1234 (DC brake starting speed). The slope of the ramp is identical with that of the OFF1 ramp (parameterized using p1082, p1121). Subsequently, the pulses are disabled for the period in p0347 (demagnetizing time) in order to demagnetize the motor. The DC braking will start for the duration set in p1233 (DC braking period).

- If an encoder is present, braking will continue until the speed drops to below standstill threshold p1226.
- If no encoder is present, only the period in p1233 is effective.

Function diagram

FP 7017 Technology functions - DC braking

Parameters

- p0300: Mot type selection
- p1226 Standstill recognition speed threshold
- p1230 BI: Armature short-circuit/DC brake activation
- p1231 Armature short-circuit/DC brake configuration
 - 4: Internal armature short-circuit/DC brake
 - 14: DC braking under starting speed
- p1232 DC braking braking current
- p1233 DC braking period
- p1234 DC braking start speed
- r1239 CO/BO: Armature short-circuit / DC brake status word
- p1345 I_max voltage controller proportional gain
- p1346 I_max voltage controller integral time

9.2.10 Increasing the output frequency

9.2.10.1 Description

In applications that require higher output frequencies, the pulse frequency of the converter may have to be increased.

It may also be necessary to change the pulse frequency to prevent resonances from occurring.

Since increasing the pulse frequency also increases the switching losses, a derating factor for the output current must be taken into account when the drive is configured.

Once the pulse frequency has been increased, the new output currents are automatically included in the calculation for power unit protection.

Note

Use of a sine-wave filter (option L15) must be selected using p0230 = 3 when commissioning. This setting fixes the pulse frequency to 4 kHz or 2.5 kHz and it cannot be changed.

9.2.10.2 Default pulse frequencies

The specified maximum output frequencies can be achieved with the default pulse frequencies listed below.

Table 9- 4 Maximum output frequency with default pulse frequency

| Converter rating [kW] | Default pulse frequency [kHz] | Maximum output frequency [Hz] |
|--|-------------------------------|-------------------------------|
| Supply voltage 380 – 480 V 3 AC | | |
| 110 – 250 | 2 | 160 |
| 315 – 900 | 1.25 | 100 |
| Supply voltage 500 – 600 V 3 AC | | |
| 110 – 1000 | 1.25 | 100 |
| Supply voltage 660 – 690 V 3 AC | | |
| 75 – 1500 | 1.25 | 100 |

The pulse frequencies set in the factory are also the minimum frequencies.

The scanning times for the inputs and outputs of the customer terminal block TM31 are set in the factory to 4000 μ s. This is also the minimum limit.

9.2.10.3 Increasing the pulse frequency

Description

The pulse frequency can be increased in a virtually continuously variable manner to between the value preassigned in the factory and the maximum pulse frequency which can be set.

9.2 Drive Functions

Procedure

1. Parameter p0009 on the Control Unit must be set to 3 "Basic drive configuration".
2. Parameter p0112 "Sampling times default setting p0115" of the DO VECTOR must be set to 0 "Expert".
3. Use p0113 to enter any pulse frequency between 1 kHz and 2 kHz. If a higher pulse frequency is to be set (e.g. 2.2 kHz), this value must be divided by 2 or by 4 to obtain a result between 1 kHz and 2 kHz (e.g. 2.2 kHz divided by 2 is 1.1 kHz).
4. Not all pulse frequencies are accepted in parameter p0113; in such cases, the alarm "Impermissible value" is output.
5. If the frequency entered in parameter p0113 is not accepted, parameter r0114[0] recommends a different frequency that can deviate from the entered pulse frequency by several Hertz. This frequency should be entered in p0113.
6. After entering the frequency in p0113, parameter p0009 on the Control Unit must be set to 0 "Ready" again.
7. The Control Unit re-initializes. After booting, the pulse frequencies recommended in r0114[i] (i = 1, 2, ...) can be entered in parameter p1800 "Pulse frequency" of the DO VECTOR.

NOTICE

The pulse frequency entered in p1800 must correspond precisely to the value given in r0114[i]; otherwise, the entry will be rejected.

9.2.10.4 Maximum output frequency achieved by increasing the pulse frequency

Maximum output frequencies achieved by increasing the pulse frequency

By multiplying the basis pulse frequency (with integers), the following output frequencies can be achieved (taking into account the derating factors):

Table 9- 5 Maximum output frequency achieved by increasing the pulse frequency

| Pulse frequency [kHz] | Maximum output frequency [Hz] |
|-----------------------|-------------------------------|
| 1,25 | 100 |
| 2 | 160 |
| 2,5 | 200 |
| 4 | 300 ¹⁾ |
| 5 | 300 ¹⁾ |

¹⁾ The maximum output frequency is limited to 300 Hz due to the closed-loop control.

9.2.10.5 Parameters

- p0009 Device commissioning parameter filter
- p0112 Sampling times pre-setting p0115
- p0113 Selects the minimum pulse frequency
- p0115 Sampling times
- p1800 Pulse frequency

9.2.11 Pulse frequency wobbling

Description

Pulse frequency wobbling is when the pulse frequency is varied slightly according to a statistical process. The average pulse frequency value is still the value set; the statistical variation of the instantaneous value results in a modified noise spectrum.

This procedure reduces the subjectively noticeable motor noise, especially for the relatively low pulse frequencies set in the factory.

Pulse frequency wobbling is activated with $p1810.2 = 1$. The amplitude of the static wobbling signal can be set in the range from 0% to 20% via $p1811$.

For units connected in parallel, pulse frequency wobbling is activated automatically during commissioning.

Restrictions

- Pulse frequency wobbling can only be activated under the following conditions ($p1810.2 = 1$):
 - The drive is pulse suppressed.
 - $p1800 < 2 \times 1000 / p0115[0]$
- $p1811$ (Pulse frequency wobbling amplitude) can only be set under the following conditions:
 - $p1802.2 = 1$
 - $p0230$ (output filter) < 3 (no sine-wave filter)
- When pulse frequency wobbling is activated and impulses are enabled, the maximum pulse frequency ($p1800$) can be set as follows:
 - For $p1811 = 0$: $p1800 \leq 2 \times 1000 / p0115[0]$
 - For $p1811 > 0$: $p1800 \leq 1000 / p0115[0]$
- When pulse frequency wobbling is activated and impulses are enabled, if the maximum pulse frequency ($p1800$) is set to be greater than $1000 / p0115[0]$, then $p1811$ is set to 0.
- When pulse frequency wobbling is activated and impulses are suppressed, if the maximum pulse frequency ($p1800$) is set to be greater than $2 \times 1000 / p0115[0]$, then $p1811$ and $p1810.2$ are set to 0.

Note

If pulse frequency wobbling is deactivated ($p1810.2 = 0$), then all the indices of parameter $p1811$ are set to 0.

Parameters

- p1800 Pulse frequency setpoint
- p1810.2 Wobbling activated
- p1811[D] Pulse frequency wobbling amplitude

9.2.12 Runtime (operating hours counter)

Total system runtime

The entire system runtime is displayed in r2114 (Control Unit); it is made up of r2114[0] (milliseconds) and r2114[1] (days).

Index 0 indicates the system runtime in milliseconds; after reaching 86.400.000 ms (24 hours), the value is reset. Index 1 indicates the system runtime in days.

The value is saved when the system is switched off.

Once the drive unit has been switched on, the counter continues to run with the value that was saved the last time the drive was switched off.

Relative system runtime

The relative system runtime since the last POWER ON is displayed in p0969 (Control Unit). The value is indicated in milliseconds and the counter overflows after 49 days.

Actual motor operating hours

The motor operating hours counter p0650 (drive) resumes when the pulses are enabled. When the pulse enable is withdrawn, the counter is stopped and the value saved.

To store the value, you need a CONTROL UNIT with order number 6SL3040-....-0AA1 and version C or higher.

The counter is deactivated with p0651 = 0.

If the maintenance interval set in p0651 is reached, alarm A01590 is triggered. Once the motor has been maintained, the maintenance interval must be reset.

Operating hours counter for the fan

The operating hours of the fan in the power unit are displayed in p0251 (drive).

The number of hours operated can only be reset to 0 in this parameter (e.g. after a fan has been replaced).

The service life of the fan is entered in p0252 (drive).

Alarm A30042 (service life of the fan reached or exceeded) is output when this figure is reached, and also 500 hours beforehand. Evaluation of the fault value in the alarm provides details of the cause of the alarm.

Monitoring is deactivated with p0252 = 0.

9.2.13 Simulation operation

Description

The simulation function is predominantly used to simulate the drive without a motor being connected and without a DC link voltage. In this case, it should be noted that the simulation mode can only be activated under an actual DC link voltage of 40 V. If the voltage lies above this threshold, the simulation mode is reset, and a fault message F07826 is issued.

Communications with a higher-level automation system can be tested using the simulation mode. If the drive is also to return actual values, note that it must be switched over to encoderless operation during simulation mode. This means that large parts of the SINAMICS software (e.g., software channel, sequence control, communications, technology function, etc.) can be tested in advance without requiring a motor.

Another application is to test the correct functioning of the Power Module. Especially for drive units with higher power ratings 75 kW (690 V) and 110 kW (400 V), after repairs, it is necessary to test the gating of the power semiconductors. This is done by injecting a low DC voltage as DC link voltage (e.g. 12 V). The drive unit is then powered-up and the pulses enabled. It must be possible to run through all of the pulse patterns of the gating unit software.

This means that the software must allow the pulses to be switched-in and various frequencies approached. If a speed encoder is not being used, then this is generally implemented using V/f control or sensorless closed-loop speed control.

Note

The following functions are de-activated in the simulation mode:

- Motor data identification
- Motor data identification, rotating without encoder
- Pole position identification

No flying restart is carried-out for V/f control and sensorless closed-loop vector control.

Commissioning

Simulation is activated using p1272 = 1; the following pre-requisites must be fulfilled:

- The drive unit must have been commissioned for the first time (default: Standard induction motors).
- The DC link voltage must lie below 40 V (observe the tolerance of the DC link voltage sensing).

Alarm A07825 (simulation mode activated) must be output during simulation operation.

Parameters

- p1272 Simulation operation

9.2.14 Direction reversal

Description

The direction of rotation of the motor can be reversed using direction reversal via p1821 without having to change the motor rotating field by interchanging two phases on the motor and inverting the encoder signals using p0410.

Reversal via p1821 can be detected from the motor direction of rotation. The speed setpoint and actual value, torque setpoint and actual value remain unchanged, as does the relative position change.

A pulse inhibit must be set prior to attempting reversal.

Reversing can be set differently for each drive data set.

Note

When changing over the drive data set to differently set reversing and with pulse approval, fault F7434 is issued.

Reversing can be observed by checking parameters r0069 (phase currents) and r0089 (phase voltage). The absolute position reference is lost on reversal.

Function diagram

| | |
|---------------|--------------------|
| FD 4704, 4715 | Encoder evaluation |
| FD 6730, 6731 | Current control |

Parameters

- r0069 Phase currents actual value
- r0089 Phase voltage actual value
- p1820 Reverse output phase sequence
- p1821 Direction of rotation

9.2.15 Unit changeover

Description

Parameters and process variables for input and output can be switched to a suitable units system (SI units, US units or referenced variables (%)) with the help of the unit changeover function.

The following constraints apply to the unit changeover:

- Unit changeover is only possible for the "VECTOR" drive object.
- Parameters of the rating plate of the drive converter or the motor rating plate can be changed over between SI/US units; however, a per unit representation is not possible.
- Once the changeover parameter has been changed, all parameters that are assigned to a unit group depending on this parameter are jointly changed over to the new unit.
- A separate parameter is available for selecting technological units (p0595) for the representation of technological variables in the technology controller.
- If a changeover is made to referenced variables and the reference variable is subsequently changed, the % value entered in a parameter will not change.

Example:

- With a reference speed of 1500 1/min, a fixed speed of 80 % corresponds to a value of 1200 1/min.
- If the reference speed is changed to 3000 1/min, the value of 80 % is retained and is now 2400 1/min.

Restrictions

- When a unit changeover occurs, rounding to the decimal places is carried out. This can mean that the original value might change by up to one decimal place.
- If a referenced form is selected and the reference parameters (e.g. p2000) are changed retrospectively, the physical significance of some of the control parameters is also adjusted, which can affect the control behavior.
- If the reference variables (p2000 to p2007) are changed in the offline mode in STARTER, there is a risk that the parameter value ranges will be violated. In this case, appropriate fault messages will be displayed when the parameters are loaded to the drive unit.

Changing over the units

The units can be changed over via the AOP30 and via STARTER.

- Unit changeover via AOP30 is always carried out immediately. Once the corresponding parameters have been changed, the values affected are displayed in the new selected unit.
- If STARTER is used, unit changeover can only take place in offline mode in the configuration screen of the corresponding drive object. The new units are not displayed until after the download ("Load project to target system") and subsequent upload ("Load project to PG") have been completed.

Unit groups

Each parameter that can be switched is assigned to a unit group which can be switched within certain limits depending on the group.

This assignment and the units groups for each parameter appear in the parameter list in the SINAMICS List Manual.

The unit groups can be individually switched using 4 parameters (p0100, p0349, p0505 and p0595).

Parameters

- p0010 Commissioning parameter filter
- p0100 IEC/NEMA mot stds
- p0349 Selection of units system, motor equivalent circuit diagram data
- p0505 Selection of units system
- p0595 Selection of technological unit
- p0596 Reference variable of technological unit
- p2000 Reference frequency/speed
- p2001 Reference voltage
- p2002 Reference current
- p2003 Reference torque
- p2004 Reference power
- p2005 Reference angle
- p2007 Reference acceleration

9.2.16 Derating behavior at increased pulse frequency

Description

To reduce motor noise or to increase output frequency, the pulse frequency can be increased relative to the factory setting.

The increase in the pulse frequency normally results in a reduction of the maximum output current (see "Technical data/current derating depending on the pulse frequency").

When commissioning the converter the behavior at overload is adjusted in such a manner that the pulse frequency is variably reduced so that the required power can be obtained.

Characteristics:

- The reaction to overload depends on the setting of parameter p0290:
 - p0290 = 0: Reduce output current or output frequency
 - p0290 = 1: No reduction, shutdown when overload threshold is reached
 - p0290 = 2: Reduce the output current or output and pulse frequency (not using I^2t).
 - p0290 = 3: Reduce the pulse frequency (not using I^2t)
- For p0290 = 2 at overload first reduce the pulse frequency (and consequently the output frequency) until it has dropped to rated pulse frequency, then reduce the output frequency if overload continues to persist.
The rated pulse frequency is half the inverse value of the current controller clock cycle: $0.5 \times 1/p0115[0]$.
- Reduction of the pulse frequency is executed in whole multiples based on the rated pulse frequency (5 kHz -> 2.5 kHz -> 1.25 kHz or 4 kHz -> 2 kHz).
- After entering the maximum speed in p1082 the system automatically calculates whether the pulse frequency is sufficient for the entered maximum speed, if necessary the pulse frequency is increased automatically to a value that is necessary for this.
At overload, then also for p0290 = 2 or 3, this new pulse frequency will no longer be underranged, the downstream reaction (reduce output voltage or switch off) will be triggered.

Exceptions:

- With an activated sinus filter (p0230 = 3, 4), this behavior is not permitted because the factory set pulse frequency (2.5 kHz or 4 kHz) should not be changed through this measure. Consequently in this case the selection possibility for the parameter p0290 is limited to "0" and "1".

Activation of the variable pulse frequency

At commissioning the parameter p 0290 is automatically set to the value "2". This activates pulse frequency reduction at overload.

Deactivation of the variable pulse frequency

By changing the parameter p0290 to "0" or "1" the variable pulse frequency is deactivated.

Function diagram

FP 8014 Signals and monitoring functions - thermal monitoring power unit

Parameter

- r0036 Power unit overload I2t
- r0037 CO: Power unit temperatures
- p0115 Sampling times for internal control loops
- p0230 Drive filter type, motor side
- p0290 Power unit overload response
- p1082 Maximum speed
- r2135.13 Fault thermal overload power unit
- r2135.15 Thermal overload in power unit alarm

9.3 Extended functions

9.3.1 Technology controller

Description

The "technology controller" function module allows simple control functions to be implemented, e.g.:

- Liquid level control
- Temperature control
- Dancer position control
- Pressure control
- Flow control
- Simple control without higher-level control
- Tension control

The technology controller features:

- Two scalable setpoints
- Scalable output signal
- Separate fixed values
- Separate motorized potentiometer
- The output limits can be activated and deactivated via the ramp-function generator.
- The D component can be switched to the system deviation or actual value channel.
- The motorized potentiometer of the technology controller is only active when the drive pulses are enabled.

The technology controller is designed as a PID controller, whereby the differentiator can be switched to the control deviation channel or the actual value channel (factory setting). The P, I, and D components can be set separately.

A value of 0 deactivates the corresponding component. Setpoints can be specified via two connector inputs. The setpoints can be scaled via parameters p2255 and p2256.

A ramp-function generator in the setpoint channel can be used to set the setpoint ramp-up/ramp-down time via parameters p2257 and p2258. The setpoint and actual value channel each have a smoothing element. The smoothing time can be set via parameters p2261 and p2265.

The setpoints can be specified via separate fixed setpoints (p2201 to p2215), the motorized potentiometer, or via the field bus (e.g. PROFIBUS).

Pre-control can be integrated via a connector input.

The output can be scaled via parameter p2295 and the control direction reversed. It can be limited via parameters p2291 and p2292 and interconnected as required via a connector output (r2294).

The actual value can be integrated, for example, via an analog input on the TM31.

If a PID controller has to be used for control reasons, the D component is switched to the setpoint/actual value difference (p2263 = 1) unlike in the factory setting. This is always necessary when the D component is to be effective, even if the reference variable changes. The D component can only be activated when p2274 > 0.

Note

With the entry "0" sec. as power up time or ramp-down time for the ramp function generator of the technology controller, the current values of the respective ramp function generator will be frozen.

Commissioning

The "technology controller" function module can be activated by running the commissioning Wizard. Parameter r0108.16 indicates whether the function module has been activated.

Function diagram

| | |
|---------|--|
| FD 7950 | Technology controller – fixed values, binary selection |
| FP 7951 | Technology controller – fixed values, direct selection |
| FD 7954 | Technology controller – motorized potentiometer |
| FD 7958 | Technology controller – closed-loop controller |

Example: liquid level control

The objective here is to maintain a constant level in the container.

This is carried out by means of a variable-speed pump in conjunction with a sensor for measuring the level.

The level is determined via an analog input (e.g. AI0 TM31) and sent to the technology controller. The level setpoint is defined in a fixed setpoint. The resulting controlled variable is used as the setpoint for the speed controller.

In this example, a Terminal Module (TM31) is used.

9.3 Extended functions




Figure 9-8 Level control: Application




Figure 9-9 Level control: Controller structure

Key control parameters

- p1155 = r2294 CI: Speed controller speed setpoint 1 [FP 3080]
- p2253 = r2224 Technology controller setpoint effective via fixed setpoint [FD 7950]
- p2263 = 1 D component in fault signal [FD 7958]
- p2264 = r4055 Actual value signal X_{actual} via AI0 of TM31 [FP 9566]
- p2280 = Kp Calculate P gain by means of optimization
- p2285 = Tn Calculate integral time by means of optimization
- p2200 = 1 Technology controller enabled

9.3.2 Bypass function

The bypass function uses digital converter outputs to activate two contactors and uses digital inputs to evaluate the contactor's feedback (e.g. via TM31). This circuit allows the motor to be operated using the converter or directly on the supply line. The contactors are activated by the converter. The feedback signals for the contactor positions have to be returned to the converter.

The bypass circuit can be implemented in two ways:

- without synchronizing the motor to the supply and
- with synchronizing the motor to the supply.

The following applies to all bypass versions:

- The bypass switch is also shut down when one of the "OFF2" or "OFF3" control word signals is canceled.
- Exception:
If necessary, the bypass switch can be interlocked by a higher-level controller such that the converter can be shut down completely (i.e. including the controller electronics) while the motor is operated on the supply.
The protective interlocking must be implemented on the system side.
- When the converter is started up again after POWER OFF, the status of the bypass contactors is evaluated. After powering up, the converter can thereby change straight into "Ready to start and bypass" status. This is only possible if the bypass is activated via a control signal, the control signal (p1266) is still present once the system has been ramped up, and the automatic restart function (p1200 = 4) is active.
- Changing the converter into "Ready to start and bypass" status after powering up, is of a higher priority than switching back on automatically.
- Monitoring of the motor temperatures using temperature sensors is active while the converter is in one of two statuses "Ready to start and bypass" or "Ready for operation and bypass".
- The two motor contactors must be designed for switching under load.

Note

The examples contained in the following descriptions are only basic circuits designed to explain the basic function. The dimensions of specific circuit configurations (contactors, protective equipment) must be calculated for specific systems.

Prerequisites

The bypass function is only available for speed control without encoders (p1300 = 20) or V/f-control (p1300 = 0...19) and when using an asynchronous motor.

Establishing the bypass function

The bypass function is part of the "technology controller" function module that can be activated by running the commissioning Wizard. Parameter r0108.16 indicates whether the function module has been activated.

9.3 Extended functions

9.3.2.1 Bypass with synchronizer with degree of overlapping (p1260 = 1)

Description

When “Bypass with synchronizer with degree of overlapping (p1260 = 1)” is activated, the synchronized motor is transferred to the supply and retrieved again. During the changeover, both contactors K1 and K2 are closed at the same time for a period (phase lock synchronization).

A reactor is used to de-couple the drive converter from the line supply - the uk value for the reactor is 10 (± 2) %.




Figure 9-10 Typical circuit diagram for bypass with synchronizer with degree of overlapping

Activation

The function with synchronizer with degree of overlapping (p1260 = 1) function can only be activated using a control signal. It cannot be activated using a speed threshold or a fault.

Parameterization

Once the bypass with synchronizer with degree of overlapping (p1260 = 1) function has been activated, the following parameters must be set:

Table 9- 6 Parameter settings for bypass function with synchronizer with degree of overlapping

| Parameters | Description |
|----------------------------|--|
| p1266 = | Control signal setting when p1267.0 = 1 |
| p1267.0 = 1 p1267.1 = 0 | Bypass function is initiated by the control signal |
| p1269[0] = | Signal source for contactor K1 feedback |
| p1269[1] = | Signal source for contactor K2 feedback |
| p3800 = 1 | The internal voltages are used for synchronization. |
| p3802 = r1261.2 | Synchronizer activation is triggered by the bypass function. |

Transfer process




Figure 9-11 Signal diagram, bypass with synchronization with overlap

9.3 Extended functions

Transfer of motor to line supply
(contactors K1 and K2 are activated by the converter):

- The initial state is as follows: Contactor K1 is closed, contactor K2 is open and the motor is fed from the converter.
- The control bit "bypass command" (p1266) is set (e.g., by the higher-level automation).
- The bypass function sets the control word bit "synchronizing" (r1261.2).
- Since the bit is set while the converter is running, the "Transfer motor to line supply" synchronization process is started.
- Once motor synchronization to line frequency, line voltage and line phasing is complete, the synchronization algorithm reports this state (r3819.2).
- The bypass mechanism evaluates this signal and closes contactor K2 (r1261.1 = 1). The signal is evaluated internally - BICO wiring is not required.
- After contactor K2 has fed back the "closed" state (r1269[1] = 1), contactor K1 is opened and the converter inhibits the pulses. The converter is in "Ready for operation and bypass" state.
- If the On command is cancelled in this phase, the converter will change to "Ready to start and bypass" status. If the appropriate contactors are being used, the converter will be isolated from the line supply and the DC link discharged.

To transfer the motor back from the line supply, the sequence is simply reversed: At the start of the process, contactor K2 is closed and contactor K1 is open.

- The "Command bypass" control bit is canceled (e.g., by the higher-level automation).
- The bypass function sets the control word bit "synchronizing".
- The pulses are enabled. Since "synchronizing" is set before "pulse enable", the converter interprets this as a command to retrieve the motor from the line supply.
- Once converter synchronization to line frequency, line voltage and line phasing is complete, the synchronization algorithm reports this state.
- The bypass mechanism evaluates this signal and closes contactor K1. The signal is evaluated internally - BICO wiring is not required.
- Once contactor K1 has reported "closed" status, contactor K2 is opened and the motor returns to operation on the converter.

9.3.2.2 Bypass with synchronizer without degree of overlapping (p1260 = 2)

Description

When "Bypass with synchronizer without degree of overlapping (p1260 = 2)" is activated, contactor K2 (to be closed) is only closed when contactor K1 is opened (anticipatory type synchronization). Phasing of the motor voltage before synchronization must be set such that there is an "initial jump" upstream of the supply to which synchronization should be carried out. This done by setting the synchronization setpoint (p3809). A phase and frequency difference of around zero is produced when closing contactor K2 by braking the motor in the brief period in which both contactors are open.

In order for the function to run correctly, the moment of inertia must be sufficient.

Due to the expense of determining the synchronization setpoint (p3809), the decoupling restrictor is not needed.

The "flying restart" function must be activated (p1200 = 1).




Figure 9-12 Example circuit for bypass with synchronizer without degree of overlapping

Activation

The bypass with synchronizer without degree of overlapping (p1260 = 2) function can only be activated using a control signal. It cannot be activated using a speed threshold or a fault.

Parameterization

Once the bypass with synchronizer without degree of overlapping (p1260 = 2) function has been activated, the following parameters must be set:

9.3 Extended functions

Table 9- 7 Parameter settings for bypass function with synchronizer without degree of overlapping

| Parameters | Description |
|----------------------------|--|
| p1266 = | Control signal setting when p1267.0 = 1 |
| p1267.0 = 1 p1267.1 = 0 | Bypass function is initiated by the control signal |
| p1269[0] = | Signal source for contactor K1 feedback |
| p1269[1] = | Signal source for contactor K2 feedback |
| p3800 = 1 | The internal voltages are used for synchronization. |
| p3802 = r1261.2 | Synchronizer activation is triggered by the bypass function. |
| p1200 = 1 | The "flying restart" function is always active. |

9.3.2.3 Bypass without synchronizer (p1260 = 3)

Description

When the motor is transferred to the supply, contactor K1 is opened (following converter's pulse inhibit). The system then waits for the motor excitation time to elapse after which contactor K2 is closed and the motor is run directly on the supply. If the motor is switched on in a non-synchronized manner, when activated an equalizing current flows and this must be taken into account when designing the protective equipment (see diagram "Circuit bypass without synchronization").

When the motor is being transferred from the supply by the converter, initially contactor K2 is opened and after the excitation time, contactor K1 is closed. The converter then captures the rotating motor and the motor is operated on the converter.

Contactor K2 must be designed for switching under load.

Contactors K1 and K2 must be interlocked against closing at the same time.

The "flying restart" function must be activated (p1200 = 1).




Figure 9-13 Example circuit for bypass without synchronization

9.3 Extended functions

Activation

The bypass with synchronizer (p1260 = 3) can be triggered by the following signals (p1267):

- Bypass by means of control signal (p1267.0 = 1):
The bypass can be activated by means of a digital signal (p1266) (e.g. from a higher-level automation system). If the digital signal is canceled, a changeover to converter operations is triggered once the debypass delay time (p1263) has expired.
- Bypass at speed threshold (p1267.1 = 1):
Once a certain speed is reached, the system switches to bypass (i.e. the converter is used as a start-up converter). The bypass cannot be connected until the speed setpoint is greater than the bypass speed threshold (p1265).
The system reverts to converter mode when the setpoint (on the input of the ramp-function generator, r1119) falls below the bypass speed threshold (p1265). The setpoint > comparison value condition prevents the bypass from being reactivated straight away if the actual speed is still above the bypass speed threshold (p1265) after switching back to converter operations.

The bypass time, debypass time, bypass speed variables and the command source for changing over are set using parameters.

Parameterization

Once the bypass without synchronizer (p1260 = 3) function has been activated, the following parameters must be set:

Table 9- 8 Parameter settings for bypass function with synchronizer without degree of overlapping

| Parameter | Description |
|------------------------|--|
| p1262 = | Bypass dead time setting |
| p1263 = | Debypass dead time setting |
| p1264 = | Bypass delay time setting |
| p1265 = | Speed threshold setting when p1267.1 = 1 |
| p1266 = | Control signal setting when p1267.0 = 1 |
| p1267.0 = p1267.1 = | Trigger signal setting for bypass function |
| p1269[1] = | Signal source for contactor K2 feedback |
| p3800 = 1 | The internal voltages are used for synchronization. |
| p3802 = r1261.2 | Synchronizer activation is triggered by the bypass function. |
| P1200 = 1 | The "flying restart" function is always active. |

9.3.2.4 Function diagram

FP 7020 Synchronization

9.3.2.5 Parameters

Bypass function

- p1200 Flying restart operating mode
- p1260 Bypass configuration
- r1261 CO/BO: Bypass control/status word
- p1262 Bypass dead time
- p1263 Debypass delay time
- p1264 Bypass delay time
- p1265 Bypass speed threshold
- p1266 BI: Bypass control command
- p1267 Bypass changeover source configuration
- p1268 BI: Bypass feedback signal synchronization completed
- p1269 BI: Bypass switch feedback signal
- p1274 BI: Bypass switch monitoring time

Synchronization

- p3800 Sync-supply-drive activation
- p3801 Sync-supply-drive drive object number
- p3802 BI: Sync-supply-drive enable
- r3803 CO/BO: Sync-supply-drive control word
- r3804 CO: Sync-supply-drive target frequency
- r3805 CO: Sync-supply-drive frequency difference
- p3806 Sync-supply-drive frequency difference threshold
- r3808 CO: Sync-supply-drive phase difference
- p3809 Sync-supply-drive phase setpoint
- p3811 Sync-supply-drive frequency limitation
- r3812 CO: Sync-supply-drive correction frequency
- p3813 Sync-supply-drive phase synchronism threshold
- r3814 CO: Sync-supply-drive voltage difference
- p3815 Sync-supply-drive voltage difference threshold
- r3819 CO/BO: Sync-supply-drive status word

9.3 Extended functions

9.3.3 Extended braking control

Description

The "extended braking control" function module allows complex braking control for motor holding brakes and operational brakes.

The brake is controlled as follows (the sequence reflects the priority):

- Via parameter p1215
- Via binector parameters p1219[0..3] and p0855
- Via zero speed detection
- Via a connector interconnection threshold value

Commissioning

The "extended braking control" function module can be activated by running the commissioning Wizard. Parameter r0108.14 indicates whether the function module has been activated.

Parameter p1215 must be set to "3" and the brake controlled via a digital output on customer terminal strip TM31.

Function diagram

| | |
|---------|----------------------|
| FD 2704 | Zero speed detection |
| FD 2707 | Release/apply brake |
| FD 2711 | Signal outputs |

Example 1: Starting against applied brake

When the device is switched on, the setpoint is enabled immediately (if other enable signals are issued), even if the brake has not yet been released (p1152 = 1). The factory setting p1152 = r0899.15 must be separated here. The drive starts by generating a torque against the applied brake. The brake is not released until the motor torque or motor current (p1220) has exceeded braking threshold 1 (p1221).

This configuration is used, for example, when the drive is connected to a belt that is under tension (loop accumulator in the steel industry).

Example 2: Emergency brake

If emergency braking is required, electrical and mechanical braking is to take place simultaneously. This can be achieved if OFF3 is used as a tripping signal for emergency braking:

p1219[0] = r0898.2 (OFF3 to "apply brake immediately").

To prevent the converter working in opposition to the brake, the OFF3 ramp (p1135) should be set to 0 seconds. Any prevailing regenerative energy must be converted into heat via a braking resistor.

This is often used, for example, in calendar stacks, cutting tools, running gears, and presses.

Example 3: Service brake on crane drives

For cranes with manual control, it is important that the drive responds immediately when the control lever is moved (master switch). To this end, the drive is powered up using the on command (p0840) (the pulses are enabled). Speed setpoint (p1142) and speed controller (p0856) are inhibited. The motor is magnetized. The magnetization time generally applicable for three-phase motors (1-2 seconds) is, therefore, eliminated.

Now, only the brake opening time will delay the motor starting to rotate following activation of the master switch. Movement of the master switch generates a "setpoint enable from the control" (bit interconnected with p1142, p1229.2, p1224.0). The speed controller is enabled immediately and the speed setpoint is enabled once the brake opening time (p1216) has elapsed. When the master switch is in the zero position, the speed setpoint is inhibited and the drive ramps down along the ramp-function generator's ramp-down ramp. The brake closes once the standstill limit (p1226) is undershot. Once the brake closing time (p1217) has elapsed, the speed controller is inhibited (the motor is no longer generating any force). Extended braking control is used with the modifications described below.




Figure 9-14 Example: Service brake on a crane drive

9.3 Extended functions

9.3.4 Extended monitoring functions

Description

The "extended monitoring functions" function module enables additional monitoring functions:

- Speed setpoint monitoring: $|n_set| \leq p2161$
- Speed setpoint monitoring: $n_set > 0$
- Load monitoring

Description of load monitoring

This function monitors power transmission between the motor and the working machine. Typical applications include V-belts, flat belts, or chains that loop around the belt pulleys or cog wheels for drive and outgoing shafts and transfer the peripheral speeds and forces. Load monitoring can be used here to identify blockages in the working machine and interruptions to the power transmission.

During load monitoring, the current speed/torque curve is compared with the programmed speed/torque curve (p2182 – p2190). If the current value is outside the programmed tolerance bandwidth, a fault or alarm is triggered depending on parameter p2181. The fault or alarm message can be delayed by means of parameter p2192 to prevent false alarms caused by brief transitional states.




Figure 9-15 Load monitoring (p2181 =1)

Commissioning

The "extended monitoring functions" function module can be activated by running the commissioning wizard. Parameter r0108.17 indicates whether it has been activated.

Function diagram

| | |
|---------|------------------|
| FD 8010 | Speed messages 1 |
| FP 8011 | Speed messages 2 |
| FD 8013 | Load monitoring |

Parameters

- p2150 Hysteresis speed 3
- p2151 Cl: Speed setpoint for messages
- p2161 Speed threshold 3
- p2181 Load monitoring, response
- p2182 Load monitoring, speed threshold 1
- p2183 Load monitoring, speed threshold 2
- p2184 Load monitoring, speed threshold 3
- p2185 Load monitoring, speed threshold 1 upper
- ...
- p2190 Load monitoring, speed threshold 3 lower
- p2192 Load monitoring, delay time
- r2198.4 $|n_set| \leq p2161$
- r2198.5 $n_set > 0$
- r2198.11 Load monitoring displays alarm
- r2198.12 Load monitoring displays fault

9.4 Monitoring and protective functions

9.4 Monitoring and protective functions

9.4.1 Protecting power components

Description

SINAMICS power units offer comprehensive functions for protecting power components.

Table 9- 9 General protection for power units

| Protection against: | Protective measure | Response |
|--|--|---|
| Overcurrent ¹⁾ | Monitoring with two thresholds: <ul style="list-style-type: none"> • First threshold exceeded | A30031, A30032, A30033 Current limiting in phase U has responded. Pulsing in this phase is inhibited for one pulse period. F30017 -> OFF2 is triggered if the threshold is exceeded too often. |
| | <ul style="list-style-type: none"> • Second threshold exceeded | F30001 "Overcurrent" -> OFF2 |
| DC link overvoltage ¹⁾ | Comparison of DC link voltage with hardware shutdown threshold | F30002 "Overvoltage" -> OFF2 |
| DC link undervoltage ¹⁾ | Comparison of DC link voltage with hardware shutdown threshold | F30003 "Undervoltage" -> OFF2 |
| Short-circuit ¹⁾ | Second monitoring threshold checked for overcurrent | F30001 "Overcurrent" -> OFF2 |
| | Uce monitoring for IGBT module | F30022 "Monitoring Uce" -> OFF2 |
| Ground fault | Monitoring the sum of all phase currents | After threshold in p0287 is exceeded: F30021 "power unit: Ground fault" -> OFF2 Note: The sum of all phase currents is displayed in r0069[6]. For operation, the value in p0287[1] must be greater than the sum of the phase currents when the insulation is intact. |
| Line phase-failure detection ¹⁾ | | F30011 "Line phase-failure in main circuit" -> OFF2 |

¹⁾ The monitoring thresholds are permanently set in the converter and cannot be changed by the user.

9.4.2 Thermal monitoring and overload responses

Description

The priority of thermal monitoring for power components is to identify critical situations. If alarm thresholds are exceeded, the user can set parameterizable response options that enable continued operation (e.g. with reduced power) and prevent immediate shutdown. The parameterization options, however, only enable intervention below the shutdown thresholds, which cannot be changed by the user.

The following thermal monitoring options are available:

- i^2t monitoring – A07805 – F30005
 i^2t monitoring is used to protect components that have a high thermal time constant compared with semi-conductors. Overload with regard to i^2t is present when the converter load (r0036) is greater than 100% (load in % in relation to rated operation).
- Heatsink temperature – A05000 – F30004
Monitoring of the heat-sink temperature (r0037) of the power semi-conductor (IGBT).
- Chip temperature – A05001 – F30025
Significant temperature differences can occur between the barrier layer of the IGBT and the heatsink. These differences are taken into account and monitored by the chip temperature (r0037).

If an overload occurs with respect to any of these three monitoring functions, an alarm is first output. The alarm threshold p0294 (i^2t monitoring) can be parameterized relative to the shutdown (trip) values.

Example

The factory setting for the alarm threshold for chip temperature monitoring is 15 Kelvin (K), and 5 K for the heat sink and inlet air. This means that the "Overtemperature, overload" alarm is triggered at 15 K or 5 K below the shutdown threshold.

The parameterized responses are induced via p0290 simultaneously when the alarm is output. Possible responses include:

- Reduction in pulse frequency (p0290 = 2, 3)
This is a highly effective method of reducing losses in the power unit, since switching losses account for a high proportion of overall losses. In many applications, a temporary reduction in the pulse frequency can be tolerated to allow the process to continue.
Disadvantage:
As a result of the pulse frequency reduction, the current ripple is increased which can mean that the torque ripple is increased at the motor shaft (for low moments of inertia) and also an increased noise level. Reducing the pulse frequency does not affect the dynamic response of the current control circuit, since the sampling time for the current control circuit remains constant.

9.4 Monitoring and protective functions

- Reducing the output frequency (p0290 = 0, 2)
This variant is recommended when you do not need to reduce the pulse frequency or the pulse frequency has already been set to the lowest level. The load should also have a characteristic similar to a fan, that is, a quadratic torque characteristic with falling speed. Reducing the output frequency has the effect of significantly reducing the converter output current which, in turn, reduces losses in the power unit.
- No reduction (p0290 = 1)
You should choose this option if it is neither possible to reduce the pulse frequency nor reduce the output current. The converter does not change its operating point once an alarm threshold has been overshoot, which means that the drive can be operated until it reaches its shutdown values. Once it reaches its shutdown threshold, the converter switches itself off and the "Overtemperature, overload" fault is output. The time until shutdown, however, is not defined and depends on the degree of overload. To ensure that an alarm can be output earlier or that the user can intervene, if necessary, in the drive process (e.g. reduce load/ambient temperature), only the alarm threshold can be changed.

Function diagram

FP 8014 Thermal monitoring, power unit

Parameters

- r0036 Power Module overload
- r0037 Power Module temperatures
- p0290 Power Module overload response
- r0293 Power unit alarm threshold model temperature
- p0294 Power Module alarm with i^2t overload
- r2135.13 Fault: thermal overload in power unit
- r2135.15 Alarm: thermal overload in power unit

9.4.3 Block protection

Description

The fault message "Motor blocked" is only triggered if the speed of the drive is below the variable speed threshold set in p2175. With vector control, it must also be ensured that the speed controller is at the limit. With V/f control, the current limit must already have been reached.

Once the ON delay (p2177) has elapsed, the message "Motor blocked" and fault F07900 are generated.

The blocking monitoring enable can be deactivated via p2144.




Figure 9-16 Blocking protection

Function diagram

FP 8012 Messages and monitoring - Torque messages, motor blocked/stalled

Parameters

- p2144 BI: Motor stall monitoring enable (negated)
- p2175 Motor locked speed threshold
- p2177 Motor locked delay time

9.4 Monitoring and protective functions

9.4.4 Stall protection (only for vector control)

Description

If, for closed-loop speed control with encoder, the speed threshold set in p1744 for stall detection is exceeded, then r1408.11 (speed adaptation, speed deviation) is set.

If the fault threshold value set in p1745 is exceeded when in the low speed range (less than p1755 x (100% - p1756)), r1408.12 (motor stalled) is set.

If one of these two signals is set, then after the delay time in p2178, fault F07902 (motor stalled) is returned.




Figure 9-17 Stall protection

Function diagram

| | |
|---------|--|
| FP 6730 | Current control |
| FP 8012 | Messages and monitoring - Torque messages, motor blocked/stalled |

Parameters

- r1408 CO/BO: Control status word 3
- p1744 Motor model speed threshold stall detection
- p1745 Motor model error threshold stall detection
- p1755 Motor model changeover speed encoderless operation
- p1756 Motor model changeover speed hysteresis encoderless operation
- p2178 Motor stalled delay time

9.4.5 Thermal motor protection

9.4.5.1 Description

Description

The priority of thermal motor protection is to identify critical situations. If alarm thresholds are exceeded, the user can set parameterizable response options (p0610) that enable continued operation (e.g. with reduced power) and prevent immediate shutdown.

- Effective protection is also possible without a temperature sensor (p4100 = 0). The temperatures of different motor components (stators, core, rotors) can be determined indirectly using a temperature model.
- Connecting temperature sensors allows the motor temperature to be determined directly. In this way, accurate start temperatures are available immediately when the motor is switched on again or after a power failure.

9.4.5.2 Temperature connection at the customer terminal block TM31 (option G60)

Temperature measurement via KTY

The device is connected to terminals X522:7 (Temp+) and X522:8 (Temp-) on the customer terminal block (TM31) in the forward direction of the diode. The measured temperature is limited to between $-140\text{ }^{\circ}\text{C}$ and $+248\text{ }^{\circ}\text{C}$ and is made available for further evaluation.

- Set the KTY temperature sensor type: p4100 = 2
- Activate motor temperature measurement via the external sensor: p0600 = 10
If a customer terminal block TM31 is present and on completion of commissioning, the source for the external sensor is set to the customer terminal block (p0603 = (TM31) r4105).

Temperature measurement via PTC

The device is connected to terminal X522:7/8 on the customer terminal block (TM31). The threshold for switching to an alarm or fault is $1650\ \Omega$. If the threshold is exceeded, the system switches internally from an artificially-generated temperature value of $-50\text{ }^{\circ}\text{C}$ to $+250\text{ }^{\circ}\text{C}$ and makes it available for further evaluation.

- Set the PTC temperature sensor type: p4100 = 1
- Activate motor temperature measurement via the external sensor: p0600 = 10
If a customer terminal block TM31 is present and on completion of commissioning, the source for the external sensor is set to the customer terminal block (p0603 = (TM31) r4105).

9.4 Monitoring and protective functions

9.4.5.3 Temperature connection to a Sensor Module (option K50)

Temperature measurement via KTY

The device is connected to the appropriate terminals Temp- and Temp+ on the Sensor Module in the forward direction of the diode (see corresponding section in chapter "Electrical installation").

- Activate motor temperature measurement via encoder 1: p0600 = 1.
- Set the KTY temperature sensor type: p0601 = 2

Temperature measurement via PTC

The device is connected to the appropriate terminals Temp- and Temp+ on the Sensor Module (see corresponding section in chapter "Electrical installation"). The threshold for switching to an alarm or fault is 1650 Ω .

- Activate motor temperature measurement via encoder 1: p0600 = 1.
- Set the PTC temperature sensor type: p0601 = 1

9.4.5.4 Temperature connection directly to the Control Interface Module

Temperature measurement via KTY

The device is connected to terminals X41:3 (Temp-) and X41:4 (Temp+) on the Control Interface Module in the forward direction of the diode.

- Activate motor temperature measurement via Motor Module: p0600 = 11.
- Set the KTY temperature sensor type: p0601 = 2

Temperature measurement via PTC

The device is connected to terminals X41:3 (Temp-) and X41:4 (Temp+) on the Control Interface Module. The threshold for switching to an alarm or fault is 1650 Ω .

- Activate motor temperature measurement via Motor Module: p0600 = 11.
- Set the PTC temperature sensor type: p0601 = 1

Temperature measurement via PT100

The device is connected to terminals X41:3 (Temp-) and X41:4 (Temp+) on the Control Interface Module. p0624 can be used to set the temperature offset for the PT100 measured value.

- Activate motor temperature measurement via Motor Module: p0600 = 11.
- Set the PT100 temperature sensor type: p0601 = 5

9.4.5.5 Temperature sensor evaluation

Temperature measurement via KTY or PT100

- When the alarm threshold is reached (set via p0604; delivery state 130 °C), alarm A07910 is triggered.
Parameter p0610 can be used to set how the drive responds to the alarm triggered:
 - 0: No response, only alarm, no reduction of I_{max}
 - 1: Alarm and reduction of I_{max} and fault (F07011)
 - 2: Alarm and fault (F07011), no reduction of I_{max}
- When the fault threshold is reached (set via p0605, delivery state 145 °C), fault F07011 is triggered in conjunction with the setting in p0610.

Temperature measurement via PTC

- Alarm A07910 is triggered once the PTC responds.
- Fault F07011 is triggered once the waiting time defined in p0606 has elapsed.

Sensor monitoring for wire breakage/short-circuit

If the temperature of the motor temperature monitor is outside the range -140 °C to +250 °C, the sensor cable is broken or has short-circuited. Alarm A07015 ("Drive: Motor temperature sensor alarm") is triggered. Fault F07016 ("Drive: Motor temperature sensor fault") is triggered once the waiting time defined in p0607 has elapsed.

Fault F07016 can be suppressed by p0607 = 0. If an induction motor is connected, the drive continues operating with the data calculated in the thermal motor model.

If the system detects that the motor temperature sensor set in p0600 is not connected, alarm A07820 "Temperature sensor not connected" is triggered.

9.4.5.6 Function diagram

| | |
|---------|--------------------------------------|
| FP 8016 | Thermal monitoring motor |
| FP 9576 | TM31 -temperature evaluation KTY/PTC |
| FP 9577 | TM31 -sensor monitoring KTY/PTC |

9.4 Monitoring and protective functions

9.4.5.7 Parameters

- p0600 Motor temperature sensor for monitoring
- p0601 Motor temperature sensor type
- p0604 Motor overtemperature fault threshold
- p0605 Motor overtemperature alarm threshold
- p0606 Motor overtemperature timer
- p0607 Temperature sensor fault timer
- p0610 Motor overtemperature response
- p4100 TM31 temperature evaluation sensor type
- r4105 CO: TM31 temperature evaluation actual value


10

Diagnosis / faults and alarms

10.1 Chapter content

This chapter provides information on the following:

- Troubleshooting
- Service and support offered by Siemens AG



10.2 Diagnosis

Description

This section describes procedures for identifying the causes of problems and the measures you need to take to rectify them.

Note

If errors or malfunctions occur in the device, you must carefully check the possible causes and take the necessary steps to rectify them. If you cannot identify the cause of the problem or you discover that components are defective, your regional office or sales office should contact Siemens Service and describe the problem in more detail.

10.2.1 Diagnostics using LEDs

Control Unit (-A10)

Table 10- 1 Description of the Control Unit LEDs

| LED | Color | State | Description |
|---|-------------|-----------------------|---|
| RDY (ready) | --- | OFF | The electronics power supply is missing or lies outside permissible tolerance range. |
| | Green | Steady light | The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place. The Control Unit is awaiting first commissioning. |
| | | 2 Hz flashing light | Writing to CompactFlash card. |
| | Red | Steady light | At least one fault is present in this component. |
| | | 0.5 Hz flashing light | CompactFlash card has not been inserted. Boot error (e.g., firmware cannot be loaded to the RAM). |
| | Green / red | 0.5 Hz flashing light | Control Unit is ready for operation. However there are no software licenses. |
| | Orange | Steady light | System is booting and DRIVE-CLiQ communication is being established. |
| | | 0.5 Hz flashing light | DRIVE-CLiQ component firmware update in progress. |
| | | 2 Hz flashing light | Component firmware update complete. Waiting for POWER ON of relevant components. |
| DP1 (PROFIdrive cyclic transmission) | --- | OFF | Cyclic communication is not (yet) running. Note: The PROFIdrive is ready for communication when the Control Unit is ready for operation (see RDY LED). |
| | Green | Steady light | Cyclic communication is running. |
| | | 0.5 Hz flashing light | Cyclic communication is not fully underway yet. Possible causes: - The controller is not transmitting any setpoints. - In isochronous mode, the controller did not send a Global Control or it sent a defective Global Control (GC). |
| | Red | Steady light | Cyclic communication has been interrupted. |
| | Orange | 2 Hz flashing light | Firmware checksum error (CRC error). |
| OPT (option) | --- | OFF | Electronic power supply outside permissible tolerance range. The component is not ready for operation. The Option Board is missing or an associated drive object has not been created. |
| | Green | Steady light | Option Board is ready. |
| | | 0.5 Hz flashing light | Depends on the Option Board used. |
| | Red | Steady light | At least one fault is pending on this component. The Option Board is not ready (e.g., after switching on). |
| MOD | --- | OFF | Reserved |

10.2 Diagnosis

Customer Terminal Block TM31 (-A60)

Table 10- 2 Description of the LEDs on the TM31

| LED | Color | State | Description | |
|-----|----------------------------|---------------------|---|--|
| RDY | --- | OFF | The electronics power supply is missing or lies outside permissible tolerance range. | |
| | Green | Steady light | The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place. | |
| | Orange | Steady light | DRIVE-CLiQ communication is being established. | |
| | Red | Steady light | At least one fault is pending on this component. Note: LED is driven irrespective of the corresponding messages being reconfigured. | |
| | Green / red | | 0.5 Hz flashing light | Firmware is being downloaded. |
| | | | 2 Hz flashing light | Firmware download is complete. Waiting for POWER ON. |
| | Green orange or red orange | 2 Hz flashing light | Detection of the components via LED is activated (p0154). Note: Both options depend on the LED status when module recognition is activated via p0154 = 1. | |

Control Interface Module – Interface module in the Power Module (-T1)

Table 10- 3 Description of the LEDs "READY" and "DC LINK" on the Control Interface Module

| LED state | | Description |
|---|---------|---|
| READY | DC LINK | |
| OFF | OFF | The electronics power supply is missing or out of tolerance. |
| Green | OFF | The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place. |
| | Orange | The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place. The DC link voltage is present. |
| | Red | The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place. The DC link voltage is too high. |
| Orange | Orange | DRIVE-CLiQ communication is being established. |
| Red | --- | At least one fault is pending on this component. Note: LED is driven irrespective of the corresponding messages being reconfigured. |
| Flashing, 0.5 Hz: Green/red | --- | Firmware is being downloaded. |
| Flashing, 2 Hz: Green/red | --- | Firmware download is complete. Waiting for POWER ON. |
| Flashing, 2 Hz: Green/orange or red/orange | --- | Detection of the components via LED is activated (p0124). Note: Both options depend on the LED status when module recognition is activated via p0124 = 1. |

Table 10- 4 Meaning of the LED "POWER OK" on the Control Interface Module

| LED | Color | State | Description |
|----------|-------|----------------|--|
| POWER OK | Green | OFF | DC link voltage < 100 V and voltage at -X9:1/2 less than 12 V. |
| | | ON | The component is ready for operation. |
| | | Flashing light | There is a fault. If the LED continues to flash after you have performed a POWER ON, please contact your Siemens service center. |



WARNING

Hazardous DC link voltages may be present at any time regardless of the status of the "DC LINK" LED.
The warning information on the components must be carefully observed!

10.2 Diagnosis

SMC30 – encoder evaluation (-B83)

Table 10- 5 Description of the LEDs on the SMC30

| LED | Color | State | Description | |
|--------------------------------|----------------|---|--|--|
| RDY | --- | OFF | The electronics power supply is missing or lies outside the permissible tolerance range. | |
| | Green | Steady light | The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place. | |
| | Orange | Steady light | DRIVE-CLiQ communication is being established. | |
| | Red | Steady light | At least one fault is pending on this component. Note: LED is driven irrespective of the corresponding messages being reconfigured. | |
| | Green Red | | Flashing, 0.5 Hz | Firmware is being downloaded. |
| | | | Flashing, 2 Hz | Firmware download is complete. Waiting for POWER ON. |
| Green / orange or red / orange | Flashing, 2 Hz | Detection of the components via LED is activated (p0144). Note: Both options depend on the LED status when module recognition is activated via p0144 = 1. | | |
| OUT>5 V | --- | OFF | Electronics power supply is missing or outside permissible tolerance range. Power supply ≤ 5 V. | |
| | Orange | Steady light | Electronic power supply for measuring system present. Supply voltage > 5 V. Notice: You must ensure that the connected encoder can be operated with a 24 V supply. Operating an encoder designed for a 5 V supply with a 24 V supply can damage the encoder electronics beyond repair. | |

CBE20 – Communication Board Ethernet (option G33)

Table 10- 6 Description of the LEDs on the CBE20

| LED | Color | State | Description |
|---------------|--------|--------------|--|
| Link port | --- | OFF | The electronics power supply is missing or lies outside the permissible tolerance range. |
| | Green | Steady light | A different device is connected to port x and a physical connection exists. |
| Activity port | --- | OFF | The electronics power supply is missing or lies outside the permissible tolerance range. |
| | Yellow | Steady light | Data is being received or sent at port x. |

| LED | Color | State | Description |
|-------------------------|--------|------------------|--|
| Fault | --- | OFF | If the link port LED is green: The CBE20 is operating normally, data is being exchanged with the configured IO Controller. |
| | Red | Flashing | <ul style="list-style-type: none"> - The response monitoring time has elapsed. - Communication has been interrupted. - The IP address is incorrect. - Incorrect or missing configuration. - Incorrect parameterization. - Incorrect or missing device name. - IO Controller not present/switched off but Ethernet connection present. - Other CBE20 errors |
| | | Steady light | CBE20 bus fault <ul style="list-style-type: none"> - No physical connection to a subnet/switch. - Incorrect transmission rate. - Full-duplex transmission not activated. |
| Sync | --- | OFF | If the link port LED is green: Control Unit task system is not synchronized with the IRT clock. An internal substitute clock is generated. |
| | Green | Flashing | Control Unit task system has synchronized with the IRT clock and data is being exchanged. |
| | | Steady light | Task system and MC-PLL have synchronized with the IRT clock. |
| OPT on the Control Unit | --- | OFF | The electronics power supply is missing or lies outside the permissible tolerance range. Communication Board either defective or not inserted. |
| | Green | Steady light | Communication Board is ready and cyclic communication is taking place. |
| | | Flashing, 0.5 Hz | The Communication Board is ready, but cyclic communication is not yet taking place. Possible causes: <ul style="list-style-type: none"> - At least one fault is pending. - Communication is being established. |
| | Red | Steady light | Cyclic communication via PROFINET has not yet been established. However, acyclic communication is possible. SINAMICS is waiting for a parameterization/configuration telegram. |
| | | Flashing, 0.5 Hz | The firmware download to the CBE20 has failed. Possible causes: <ul style="list-style-type: none"> - The CBE20 is defective. - The memory card for the Control Unit is defective. In this state, the CBE20 cannot be used. |
| | | Flashing, 2.5 Hz | Communication between the Control Unit and the CBE20 is faulty. Possible causes: <ul style="list-style-type: none"> - The CBE20 was removed following power-up. - The CBE20 is defective. |
| | Orange | Flashing, 2.5 Hz | Firmware is being downloaded. |

10.2 Diagnosis

10.2.2 Diagnostics via parameters

All Objects: key diagnostic parameters (details in List Manual)

| Parameters | Name |
|------------|---|
| | Description |
| r0945 | Fault code |
| | Displays the fault number. Index 0 is the most recent fault (last fault to have occurred). |
| r0948 | Fault time received in milliseconds |
| | Displays the system runtime in ms at which the fault occurred. |
| r0949 | Fault value |
| | Displays additional information about the fault. This information is required for detailed fault diagnosis. |
| r2109 | Fault time removed in milliseconds |
| | Displays the system runtime in ms at which the fault was rectified. |
| r2123 | Alarm time received in milliseconds |
| | Displays the system runtime in ms at which the alarm occurred. |
| r2124 | Alarm value |
| | Displays additional information about the alarm. This information is required for detailed alarm diagnosis. |
| r2125 | Alarm time removed in milliseconds |
| | Displays the system runtime in ms at which the alarm was rectified. |

Control Unit: key diagnostic parameters (details in List Manual)

| Parameters | Name |
|------------|---|
| | Description |
| r0002 | Control Unit status display |
| | Status display for the Control Unit |
| r0018 | Control Unit firmware version |
| | Displays the firmware version of the Control Unit. For the display parameters for the firmware version of the other connected components, see the parameter description in the List Manual. |
| r0721 | Digital inputs actual terminal value |
| | Displays the actual value at the digital input terminals on the CU. This parameter shows the actual value, uninfluenced by simulation mode of the digital inputs. |
| r0722 | Status of digital inputs (CU) |
| | Displays the status of the digital inputs on the CU. This parameter shows the status of the digital inputs under the influence of simulation mode of the digital inputs. |
| r0747 | Status of digital outputs (CU) |
| | Display of the CU digital output status. This parameter shows the status of the digital inputs under the influence of simulation mode of the digital inputs. |
| r2054 | Profibus status |
| | Displays the status of the Profibus interface. |

| Parameters | Name |
|-------------|---|
| | Description |
| r9976[0..7] | System load |
| | Displays the system load. The individual values (computation load and cyclic load) are measured over short time slices; from these values, the maximum, the minimum and the average value are generated and displayed in the appropriate indices. Further, the degree of memory utilization of the data and program memory is displayed. |

VECTOR: key diagnostic parameters (details in List Manual)

| Parameters | Name |
|------------|---|
| | Description |
| r0002 | Operating display |
| | The value provides information about the current operating status and the conditions necessary to reach the next status. |
| r0020 | Speed setpoint smoothed |
| | Displays the actual smoothed speed/velocity setpoint at the input of the speed/velocity controller or V/f characteristic (after the interpolator). |
| r0021 | Actual speed value smoothed |
| | Displays the smoothed actual value of the motor speed/velocity. |
| r0026 | DC link voltage smoothed |
| | Displays the smoothed actual value of the DC link. |
| r0027 | Absolute actual current smoothed |
| | Displays the smoothed actual value of the current. |
| r0031 | Actual torque smoothed |
| | Displays the smoothed actual torque. |
| r0035 | Motor temperature |
| | If r0035 does not equal -200.0 °C, the following applies: |
| | <ul style="list-style-type: none"> This temperature indicator is valid. An KTY sensor is connected. If using an asynchronous motor, the thermal motor model is activated (p0600 = 0 or p0601 = 0). |
| | If r0035 equals -200.0 °C, the following applies: |
| r0037 | Power Module temperatures |
| | Displays the measured temperatures in the Power Module. |
| r0046 | Missing drive enable signals |
| | Displays missing enable signals that are preventing the closed-loop drive control from being commissioned. |
| r0049 | Motor/encoder data set effective (MDS, EDS) |
| | Displays the effective motor data set (MDS) and the effective encoder data sets (EDS). |
| r0050 | Command data set effective (CDS) |
| | Displays the effective command data set (CDS) |

10.2 Diagnosis

| Parameters | Name |
|------------|---|
| | Description |
| r0051 | Drive data set (DDS) effective |
| | Effective drive data set (DDS) display. |
| r0206 | Rated power module power |
| | Displays the rated power module power for various load duty cycles. |
| r0207 | Rated power module current |
| | Displays the rated power module power for various load duty cycles. |
| r0208 | Rated power module line supply voltage |
| | Displays the rated line supply voltage of the power module. |

TM31: key diagnostic parameters (details in List Manual)

| Parameters | Name |
|------------|--|
| | Description |
| r0002 | TM31 operating display |
| | Operating display for terminal board 31 (TB31). |
| r4021 | Digital inputs actual terminal value |
| | Displays the actual value at the digital input terminals on the TM31. This parameter shows the actual value, uninfluenced by simulation mode of the digital inputs. |
| r4022 | Status of digital inputs |
| | Displays the status of the digital inputs on the TM31. This parameter shows the status of the digital inputs under the influence of simulation mode of the digital inputs. |
| r4047 | Status of digital outputs |
| | Displays the status of the TM31 digital outputs. Inversion via p4048 is taken into account. |

Additional diagnostic parameters for units that are connected in parallel (details in List Manual)

For units that are connected in parallel, there are additional diagnostic parameters that provide detailed information about individual Power Modules for a parallel circuit configuration.

- For 380 V – 480 V 3 AC:
6SL3710-2GE41-1AAx, 6SL3710-2GE41-4AAx, 6SL3710-2GE41-6AAx
- For 500 V – 600 V 3 AC:
6SL3710-2GF38-6AAx, 6SL3710-2GF41-1AAx, 6SL3710-2GF41-4AAx
- For 660 V – 690 V 3 AC:
6SL3710-2GH41-1AAx, 6SL3710-2GH41-4AAx, 6SL3710-2GH41-5AAx

r7000 - r7252 Special parameters for Power Modules in a parallel circuit configuration

10.2.3 Indicating and rectifying faults

The device features a wide range of functions that protect the drive against damage if a fault occurs (faults and alarms).

Indicating faults and alarms

If a fault occurs, the drive displays the fault and/or alarm on the AOP30 operator panel. Faults are indicated by the red "FAULT" LED and a fault screen is automatically displayed. You can use the F1 Help function to call up information about the cause of the fault and how to remedy it. You can use F5 Ack. to acknowledge a stored fault.

Any alarms are displayed by the yellow flashing "ALARM" LED. The system also displays a note in the status bar providing information on the cause.

Every fault and alarm is entered in the fault/alarm buffer along with time the error occurred. The time stamp refers to the relative system time in milliseconds (r0969).

Activate the "Set date/time - AOP synchronization -> Drive" setting to date- and time-stamp errors on the AOP30.

What is a fault?

A fault is a message from the drive indicating an error or other exceptional (unwanted) status. This could be caused by a fault within the converter or an external fault triggered, for example, from the winding temperature monitor for the induction motor. The faults are displayed and can be reported to a higher-level control system via PROFIdrive. In the delivery condition, the message "Drive fault" is also sent to a relay output. Once you have rectified the cause of the fault, you have to acknowledge the fault message.

What is an alarm?

An alarm is the response to a fault condition identified by the drive. It does not result in the drive being switched off and does not have to be acknowledged. Alarms are "self acknowledging", that is, they are reset automatically when the cause of the alarm has been eliminated.

10.3 Overview of warnings and faults

If a fault occurs, the drive indicates the fault and/or alarm. Faults and alarms are listed in a fault/alarm list, together with the following information:

- Fault/alarm number
- Standard drive response
- Description of the possible cause of the fault/alarm
- Description of the procedure for rectifying the problem
- Standard fault acknowledgement after it has been rectified

Note

The list of faults and alarms is included on the customer DVD!

It also contains descriptions of the responses (OFF1, OFF2, etc.).

Note

The faults and alarms described below have been wired specially for the cabinet units listed in this document and preset via macro. In this way, the appropriate reaction is triggered by the additional components in the cabinet unit when faults and alarms are signaled.

It is possible to reprogram the faults and alarms described, provided that the stated options are not included in the scope of the equipment.

10.3.1 "External alarm 1"

Causes

Alarm A7850 ("External alarm 1") is triggered by the following optional protection devices in the cabinet unit:

- Temperature sensor for triggering the alarm threshold in the Line Harmonics Filter compact (option L01)
- Thermistor motor protection unit alarm (option L83)
- PT100 Evaluation Unit (Option L86)

Remedy

When a fault is indicated, the following procedure is recommended:

1. Identify the cause by examining the specified devices (display or LEDs).
2. Check the fault display on the relevant protection device and establish the fault.
3. Rectify the displayed fault with the help of the appropriate operating instructions provided in "Additional Operating Instructions".

10.3.2 "External fault 1"

Causes

Fault code F7860 ("External Fault 1") is triggered by the following optional protection devices in the cabinet unit:

- Temperature sensor for triggering the fault threshold in the Line Harmonics Filter compact (option L01)
- Thermistor motor protection unit shutdown (option L84)
- PT100 Evaluation Unit (Option L86)

Remedy

When a fault is indicated, the following procedure is recommended:

1. Identify the cause by examining the specified devices (display or LEDs).
2. Check the fault display on the relevant protection device and establish the fault.
3. Rectify the displayed fault with the help of the appropriate operating instructions provided in "Additional Operating Instructions".

10.3.3 "External fault 2"

Causes

Fault code F7861 ("External Fault 2") is triggered when the braking resistor available with options L61 and L62 is subject to thermal overload, thereby activating the thermostat. The drive is switched off with OFF2.

Remedy

The cause of the braking resistor overload must be eliminated and the fault code acknowledged.

10.4 Service and Support

10.3.4 "External fault 3"

Causes

Fault code F7862 "External fault 3" is triggered when the braking unit fitted for options L61 and L62 triggers a fault. The drive is switched off with OFF2.

Remedy

The cause of the braking unit overload must be eliminated and the fault code acknowledged.

10.4 Service and Support

Technical support

We offer technical support in both German and English for deploying products, systems, and solutions in drive and automation technology.

In special cases, help is available from professional, trained, and experienced specialists via teleservice and video conferencing.

If you have any questions, please contact our hotline:

| Time zone Europe/Africa | |
|-------------------------|---|
| Phone | +49 (0) 911 895 7222 |
| Fax | +49 (0) 911 895 7223 |
| Internet | http://www.siemens.com/automation/support-request |

| Time zone America | |
|-------------------|--|
| Phone | +1 423 262 2522 |
| Fax | +1 423 262 2200 |
| Internet | techsupport.sea@siemens.com |

| Time zone Asia/Pacific | |
|------------------------|--|
| Phone | +86 1064 757 575 |
| Fax | +86 1064 747 474 |
| Internet | support.asia.automation@siemens.com |

10.4.1 Spare parts

The spare parts available for the ordered cabinet unit can be found in the spare parts list.

This list is provided on the customer DVD.

Maintenance and servicing

11

11.1 Chapter content

This chapter provides information on the following:

- Maintenance and servicing procedures that have to be carried out on a regular basis to ensure the availability of the cabinet units.
- Exchanging device components when the unit is serviced
- Forming the DC link capacitors
- Upgrading the cabinet unit firmware
- Loading the new operator panel firmware from the PC.



DANGER

Five safety rules

When carrying out any kind of work on electrical devices, the "five safety rules" must always be observed:

1. Disconnect the system
2. Protect against reconnection.
3. Make sure that the equipment has zero potential
4. Ground and short-circuit.
5. Cover or fence off adjacent components that are still live.



DANGER

Before carrying out any maintenance or repair work on the de-energized cabinet unit, wait for 5 minutes after switching off the supply voltage. This allows the capacitors to discharge to a harmless level (< 25 V) after the supply voltage has been switched off.

Before starting work, you should also measure the voltage after the 5 minutes have elapsed. The voltage can be measured on DC link terminals DCP and DCN.



DANGER

When the external power supply for individual options (L50 / L55) or the external 230 V AC auxiliary supply is connected, dangerous voltages are still present in the cabinet unit even when the main circuit breaker is open.

11.2 Maintenance



DANGER

During connection, installation and repair work on units that are connected in parallel, it must be ensured that both sub-cabinets are electrically disconnected from the power supply.

11.2 Maintenance

The cabinet unit mainly comprises electronic components. Apart from the fan(s), the unit contains very few components that are subject to wear or require maintenance or servicing. Maintenance aims to preserve the specified condition of the cabinet unit. Dirt and contamination must be removed regularly and parts subject to wear replaced.

The following points must generally be observed.

11.2.1 Cleaning

Dust deposits

Dust deposits inside the cabinet unit must be removed at regular intervals (or at least once a year) by qualified personnel in line with the relevant safety regulations. The unit must be cleaned using a brush and vacuum cleaner, and dry compressed air (max. 1 bar) for areas that cannot be easily reached.

Ventilation

The ventilation openings in the cabinet must never be obstructed. The fan must be checked to make sure that it is functioning correctly.

Cable and screw terminals

Cable and screw terminals must be checked regularly to ensure that they are secure in position, and if necessary, retightened. Cabling must be checked for defects. Defective parts must be replaced immediately.

Note

The actual intervals at which maintenance procedures are to be performed depend on the installation conditions (cabinet environment) and the operating conditions.

Siemens offers its customers support in the form of a service contract. For further details, contact your regional office or sales office.

11.3 Maintenance

Servicing involves activities and procedures for maintaining and restoring the specified condition of the device.

Required tools

The following tools are required for replacing components:

- Spanner or socket spanner (w/f 10)
- Spanner or socket spanner (w/f 13)
- Spanner or socket spanner (w/f 16/17)
- Spanner or socket spanner (w/f 18/19)
- Hexagon-socket spanner (size 8)
- Torque wrench from 5 Nm to 50 Nm
- Screwdriver size 1 / 2
- Screwdriver Torx T20
- Screwdriver Torx T30

Tightening torques for current-carrying parts

When securing connections for current-conducting parts (DC link/motor connections, busbars), you must observe the following tightening torques.

Table 11- 1 Tightening torques for connecting current-carrying parts

| Screw | Torque |
|-------|--------|
| M6 | 6 Nm |
| M8 | 13 Nm |
| M10 | 25 Nm |
| M12 | 50 Nm |

11.3 Maintenance

11.3.1 Installation device

Description

The installation device is used for installing and removing the power blocks.

It is used as an installation aid, which is placed in front of and secured to the module. The telescopic guide support allows the withdrawable device to be adjusted according to the height at which the power blocks are installed. Once the mechanical and electrical connections have been removed, the power block can be removed from the module, whereby the power block is guided and supported by the guide rails on the withdrawable devices.



Figure 11-1 Installation device

Order number

Order number for the installation device: 6SL3766-1FA00-0AA0.

11.3.2 Using crane lifting lugs to transport power blocks

Crane lifting lugs

The power blocks are fitted with crane lifting lugs for transportation on a lifting harness in the context of replacement.

The positions of the crane lifting lugs are illustrated by arrows in the figures below.

WARNING

A lifting harness with vertical ropes or chains must be used to prevent any risk of damage to the housing.

CAUTION

The power block busbars must not be used to support or secure lifting harnesses for the purpose of transportation.




Figure 11-2 Crane lifting lugs on FX, GX power block

11.3 Maintenance




Figure 11-3 Crane lifting lugs on HX, JX power block

Note

On HX and JX power blocks, the front crane lifting lug is located behind the busbar.

11.4 Replacing components



WARNING

The following must be taken into account when the devices are transported:

- Some of the devices are heavy or top heavy.
- Due to their weight, the devices must be handled with care by trained personnel.
- Serious injury or even death and substantial material damage can occur if the devices are not lifted or transported properly.



WARNING

The devices are operated with high voltages.

All connection work must be carried out when the cabinet is de-energized!

All work on the device must be carried out by trained personnel only. Non-observance of these warnings can result in death, serious personal injury, or substantial property damage.

Work on an open device must be carried out with extreme caution because external supply voltages may be present. The power and control terminals may be live even when the motor is not running.

Dangerously high voltage levels are still present in the device up to five minutes after it has been disconnected due to the DC link capacitors. For this reason, the unit should not be opened until a reasonable period of time has elapsed.



DANGER

Five safety rules

When carrying out any kind of work on electrical devices, the "five safety rules" according to EN 50110 must always be observed:

1. Disconnect the system
2. Protect against reconnection.
3. Make sure that the equipment has zero potential
4. Ground and short-circuit.
5. Cover or fence off adjacent components that are still live.

11.4 Replacing components

11.4.1 Replacing the filter mats

The filter mats must be checked at regular intervals. If the mats are too dirty to allow the air supply to flow normally, they must be replaced.

Note

Filter mat replacement is only relevant for options M23, M43 and M54.

Not replacing contaminated filter mats can cause premature drive shutdown.

11.4.2 Replacing the Control Interface Module, frame size FX

Replacing the Control Interface Module




Figure 11-4 Replacing the Control Interface Module, frame size FX

11.4 Replacing components

Preparatory steps

- Disconnect the cabinet unit from the power supply.
- Allow unimpeded access.
- Remove the protective cover.

Removal steps

The removal steps are numbered in accordance with the figure.

1. Disconnect the plug-in connections for the fiber-optic cables and signal cables (5 plugs).
2. Remove the DRIVE-CLiQ cables and connections on -X41, -X42, -X46 (6 plugs).
3. Take out the retaining screws for the IPD card (2 screws) and remove the IPD card from plug -X45 on the Control Interface Module.
4. Remove the retaining screws for the Control Interface Module (2 screws).

When removing the Control Interface Module, you have to disconnect 5 further plugs one after the other (2 at the top, 3 below).

| |
|----------------|
| CAUTION |
|----------------|

| |
|--|
| When removing the unit, ensure that you do not damage any signal cables. |
|--|

Installation steps

For installation, carry out the above steps in reverse order.

| |
|----------------|
| CAUTION |
|----------------|

| |
|--|
| The tightening torques specified in the table "Tightening torques for connecting current-conducting parts" must be observed. |
|--|

| |
|--|
| Carefully establish the plug connections and then ensure that they are secure. |
|--|

| |
|--|
| The fiber optic cable plugs must be remounted at their original slot. Fiber optic cables and sockets are accordingly labeled for correct assignment (U11, U21, U31). |
|--|

| |
|--|
| The screw connections for the protective covers must only be tightened finger-tight. |
|--|

11.4.3 Replacing the Control Interface Module, frame size GX

Replacing the Control Interface Module




Figure 11-5 Replacing the Control Interface Module, frame size GX

11.4 Replacing components

Preparatory steps

- Disconnect the cabinet unit from the power supply.
- Allow unimpeded access.
- Remove the protective cover.

Removal steps

The removal steps are numbered in accordance with the figure.

1. Disconnect the plug-in connections for the fiber-optic cables and signal cables (5 plugs).
2. Remove the DRIVE-CLiQ cables and connections on -X41, -X42, -X46 (6 plugs).
3. Take out the retaining screws for the IPD card (2 screws) and remove the IPD card from plug -X45 on the Control Interface Module.
4. Remove the retaining screws for the Control Interface Module (2 screws)

When removing the Control Interface Module, you have to disconnect 5 further plugs one after the other (2 at the top, 3 below).

| |
|----------------|
| CAUTION |
|----------------|

| |
|--|
| When removing the unit, ensure that you do not damage any signal cables. |
|--|

Installation steps

For installation, carry out the above steps in reverse order.

| |
|----------------|
| CAUTION |
|----------------|

| |
|--|
| The tightening torques specified in the table "Tightening torques for connecting current-conducting parts" must be observed. |
|--|

| |
|--|
| Carefully establish the plug connections and then ensure that they are secure. |
|--|

| |
|--|
| The fiber optic cable plugs must be remounted at their original slot. Fiber optic cables and sockets are accordingly labeled for correct assignment (U11, U21, U31). |
|--|

| |
|--|
| The screw connections for the protective covers must only be tightened finger-tight. |
|--|

11.4.4 Replacing the Control Interface Module, frame size HX

Replacing the Control Interface Module




Figure 11-6 Replacing the Control Interface Module, frame size HX

11.4 Replacing components

Preparatory steps

- Disconnect the cabinet unit from the power supply.
- Allow unimpeded access.
- Remove the protective cover.

Removal steps

The removal steps are numbered in accordance with the figure.

1. Disconnect the plug-in connections for the fiber-optic cables and signal cables (5 plugs).
2. Remove the DRIVE-CLiQ cables and connections on -X41, -X42, -X46 (6 plugs).
3. Take out the retaining screws for the IPD card (2 screws) and remove the IPD card from plug -X45 on the Control Interface Module.
4. Remove the retaining screws for the Control Interface Module (2 screws).

When removing the Control Interface Module, you have to disconnect 5 further plugs one after the other (2 at the top, 3 below).

| |
|----------------|
| CAUTION |
|----------------|

| |
|--|
| When removing the unit, ensure that you do not damage any signal cables. |
|--|

Installation steps

For installation, carry out the above steps in reverse order.

| |
|----------------|
| CAUTION |
|----------------|

| |
|--|
| The tightening torques specified in the table "Tightening torques for connecting current-conducting parts" must be observed. |
|--|

| |
|--|
| Carefully establish the plug connections and then ensure that they are secure. |
|--|

| |
|--|
| The fiber optic cable plugs must be remounted at their original slot. Fiber optic cables and sockets are accordingly labeled for correct assignment (U11, U21, U31). |
|--|

| |
|--|
| The screw connections for the protective covers must only be tightened finger-tight. |
|--|

11.4.5 Replacing the Control Interface Module, frame size JX

Replacing the Control Interface Module




Figure 11-7 Replacing the Control Interface Module, frame size JX

11.4 Replacing components

Preparatory steps

- Disconnect the cabinet unit from the power supply.
- Allow unimpeded access.
- Remove the protective cover.

Removal steps

The removal steps are numbered in accordance with the figure.

1. Disconnect the plug-in connections for the fiber-optic cables and signal cables (5 plugs).
2. Remove the DRIVE-CLiQ cables and connections on -X41, -X42, -X46 (6 plugs).
3. Take out the retaining screws for the IPD card (2 screws) and remove the IPD card from plug -X45 on the Control Interface Module.
4. Remove the retaining screws for the Control Interface Module (2 screws).

When removing the Control Interface Module, you have to disconnect 5 further plugs one after the other (2 at the top, 3 below).

| |
|--|
| CAUTION |
| When removing the unit, ensure that you do not damage any signal cables. |

Installation steps

For installation, carry out the above steps in reverse order.

| |
|--|
| CAUTION |
| The tightening torques specified in the table "Tightening torques for connecting current-conducting parts" must be observed. |
| Carefully establish the plug connections and then ensure that they are secure. |
| The fiber optic cable plugs must be remounted at their original slot. Fiber optic cables and sockets are accordingly labeled for correct assignment (U11, U21, U31). |
| The screw connections for the protective covers must only be tightened finger-tight. |

11.4.6 Replacing the power block (type FX)

Replacing the power block




Figure 11-8 Replacing the power block, frame size FX

11.4 Replacing components

Preparatory steps

- Disconnect the cabinet unit from the power supply.
- Allow unimpeded access to the power block.
- Remove the protective cover.
- Removing the Control Interface Module (see corresponding section)

Removal steps

The removal steps are numbered in accordance with the figure.

1. Unscrew the connection to the outgoing motor section (3 screws).
2. Unscrew the connection to the line supply (3 screws).
3. Remove the retaining screws at the top (2 screws).
4. Remove the retaining screws at the bottom (2 screws).
5. Disconnect the plug for the thermocouple.
6. Unscrew the two retaining screws for the fan and attach the equipment for assembling the power block at this position.

You can now remove the power block.

| |
|----------------|
| CAUTION |
|----------------|

| |
|---|
| When removing the power block, ensure that you do not damage any signal cables. |
|---|

Installation steps

For installation, carry out the above steps in reverse order.

| |
|----------------|
| CAUTION |
|----------------|

| |
|--|
| The tightening torques specified in the table "Tightening torques for connecting current-conducting parts" must be observed. |
|--|

| |
|--|
| Carefully establish the plug connections and then ensure that they are secure. |
|--|

| |
|--|
| The screw connections for the protective covers must only be tightened finger-tight. |
|--|

11.4.7 Replacing the power block (type GX)

Replacing the power block




Figure 11-9 Replacing the power block, frame size GX

11.4 Replacing components

Preparatory steps

- Disconnect the cabinet unit from the power supply.
- Allow unimpeded access to the power block.
- Remove the protective cover.
- Removing the Control Interface Module (see corresponding section)

Removal steps

The removal steps are numbered in accordance with the figure.

1. Unscrew the connection to the outgoing motor section (3 screws).
2. Unscrew the connection to the line supply (3 screws).
3. Remove the retaining screws at the top (2 screws).
4. Remove the retaining screws at the bottom (2 screws).
5. Disconnect the plug for the thermocouple.
6. Unscrew the two retaining screws for the fan and attach the equipment for assembling the power block at this position.

You can now remove the power block.

| |
|----------------|
| CAUTION |
|----------------|

| |
|---|
| When removing the power block, ensure that you do not damage any signal cables. |
|---|

Installation steps

For installation, carry out the above steps in reverse order.

| |
|----------------|
| CAUTION |
|----------------|

| |
|--|
| The tightening torques specified in the table "Tightening torques for connecting current-conducting parts" must be observed. |
|--|

| |
|--|
| Carefully establish the plug connections and then ensure that they are secure. |
|--|

| |
|--|
| The screw connections for the protective covers must only be tightened finger-tight. |
|--|

11.4.8 Replacing the power block (type HX)

Replacing the left power block




Figure 11-10 Replacing the power block, frame size HX, left power block

11.4 Replacing components

Preparatory steps

- Disconnect the cabinet unit from the power supply.
- Allow unimpeded access to the power block.
- Remove the protective cover.

Removal steps

The removal steps are numbered in accordance with the figure.

1. Remove the busbar (6 screws).
2. Unscrew the connection to the DC link (8 nuts).
3. Remove the retaining screw at the top (1 screw).
4. Remove the retaining screws at the bottom (2 screws).
5. Disconnect the plug-in connections for the fiber-optic cables and signal cables (3 plugs).
6. Remove the connection for the current transformer and associated PE connection (1 plug).
7. Remove the connection for the DC link sensor (1 nut).
8. Remove the power connections (6 screws).
9. Unscrew the two retaining screws for the fan and attach the tool for de-installing the power block at this position.

You can now remove the power block.

| |
|----------------|
| CAUTION |
|----------------|

| |
|---|
| When removing the power block, ensure that you do not damage any signal cables. |
|---|

Installation steps

For installation, carry out the above steps in reverse order.

| |
|----------------|
| CAUTION |
|----------------|

| |
|--|
| The tightening torques specified in the table "Tightening torques for connecting current-conducting parts" must be observed. |
|--|

| |
|--|
| Carefully establish the plug connections and then ensure that they are secure. |
|--|

| |
|--|
| The screw connections for the protective covers must only be tightened finger-tight. |
|--|

Replacing the right power block




Figure 11-11 Replacing the power block, frame size HX, right power block

11.4 Replacing components

Preparatory steps

- Disconnect the cabinet unit from the power supply.
- Allow unimpeded access to the power block.
- Remove the protective cover.

Removal steps

The removal steps are numbered in accordance with the figure.

1. Remove the busbars (12 screws).
2. Unscrew the connection to the DC link (8 nuts).
3. Remove the retaining screw at the top (1 screw).
4. Remove the retaining screws at the bottom (2 screws).
5. Disconnect the plug-in connections for the fiber-optic cables and signal cables (3 plugs).
6. Remove the connection for the current transformer and associated PE connection (2 plugs).
7. Unscrew the two retaining screws for the fan and attach the tool for de-installing the power block at this position.

You can now remove the power block.

| |
|----------------|
| CAUTION |
|----------------|

| |
|---|
| When removing the power block, ensure that you do not damage any signal cables. |
|---|

Installation steps

For installation, carry out the above steps in reverse order.

| |
|----------------|
| CAUTION |
|----------------|

| |
|--|
| The tightening torques specified in the table "Tightening torques for connecting current-conducting parts" must be observed. |
|--|

| |
|--|
| Carefully establish the plug connections and then ensure that they are secure. |
|--|

| |
|--|
| The screw connections for the protective covers must only be tightened finger-tight. |
|--|

11.4.9 Replacing the power block (type JX)

Replacing the left power block




Figure 11-12 Replacing the power block, frame size JX, left power block

11.4 Replacing components

Preparatory steps

- Disconnect the cabinet unit from the power supply.
- Allow unimpeded access to the power block.
- Remove the protective cover.

Removal steps

The removal steps are numbered in accordance with the figure.

1. Unscrew the connection to the DC link (8 nuts).
2. Remove the retaining screw at the top (1 screw).
3. Remove the retaining screws at the bottom (2 screws).
4. Disconnect the plug-in connections for the fiber-optic cables and signal cables (2 plugs).
5. Remove the connections to the mains supply (6 screws).
6. Unscrew the two retaining screws for the fan and attach the tool for de-installing the power block at this position.

You can now remove the power block.

| |
|---|
| CAUTION |
| When removing the power block, ensure that you do not damage any signal cables. |

Installation steps

For installation, carry out the above steps in reverse order.

| |
|--|
| CAUTION |
| The tightening torques specified in the table "Tightening torques for connecting current-conducting parts" must be observed. |
| Carefully establish the plug connections and then ensure that they are secure. |
| The screw connections for the protective covers must only be tightened finger-tight. |

Replacing the right power block




Figure 11-13 Replacing the power block, frame size JX, right power block

11.4 Replacing components

Preparatory steps

- Disconnect the cabinet unit from the power supply.
- Allow unimpeded access to the power block.
- Remove the protective cover.

Removal steps

The removal steps are numbered in accordance with the figure.

1. Remove the busbar (8 screws).
2. Unscrew the connection to the DC link (8 nuts).
3. Remove the retaining screw at the top (1 screw).
4. Remove the retaining screws at the bottom (2 screws).
5. Disconnect the plug-in connections for the fiber-optic cables and signal cables (2 plugs).
6. Remove the connection for the current transformer and associated PE connection (1 plug).
7. Unscrew the two retaining screws for the fan and attach the tool for de-installing the power block at this position.

You can now remove the power block.

| |
|----------------|
| CAUTION |
|----------------|

| |
|---|
| When removing the power block, ensure that you do not damage any signal cables. |
|---|

Installation steps

For installation, carry out the above steps in reverse order.

| |
|----------------|
| CAUTION |
|----------------|

| |
|--|
| The tightening torques specified in the table "Tightening torques for connecting current-conducting parts" must be observed. |
|--|

| |
|--|
| Carefully establish the plug connections and then ensure that they are secure. |
|--|

| |
|--|
| The screw connections for the protective covers must only be tightened finger-tight. |
|--|

11.4.10 Replacing the fan (type FX)

Replacing the fan




Figure 11-14 Replacing the fan (frame size FX)

11.4 Replacing components

Description

The average service life of the device fans is 50,000 hours. In practice, however, the service life depends on other variables (e.g. ambient temperature, degree of cabinet protection, etc.) and, therefore, may deviate from this value.

The fans must be replaced in good time to ensure that the cabinet unit is available.

Preparatory steps

- Disconnect the cabinet unit from the power supply.
- Allow unimpeded access.
- Remove the protective cover.

Removal

The steps for the removal procedure are numbered in accordance with the diagram.

1. Remove the retaining screws for the fan (2 screws).
2. Disconnect the supply cables (1 x "L", 1 x "N").

You can now carefully remove the fan.

| |
|---|
| CAUTION |
| When removing the fan, ensure that you do not damage any signal cables. |

Installation

For re-installation, carry out the above steps in reverse order.

| |
|--|
| CAUTION |
| The tightening torques specified in the table "Tightening torques for connecting current-carrying parts" must be observed. |
| Carefully re-establish the plug connections and ensure that they are secure. |
| The screwed connections for the protective covers must only be tightened by hand. |

11.4.11 Replacing the fan (type GX)

Replacing the fan




Figure 11-15 Replacing the fan (frame size GX)

11.4 Replacing components

Description

The average service life of the device fans is 50,000 hours. In practice, however, the service life depends on other variables (e.g. ambient temperature, degree of cabinet protection, etc.) and, therefore, may deviate from this value.

The fans must be replaced in good time to ensure that the cabinet unit is available.

Preparatory steps

- Disconnect the cabinet unit from the power supply.
- Allow unimpeded access.
- Remove the protective cover.

Removal

The steps for the removal procedure are numbered in accordance with the diagram.

1. Remove the retaining screws for the fan (3 screws).
2. Disconnect the supply cables (1 x "L", 1 x "N").

You can now carefully remove the fan.

| |
|----------------|
| CAUTION |
|----------------|

| |
|---|
| When removing the fan, ensure that you do not damage any signal cables. |
|---|

Installation

For re-installation, carry out the above steps in reverse order.

| |
|----------------|
| CAUTION |
|----------------|

| |
|--|
| The tightening torques specified in the table "Tightening torques for connecting current-carrying parts" must be observed. |
|--|

| |
|--|
| Carefully re-establish the plug connections and ensure that they are secure. |
|--|

| |
|---|
| The screwed connections for the protective covers must only be tightened by hand. |
|---|

11.4.12 Replacing the fan (type HX)

Replacing the fan (left-hand power block)




Figure 11-16 Replacing the fan (frame size HX) (left-hand power block)

11.4 Replacing components

Description

The average service life of the device fans is 50,000 hours. In practice, however, the service life depends on other variables (e.g. ambient temperature, degree of cabinet protection, etc.) and, therefore, may deviate from this value.

The fans must be replaced in good time to ensure that the cabinet unit is available.

Preparatory steps

- Disconnect the cabinet unit from the power supply.
- Allow unimpeded access.
- Remove the protective cover.

Removal steps

The removal steps are numbered in accordance with the figure.

1. Remove the busbar (6 screws).
2. Remove the retaining screws for the fan (3 screws).
3. Disconnect the supply cables (1 x "L", 1 x "N").

You can now carefully remove the fan.

| |
|----------------|
| CAUTION |
|----------------|

| |
|--|
| When removing the unit, ensure that you do not damage any signal cables. |
|--|

Installation steps

For installation, carry out the above steps in reverse order.

| |
|----------------|
| CAUTION |
|----------------|

| |
|--|
| The tightening torques specified in the table "Tightening torques for connecting current-conducting parts" must be observed. |
|--|

| |
|---|
| Carefully establish the plug-in connections and then ensure that they are secure. |
|---|

| |
|---|
| The screwed connections for the protective covers must only be tightened by hand. |
|---|

Replacing the fan (right-hand power block)




Figure 11-17 Replacing the fan (frame size HX) (right-hand power block)

11.4 Replacing components

Description

The average service life of the device fans is 50,000 hours. In practice, however, the service life depends on other variables (e.g. ambient temperature, degree of cabinet protection, etc.) and, therefore, may deviate from this value.

The fans must be replaced in good time to ensure that the cabinet unit is available.

Preparatory steps

- Disconnect the cabinet unit from the power supply.
- Allow unimpeded access.
- Remove the protective cover.

Removal steps

The removal steps are numbered in accordance with the figure.

1. Remove the busbar (12 screws).
2. Remove the retaining screws for the fan (3 screws).
3. Disconnect the supply cables (1 x "L", 1 x "N").

You can now carefully remove the fan.

| |
|--|
| CAUTION |
| When removing the unit, ensure that you do not damage any signal cables. |

Installation steps

For installation, carry out the above steps in reverse order.

| |
|--|
| CAUTION |
| The tightening torques specified in the table "Tightening torques for connecting current-conducting parts" must be observed. |
| Carefully establish the plug-in connections and then ensure that they are secure. |
| The screwed connections for the protective covers must only be tightened by hand. |

11.4.13 Replacing the fan (type JX)

Replacing the fan (left-hand power block)




Figure 11-18 Replacing the fan (frame size JX) (left-hand power block)

11.4 Replacing components

Description

The average service life of the device fans is 50,000 hours. In practice, however, the service life depends on other variables (e.g. ambient temperature, degree of cabinet protection, etc.) and, therefore, may deviate from this value.

The fans must be replaced in good time to ensure that the cabinet unit is available.

Preparatory steps

- Disconnect the cabinet unit from the power supply.
- Allow unimpeded access.
- Remove the protective cover.

Removal steps

The removal steps are numbered in accordance with the figure.

1. Remove the retaining screws for the fan (3 screws).
2. Disconnect the supply cables (1 x "L", 1 x "N").

You can now carefully remove the fan.

| |
|--|
| CAUTION |
| When removing the unit, ensure that you do not damage any signal cables. |

Installation steps

For installation, carry out the above steps in reverse order.

| |
|--|
| CAUTION |
| The tightening torques specified in the table "Tightening torques for connecting current-conducting parts" must be observed. |
| Carefully establish the plug-in connections and then ensure that they are secure. |
| The screwed connections for the protective covers must only be tightened by hand. |

Replacing the fan (right-hand power block)




Figure 11-19 Replacing the fan (frame size JX) (right-hand power block)

11.4 Replacing components

Description

The average service life of the device fans is 50,000 hours. In practice, however, the service life depends on other variables (e.g. ambient temperature, degree of cabinet protection, etc.) and, therefore, may deviate from this value.

The fans must be replaced in good time to ensure that the cabinet unit is available.

Preparatory steps

- Disconnect the cabinet unit from the power supply.
- Allow unimpeded access.
- Remove the protective cover.

Removal steps

The removal steps are numbered in accordance with the figure.

1. Remove the busbar (8 screws).
2. Remove the retaining screws for the fan (3 screws).
3. Disconnect the supply cables (1 x "L", 1 x "N").

You can now carefully remove the fan.

| |
|----------------|
| CAUTION |
|----------------|

| |
|--|
| When removing the unit, ensure that you do not damage any signal cables. |
|--|

Installation steps

For installation, carry out the above steps in reverse order.

| |
|----------------|
| CAUTION |
|----------------|

| |
|--|
| The tightening torques specified in the table "Tightening torques for connecting current-conducting parts" must be observed. |
|--|

| |
|---|
| Carefully establish the plug-in connections and then ensure that they are secure. |
|---|

| |
|---|
| The screwed connections for the protective covers must only be tightened by hand. |
|---|

11.4.14 Replacing the fan fuse (-T1 -F10 / -T1 -F11)

The order numbers for replacement fan fuses can be found in the spare parts list.

 **WARNING**

Make sure that the cause of the fault is found before the fuse is replaced.

11.4.15 Replacing the fuses for the auxiliary power supply (-A1 -F11 / -A1 -F12)

The order numbers for replacing auxiliary power supply fuses that have blown can be found in the spare parts list.

 **WARNING**

You must carry out the following:

- First disconnect the auxiliary power supply.
- Then rectify the cause of the fault.
- Replace the fuse.

11.4.16 Replacing the fuse -A1 -F21

1. Open the cabinet.
2. Remove the defective fuse.
3. Fit the replacement fuse and close the fuse holder.
4. Close the cabinet.

The order numbers for replacing fuses that have blown can be found in the spare parts list.

 **WARNING**

You must carry out the following:

- First disconnect the auxiliary power supply.
- Then rectify the cause of the fault.
- Replace the fuse.

11.4 Replacing components

11.4.17 Replacing the cabinet operator panel

1. Switch the unit into a no-voltage condition.
2. Open the cabinet.
3. Disconnect the power supply and communications line on the operator panel.
4. Release the fastenings on the operator panel.
5. Remove the operator panel.
6. Install the new operator panel.
7. Carry out any other work by reversing the sequence.

11.4.18 Replacing the Backup Battery for the Cabinet Operator Panel

Table 11- 2 Technical specifications of the backup battery

| | |
|-------------------------------|--|
| Type | CR2032 3 V lithium battery |
| Manufacturer | Maxell, Sony, Panasonic |
| Nominal capacity | 220 mAh |
| Self-discharge at 20 °C | 1 %/year |
| Service life (in backup mode) | > 1 year at 70 °C; >1.5 years at 20 °C |
| Service life (in operation) | > 2 years |

Replacement

1. Switch the unit into a no-voltage condition.
2. Open the cabinet.
3. Disconnect the 24 V DC power supply and communications line on the operator panel.
4. Open the cover of the battery compartment.
5. Remove the old battery.
6. Insert the new battery.
7. Close the cover of the battery compartment.
8. Reconnect the 24 V DC power supply and communications line.
9. Close the cabinet.

NOTICE

The battery must be replaced within one minute to ensure that no AOP settings are lost.



Figure 11-20 Replacing the backup battery for the cabinet operator panel

Note

The battery must be disposed of in accordance with the applicable country-specific guidelines and regulations.

11.5 Forming the DC link capacitors

Description

If the device is kept in storage for more than 2 years, the DC link capacitors have to be re-formed. If this is not done, the unit could be damaged when it is operated under load.

If the cabinet is commissioned within two years of its date of manufacture, the DC link capacitors do not need to be re-formed. The date of manufacture is indicated in the serial number on the type plate (see "Device Overview").

Note

It is important that the storage period is calculated from the date of manufacture and not from the date that the equipment was shipped.

Procedure

The DC link capacitors are re-formed by applying the rated voltage without load for at least 30 minutes at room temperature.

- Operation via PROFIBUS:
 - Set bit 3 of control word 1 (operation enable) permanently to "0".
 - Switch on the converter by means of an ON signal (bit 0 of the control word); all the other bits must be set in such a way that the converter can be operated.
 - Once the delay time has elapsed, switch off the converter and restore the original PROFIBUS setting.
- Operation via terminal block:
 - Set p0852 to "0" (factory setting is "1").
 - Switch on the converter (via digital input 0 on the customer terminal block).
 - Once the delay time has elapsed, switch off the converter and restore the original setting for p0852.

Note

Reforming cannot be carried out in LOCAL mode via the AOP30.

11.6 Messages after replacing DRIVE-CLiQ components

After DRIVE-CLiQ components are replaced (Control Interface Module, TM31, SMCxx) when service is required, generally no message is output after power-up, since an identical component is identified and accepted as component when the system boots.

The reason for this is that an identical component is detected and accepted as spare part when running-up. If, unexpectedly, a fault message of the "topology fault" category is displayed, then when replacing a component, one of the following faults/errors should have occurred:

- A Control Interface Module with different firmware data was installed.
- When connecting-up DRIVE-CLiQ cables, connections were interchanged.

Automatic firmware update

As of firmware 2.5, an automatic firmware update can be carried out once the electronics have been powered up on replacement DRIVE-CLiQ components.

- The following LEDs will flash slowly to indicate that an automatic firmware update is in progress: the "RDY" LED on the Control Unit (orange, 0.5 Hz) and an LED on the relevant DRIVE-CLiQ component (green/red, 0.5 Hz).

| |
|----------------|
| CAUTION |
|----------------|

| |
|--|
| The drive converter must not be shut down during this process! |
|--|

- Once the automatic firmware update is complete, the "RDY" LED on the Control Unit will flash quickly (orange, 2 Hz) along with an LED on the relevant DRIVE-CLiQ component (green/red, 2 Hz).
- To complete the automatic firmware update process, a POWER ON is required (switch the device off and back on again).

11.7 Upgrading the cabinet unit firmware

When you upgrade the cabinet unit firmware (by installing a new CompactFlash Card with a new firmware version, for example), you might also have to upgrade the firmware for the DRIVE-CLiQ components in the cabinet unit.

If the system detects that the firmware in the DRIVE-CLiQ components needs to be updated, it will trigger this process automatically when the automatic firmware update is performed.

Automatic firmware update sequence

1. During an automatic firmware update, the "RDY" LED on the Control Unit flashes slowly (orange, 0.5 Hz).
2. The firmware update is performed automatically and in sequence on the DRIVE-CLiQ components; during the update process, an LED on the component whose firmware is being updated will flash slowly (green/red, 0.5 Hz).
3. Once the firmware update on an individual DRIVE-CLiQ component is complete, the LED on that component will flash quickly (green/red, 2 Hz).
4. Once the firmware update on all components is complete, the LED on the Control Unit will flash quickly (orange, 2 Hz).
5. To complete the automatic firmware update process, a POWER ON is required (switch the device off and back on again).

| |
|--|
| CAUTION |
| The power supply to the components must not be interrupted while the firmware is being upgraded. |

| |
|--|
| CAUTION |
| New firmware should only be installed if there is a problem with the cabinet unit. |

11.8 Load the new operator panel firmware from the PC.

Description

Firmware might need to be loaded to the AOP if the AOP functionality needs to be upgraded.

If, once the drive has powered up, the CompactFlash Card is found to contain a newer version of the firmware, a message will appear on the AOP30 prompting you to load the new firmware. You should click "YES" in response to this prompt.

The firmware will then be loaded automatically on the operator panel and the following dialog screen will appear.




Figure 11-21 Dialog screen: loading firmware

If the firmware cannot be loaded successfully, it can be loaded using the following manual method.

The load program LOAD_AOP30 and the firmware file can be found on the customer DVD.

Loading the firmware

1. Establish the RS232 connection from the PC to the AOP30.
2. Provide the supply voltage (24 V DC).
3. Start the LOAD_AOP30 program on the PC.
4. Choose the PC interface (COM1, COM2).
5. Choose and open the firmware (AOP30.H86).
6. Follow the instructions in the status window of the program and connect the power supply for the AOP30 while pressing the red key (O).
7. The load procedure is started automatically.
8. Switch the power on (switch the power supply off and then back on).

11.8 Load the new operator panel firmware from the PC.

Technical specifications

12

12.1 Chapter content

This chapter provides information on the following:

- General and specific technical specifications for the devices.
- Information on restrictions that apply when the devices are used in unfavorable ambient conditions (derating)

12.2 General data

12.2 General data

Table 12- 1 General technical specifications

| Electrical data | | | |
|--|--|--|--|
| Line system configurations | TN/TT supplies or insulated supplies (IT supplies) | | |
| Line frequency | 47 ... 63 Hz | | |
| Output frequency | 0 ... 300 Hz | | |
| Power factor | ≥ 0.98 | | |
| - Fundamental mode | 0.93 ... 0.96 | | |
| - Total | | | |
| Converter efficiency | > 98 % | | |
| Switching at input | Once every 3 minutes | | |
| Mechanical data | | | |
| Degree of protection | IP20 (higher degrees of protection up to IP54 optional) | | |
| Class of protection | I acc. to EN 61800-5-1 | | |
| Cooling method | Forced air cooling AF to EN 60146 | | |
| Sound pressure level L_{pA} (1 m) | <ul style="list-style-type: none"> at 50 Hz line frequency ≤ 72 dB(A) (single units) / ≤ 75 dB(A) (units that are connected in parallel) at 60 Hz line frequency ≤ 75 dB(A) (single units) / ≤ 78 dB(A) (units that are connected in parallel) | | |
| Touch protection | EN 50274 and BGV A3 when used as intended | | |
| Cabinet system | Rittal TS 8, doors with double-barb lock, three-section base plates for cable entry | | |
| Paint finish | RAL 7035 (indoor requirements) | | |
| Compliance with standards | | | |
| Standards | EN 60146-1, EN 61800-2, EN 61800-3, EN 50178 ²⁾ , EN 61800-5-1, EN 60204-1, EN 60529 ³⁾ | | |
| CE mark | To EMC directive No. 2004/108/EC and low-voltage directive No. 2006/95/EC | | |
| RI suppression | In accordance with the EMC product standard for variable-speed drives EN 61800-3, "second environment". Application in "first environment" possible with line filters (option L00) ¹⁾ . | | |
| Ambient conditions | Storage | Transport | During operation |
| Ambient temperature | -25 ... +55 °C | -25 ... +70°C as of -40 °C for 24 hours | 0 ... +40 °C up to +50 °C with derating |
| Humidity range ³⁾ (non-condensing) corresponds to class | 5 to 95 % 1K4 to EN 60721-3-1 | 5 ... 95 % at 40 °C 2K3 to EN 60721-3-2 | 5 ... 95 % 3K3 to EN 60721-3-3 |
| Environmental class/harmful chemical substances ³⁾ | 1C2 to EN 60721-3-1 | 2C2 to EN 60721-3-2 | 3C2 to EN 60721-3-3 |
| Organic/biological influences ³⁾ | 1B1 to EN 60721-3-1 | 2B1 to EN 60721-3-2 | 3B1 to EN 60721-3-3 |
| Installation altitude | Up to 2000 m above sea level without derating, > 2000 m above sea level with derating (see "Derating data") | | |

| Electrical data | | | |
|--|---|---|--|
| Mechanical stability | Storage | Transport | During operation |
| Vibrational load ³⁾ - Displacement - Acceleration corresponds to class | 1.5 mm at 5 to 9 Hz 5 m/s ² at > 9 to 200 Hz 1M2 to EN 60721-3-1 | <i>3.1 mm</i> at 5 ... 9 Hz 10 m/s ² at > 9 ... 200 Hz 2M2 to EN 60721-3-2 | 0.075 mm at 10 ... 58 Hz 10 m/s ² at >58 ... 200 Hz - |
| Shock load ³⁾ - Acceleration corresponds to class | 40 m/s ² at 22 ms 1M2 to EN 60721-3-1 | 100 m/s ² at 11 ms 2M2 to EN 60721-3-2 | 100 m/s ² at 11 ms 3M4 to EN 60721-3-3 |

Deviations from the defined classes are shown in *italics*.

¹⁾ Applies to cable lengths of up to 100 m.

²⁾ The EN standard specified is the European edition of international standard IEC 62103.

³⁾ The EN standards specified are the European editions of the international IEC standards with the same designations.

12.2.1 Derating data

Permissible output current as a function of the ambient temperature

The cabinet devices and the associated system components are rated for an ambient temperature of 40 °C and installation altitudes up to 2000 m above sea level. The output current must be reduced if the cabinet devices are operated at ambient temperatures above 40 °C. Ambient temperatures above 50 °C are not permissible. The following tables specify the permissible output current as a function of the ambient temperature for the different degrees of protection .

Table 12- 2 Current derating factors as a function of the ambient temperature (inlet air temperature at the air inlet of the cabinet unit) and installation altitude for cabinet units with degree of protection IP20/IP21/IP23/IP43

| Installation altitude above sea level in m | Current derating factor at an ambient temperature (air intake temperature) of | | | | | | |
|---|--|-------|-------|-------|-------|--------|--------|
| | 20 °C | 25 °C | 30 °C | 35 °C | 40 °C | 45 °C | 50 °C |
| 0 ... 2000 | 100 % | 100 % | 100 % | 100 % | 100 % | 93.3 % | 86.7 % |

Table 12- 3 Current derating factors as a function of the ambient temperature (inlet air temperature at the air inlet of the cabinet unit) and installation altitude for cabinet units with degree of protection IP54

| Installation altitude above sea level in m | Current derating factor at an ambient temperature (air intake temperature) of | | | | | | |
|---|--|-------|-------|-------|--------|--------|--------|
| | 20 °C | 25 °C | 30 °C | 35 °C | 40 °C | 45 °C | 50 °C |
| 0 ... 2000 | 100 % | 100 % | 100 % | 100 % | 93.3 % | 86.7 % | 80.0 % |

12.2 General data

Installation altitudes between 2000 m and 5000 m above sea level

If the SINAMICS G150 cabinet units are operated at an installation altitude >2000 m above sea level, it must be taken into account that the air pressure and, consequently, the air density decreases. The lower air density also reduces the cooling efficiency and the insulation capacity of the air.

Installation altitudes between 2000 m and 5000 m can be achieved by applying the following measures.

Reduce the ambient temperature and the output current

Due to the reduced cooling efficiency, it is necessary, on the one hand, to reduce the ambient temperature and, on the other, to lower heat loss in the cabinet unit by reducing the output current, whereby ambient temperatures lower than 40 °C may be offset to compensate. The following tables specify the permissible output currents as a function of installation altitude and ambient temperature for the different degrees of protection. The specified values already include a permitted correction in respect of installation altitude and ambient temperatures less than 40 °C (incoming air temperature at the inlet to the cabinet unit). The values apply under the precondition that the cabinet layout ensures a cooling air flow through the units as stated in the technical specifications.

Table 12- 4 Current derating as a function of ambient temperature (inlet air temperature at the air inlet of the cabinet unit) and installation altitude for cabinet units with degree of protection IP20/IP21/IP23/IP43

| Installation altitude above sea level in m | Current derating factor at an ambient temperature (air intake temperature) of | | | | | | |
|---|--|--------|--------|--------|--------|--------|--------|
| | 20 °C | 25 °C | 30 °C | 35 °C | 40 °C | 45 °C | 50 °C |
| 0 ... 2000 | 100 % | 100 % | 100 % | 100 % | 100 % | 93.3 % | 86.7 % |
| ... 2500 | 100 % | 100 % | 100 % | 100 % | 96.3 % | | |
| ... 3000 | 100 % | 100 % | 100 % | 98.7 % | | | |
| ... 3500 | 100 % | 100 % | 100 % | | | | |
| ... 4000 | 100 % | 100 % | 96.3 % | | | | |
| ... 4500 | 100 % | 97.5 % | | | | | |
| ... 5000 | 98.2 % | | | | | | |

Table 12- 5 Current derating as a function of the ambient temperature (inlet air temperature at the air inlet of the cabinet unit) and installation altitude for cabinet units with degree of protection IP54

| Installation altitude above sea level in m | Current derating factor at an ambient temperature (air intake temperature) of | | | | | | |
|---|--|--------|--------|--------|--------|--------|--------|
| | 20 °C | 25 °C | 30 °C | 35 °C | 40 °C | 45 °C | 50 °C |
| 0 ... 2000 | 100 % | 100 % | 100 % | 100 % | 93.3 % | 86.7 % | 80.0 % |
| ... 2500 | 100 % | 100 % | 100 % | 96.3 % | 89.8 % | | |
| ... 3000 | 100 % | 100 % | 98.7 % | 92.5 % | | | |
| ... 3500 | 100 % | 100 % | 94.7 % | | | | |
| ... 4000 | 100 % | 96.3 % | 90.7 % | | | | |
| ... 4500 | 97.5 % | 92.1 % | | | | | |
| ... 5000 | 93.0 % | | | | | | |

Using an isolating transformer to reduce transient overvoltages according to IEC 61800-5-1

This drops overvoltage category III to overvoltage category II, thereby reducing the requirements for insulation capacity of the air. Additional voltage derating (reduction of the input voltage) is not required if the following framework conditions are observed:

- The isolating transformer must be fed from a low-voltage or medium-voltage network and must not be power directly from a high-voltage supply system.
- The isolating transformer may be connect to one or more cabinet units.
- The cables between the isolating transformer and the cabinet unit(s) must be routed in such a manner as to rule out direct lightning strike, i.e. overland lines must not be used.
- The following types of system are permissible:
 - TN systems with grounded star point (no grounded outer conductor).
 - IT systems (operation with a ground fault must be restricted to the shorted possible time).

12.2 General data

Current derating as a function of the pulse frequency

When the pulse frequency is increased, the derating factor of the output current must be taken into account. This derating factor must be applied to the currents specified in the technical specifications for the cabinet units.

Table 12- 6 Derating factor of the output current as a function of the pulse frequency for devices with a rated pulse frequency of 2 kHz

| Order no. 6SL3710-... | Power [kW] | Output current at 2 kHz [A] | Derating factor at 4 kHz |
|--|---------------|--------------------------------|--------------------------|
| Supply voltage 380 – 480 V 3 AC | | | |
| 1GE32-1_Ax | 110 | 210 | 82 % |
| 1GE32-6_Ax | 132 | 260 | 83 % |
| 1GE33-1_Ax | 160 | 310 | 88 % |
| 1GE33-8_Ax | 200 | 380 | 87 % |
| 1GE35-0_Ax | 250 | 490 | 78 % |

Table 12- 7 Derating factor of the output current as a function of the pulse frequency for units with a rated pulse frequency of 1.25 kHz

| Order no. 6SL3710-... | Power [kW] | Output current at 1.25 kHz [A] | Derating factor at 2.5 kHz | Derating factor at 5 kHz |
|--|---------------|-----------------------------------|-------------------------------|-----------------------------|
| Supply voltage 380 – 480 V 3 AC | | | | |
| 1GE36-1_Ax | 315 | 605 | 72 % | 60 % |
| 1GE37-5_Ax | 400 | 745 | 72 % | 60 % |
| 1GE38-4_Ax | 450 | 840 | 79 % | 60 % |
| 1GE41-0_Ax | 560 | 985 | 87 % | 60 % |
| 2GE41-1AAx | 630 | 1120 | 72 % | 60 % |
| 2GE41-4AAx | 710 | 1380 | 72 % | 60 % |
| 2GE41-6AAx | 900 | 1560 | 79 % | 60 % |
| Supply voltage 500 – 600 V 3 AC | | | | |
| 1GF31-8_Ax | 110 | 175 | 87 % | 60 % |
| 1GF32-2_Ax | 132 | 215 | 87 % | 60 % |
| 1GF32-6_Ax | 160 | 260 | 88 % | 60 % |
| 1GF33-3_Ax | 200 | 330 | 82 % | 55 % |
| 1GF34-1_Ax | 250 | 410 | 82 % | 55 % |
| 1GF34-7_Ax | 315 | 465 | 87 % | 55 % |
| 1GF35-8_Ax | 400 | 575 | 85 % | 55 % |
| 1GF37-4_Ax | 500 | 735 | 79 % | 55 % |
| 1GF38-1_Ax | 560 | 810 | 72 % | 55 % |
| 2GF38-6AAx | 630 | 860 | 87 % | 55 % |
| 2GF41-1AAx | 710 | 1070 | 85 % | 55 % |
| 2GF41-4AAx | 1000 | 1360 | 79 % | 55 % |

| Order no. 6SL3710-... | Power [kW] | Output current at 1.25 kHz [A] | Derating factor at 2.5 kHz | Derating factor at 5 kHz |
|--|---------------|-----------------------------------|-------------------------------|-----------------------------|
| Supply voltage 660 – 690 V 3 AC | | | | |
| 1GH28-5_Ax | 75 | 85 | 89 % | 60 % |
| 1GH31-0_Ax | 90 | 100 | 88 % | 60 % |
| 1GH31-2_Ax | 110 | 120 | 88 % | 60 % |
| 1GH31-5_Ax | 132 | 150 | 84 % | 55 % |
| 1GH31-8_Ax | 160 | 175 | 87 % | 60 % |
| 1GH32-2_Ax | 200 | 215 | 87 % | 60 % |
| 1GH32-6_Ax | 250 | 260 | 88 % | 60 % |
| 1GH33-3_Ax | 315 | 330 | 82 % | 55 % |
| 1GH34-1_Ax | 400 | 410 | 82 % | 55 % |
| 1GH34-7_Ax | 450 | 465 | 87 % | 55 % |
| 1GH35-8_Ax | 560 | 575 | 85 % | 55 % |
| 1GH37-4_Ax | 710 | 735 | 79 % | 55 % |
| 1GH38-1_Ax | 800 | 810 | 72 % | 55 % |
| 2GH41-1AAx | 1000 | 1070 | 85 % | 55 % |
| 2GH41-4AAx | 1350 | 1360 | 79 % | 55 % |
| 2GH41-5AAx | 1500 | 1500 | 72 % | 55 % |

For pulse frequencies in the range between the fixed values, the relevant derating factors can be determined by means of linear interpolation.

$$Y_2 = Y_0 + \frac{Y_1 - Y_0}{X_1 - X_0} (X_2 - X_0)$$

The following formula applies for this:

Example:

The derating factor is required for when $X_2 = 2$ kHz for 6SL3710-1GE41-0_Ax.

$X_0 = 1.25$ kHz, $Y_0 = 100\%$, $X_1 = 2.5$ kHz, $Y_1 = 87\%$, $X_2 = 2$ kHz, $Y_2 = ??$

$$Y_2 = 100 \% + \frac{87 \% - 100 \%}{2.5 \text{ kHz} - 1.25 \text{ kHz}} (2 \text{ kHz} - 1.25 \text{ kHz}) =$$

$$100 \% + \frac{-13 \%}{1.25 \text{ kHz}} (0.75 \text{ kHz}) = 100 \% - 7.8 \% = \underline{\underline{92.2 \%}}$$




Figure 12-1 Calculating derating factors by means of linear interpolation

12.2 General data

12.2.2 Overload capability

The converter is equipped with an overload reserve to deal with breakaway torques, for example.

In drives with overload requirements, the appropriate base load current must, therefore, be used as a basis for the required load.

The criterion for overload is that the drive is operated with its base load current before and after the overload occurs on the basis of a duty cycle duration of 300 s.

Low overload

The base load current for low overload (I_L) is based on a load duty cycle of 110% for 60 s or 150% for 10 s.




Figure 12-2 Low overload

High overload

The base load current for a high overload I_H is based on a duty cycle of 150% for 60 s or 160% for 10 s.




Figure 12-3 High overload



12.3 Technical specifications

Note

Current, voltage and power figures in these tables are rated values.

The cables to the device are protected by fuses of operating class gG.

The cable cross-sections have been determined for three-core copper cables routed horizontally in air at 40 °C ambient temperature (according to DIN VDE 0276-1000 and IEC 60364-5-52) with a permissible operating temperature of 70°C (e.g. Protodur NYY or NYCWY) and the recommended conductor protection according to DIN VDE 0100 section 430 and IEC 60364-4-43.

CAUTION

When the conditions differ from the above stated (cable routing, cable grouping, ambient temperature), the following instructions for routing the cables must be taken into account:

The required cable cross-section depends on the amperage which flows through the cable. The permissible current loading of cables is defined, for example, in DIN VDE 0276-1000 and IEC 60364-5-52. It depends partly on ambient conditions such as temperature and partly on the type of routing. If the cables are routed individually, they will be cooled relatively well. If several cables are routed together, they may heat each other up. Please note the corresponding derating factors for these supplementary conditions in DIN VDE 0276-1000 and IEC 60364-5-52.

12.3 Technical specifications

12.3.1 Cabinet unit version A, 380 V - 480 V 3 AC

Table 12- 8 Version A, 380 V – 480 V 3 AC, part 1

| Order number | 6SL3710- | 1GE32-1AAx | 1GE32-6AAx | 1GE33-1AAx |
|--|---|--|------------------------------------|-------------------------------------|
| Unit rating - for I _L at 50 Hz 400 V ¹⁾ - for I _H at 50 Hz 400 V ¹⁾ - for I _L at 60 Hz 460 V ²⁾ - for I _H at 60 Hz 460 V ²⁾ | kW kW hp hp | 110 90 150 125 | 132 110 200 150 | 160 132 250 200 |
| Output current - Rated current I _N - Base load current I _L ³⁾ - Base load current I _H ⁴⁾ | A A A | 210 205 178 | 260 250 233 | 310 302 277 |
| Input current - Rated input current ⁵⁾ - Input current, max. - Current requirements for 24 V DC auxiliary supply | A A A | 229 335 1.1 | 284 410 1.1 | 338 495 1.35 |
| Supply voltages - Line voltage - Line frequency - Electronics power supply | V _{ACrms} Hz V _{DC} | 380 V 3 AC -10% to 480 V 3 AC +10% (-15% < 1 min) 47 to 63 Hz 24 (20.4 - 28.8) | | |
| Power loss | kW | 2.9 | 3.8 | 4.4 |
| Cooling air requirement | m ³ /s | 0.17 | 0.23 | 0.36 |
| Sound pressure level L_{pA} (1 m) at 50/60 Hz | dB(A) | 67/68 | 69/73 | 69/73 |
| Line connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 2 x 70 4 x 240 M12 (2 holes) | 2 x 95 4 x 240 M12 (2 holes) | 2 x 120 4 x 240 M12 (2 holes) |
| Motor connection - recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 2 x 50 2 x 150 M12 (2 holes) | 2 x 70 2 x 150 M12 (2 holes) | 2 x 95 2 x 150 M12 (2 holes) |
| Protective conductor connection Fixing screw | | M12 (2 holes) | M12 (2 holes) | M12 (2 holes) |
| Max. motor cable length shielded / unshielded | m | 300 / 450 | 300 / 450 | 300 / 450 |
| Dimensions (standard version) - Width - Height - Depth | mm mm mm | 800 2000 600 | 800 2000 600 | 800 2000 600 |
| Power block frame size | | FX | FX | GX |
| Weight (without options), approx. | kg | 320 | 320 | 390 |

| Order number | 6SL3710- | 1GE32-1AAx | 1GE32-6AAx | 1GE33-1AAx |
|---|----------|------------------|------------------|------------------|
| Recommended protection | | | | |
| - Line protection (with option L26) | | | | |
| Rated current | A | 3NA3144 250 | 3NA3250 300 | 3NA3254 355 |
| frame size to IEC 60269 | | 2 | 2 | 3 |
| - Line and semiconductor protection (without option L26) | | | | |
| Rated current | A | 3NE1230-2 315 | 3NE1331-2 350 | 3NE1334-2 500 |
| Frame size to IEC 60269 | | 1 | 2 | 2 |
| <p>¹⁾ Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 400 V 3 AC 50 Hz.</p> <p>²⁾ Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 460 V 3 AC 60 Hz.</p> <p>³⁾ The base-load current I_L is based on a duty cycle of 110% for 60 s or 150% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>⁴⁾ The base-load current I_H is based on a duty cycle of 150% for 60 s or 160% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>⁵⁾ The current values given here are based on the rated output current.</p> <p>⁶⁾ The recommendations for the North American market in AWG or MCM must be taken from the appropriate NEC (National Electrical Code) or CEC (Canadian Electrical Code) standards.</p> | | | | |

12.3 Technical specifications

Table 12- 9 Version A, 380 V – 480 V 3 AC, part 2

| Order number | 6SL3710- | 1GE33-8AAx | 1GE35-0AAx | 1GE36-1AAx |
|--|---|--|-------------------------------------|-------------------------------------|
| Unit rating - for I _L at 50 Hz 400 V ¹⁾ - for I _H at 50 Hz 400 V ¹⁾ - for I _L at 60 Hz 460 V ²⁾ - for I _H at 60 Hz 460 V ²⁾ | kW kW hp hp | 200 160 300 250 | 250 200 400 350 | 315 250 500 350 |
| Output current - Rated current I _N - Base load current I _L ³⁾ - Base load current I _H ⁴⁾ | A A A | 380 370 340 | 490 477 438 | 605 590 460 |
| Input current - Rated input current ⁵⁾ - Input current, max. - Current requirements for 24 V DC auxiliary supply | A A A | 395 606 1.35 | 509 781 1.35 | 629 967 1.4 |
| Supply voltages - Line voltage - Line frequency - Electronics power supply | V _{ACrms} Hz V _{DC} | 380 V 3 AC -10% to 480 V 3 AC +10% (-15% < 1 min) 47 to 63 Hz 24 (20.4 - 28.8) | | |
| Power loss | kW | 5.3 | 6.4 | 8.2 |
| Cooling air requirement | m ³ /s | 0.36 | 0.36 | 0.78 |
| Sound pressure level L_{pA} (1 m) at 50/60 Hz | dB(A) | 69/73 | 69/73 | 70/73 |
| Line connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 2 x 120 4 x 240 M12 (2 holes) | 2 x 185 4 x 240 M12 (2 holes) | 2 x 240 4 x 240 M12 (2 holes) |
| Motor connection - recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 2 x 95 2 x 150 M12 (2 holes) | 2 x 150 2 x 240 M12 (2 holes) | 2 x 185 4 x 240 M12 (2 holes) |
| Protective conductor connection Fixing screw | | M12 (2 holes) | M12 (2 holes) | M12 (2 holes) |
| Max. motor cable length shielded / unshielded | m | 300 / 450 | 300 / 450 | 300 / 450 |
| Dimensions (standard version) - Width - Height - Depth | mm mm mm | 1000 2000 600 | 1000 2000 600 | 1200 2000 600 |
| Power block frame size | | GX | GX | HX |
| Weight (without options), approx. | kg | 480 | 480 | 860 |

| Order number | 6SL3710- | 1GE33-8AAx | 1GE35-0AAx | 1GE36-1AAx |
|---|----------|------------------|------------------|------------------|
| Recommended protection | | | | |
| - Line protection (with option L26) | | | | |
| Rated current | A | 3NA3260 400 | 3NA3372 630 | 3NA3475 800 |
| frame size to IEC 60269 | | 3 | 3 | 4 |
| - Line and semiconductor protection (without option L26) | | | | |
| Rated current | A | 3NE1334-2 500 | 3NE1436-2 630 | 3NE1438-2 800 |
| Frame size to IEC 60269 | | 2 | 3 | 3 |
| <p>¹⁾ Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 400 V 3 AC 50 Hz.</p> <p>²⁾ Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 460 V 3 AC 60 Hz.</p> <p>³⁾ The base-load current I_L is based on a duty cycle of 110% for 60 s or 150% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>⁴⁾ The base-load current I_H is based on a duty cycle of 150% for 60 s or 160% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>⁵⁾ The current values given here are based on the rated output current.</p> <p>⁶⁾ The recommendations for the North American market in AWG or MCM must be taken from the appropriate NEC (National Electrical Code) or CEC (Canadian Electrical Code) standards.</p> | | | | |

12.3 Technical specifications

Table 12- 10 Version A, 380 V – 480 V 3 AC, part 3

| Order number | 6SL3710- | 1GE37-5AAx | 1GE38-4AAx | 1GE41-0AAx |
|--|---|--|-------------------------------------|-------------------------------------|
| Unit rating - for I _L at 50 Hz 400 V ¹⁾ - for I _H at 50 Hz 400 V ¹⁾ - for I _L at 60 Hz 460 V ²⁾ - for I _H at 60 Hz 460 V ²⁾ | kW kW hp hp | 400 315 600 450 | 450 400 600 500 | 560 450 800 700 |
| Output current - Rated current I _N - Base load current I _L ³⁾ - Base load current I _H ⁴⁾ | A A A | 745 725 570 | 840 820 700 | 985 960 860 |
| Input current - Rated input current ⁵⁾ - Input current, max. - Current requirements for 24 V DC auxiliary supply | A A A | 775 1188 1.4 | 873 1344 1.4 | 1024 1573 1.5 |
| Supply voltages - Line voltage - Line frequency - Electronics power supply | V _{ACrms} Hz V _{DC} | 380 V 3 AC -10% to 480 V 3 AC +10% (-15% < 1 min) 47 to 63 Hz 24 (20.4 - 28.8) | | |
| Power loss | kW | 9.6 | 10.1 | 14.4 |
| Cooling air requirement | m ³ /s | 0.78 | 0.78 | 1.48 |
| Sound pressure level L_{pA} (1 m) at 50/60 Hz | dB(A) | 70/73 | 70/73 | 72/75 |
| Line connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 3 x 185 4 x 240 M12 (2 holes) | 4 x 150 8 x 240 M12 (4 holes) | 4 x 185 8 x 240 M12 (4 holes) |
| Motor connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 2 x 240 4 x 240 M12 (2 holes) | 3 x 185 4 x 240 M12 (2 holes) | 4 x 185 6 x 240 M12 (3 holes) |
| Protective conductor connection Fixing screw | | M12 (10 holes) | M12 (16 holes) | M12 (18 holes) |
| Max. motor cable length shielded / unshielded | m | 300 / 450 | 300 / 450 | 300 / 450 |
| Dimensions (standard version) - Width - Height - Depth | mm mm mm | 1200 2000 600 | 1200 2000 600 | 1600 2000 600 |
| Power block frame size | | HX | HX | JX |
| Weight (without options), approx. | kg | 865 | 1075 | 1360 |

| Order number | 6SL3710- | 1GE37-5AAx | 1GE38-4AAx | 1GE41-0AAx |
|---|----------|-----------------------|---------------------------|---------------------------|
| Recommended protection - Line protection (with option L26) Rated current frame size to IEC 60269 | A | 3NA3475 800 4 | 3NA3365 2 x 500 3 | 3NA3472 2 x 630 3 |
| - Line and semiconductor protection (without option L26) Rated current Frame size to IEC 60269 | A | 3NE1448-2 850 3 | 3NE1436-2 2 x 630 3 | 3NE1437-2 2 x 710 3 |
| <p>¹⁾ Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 400 V 3 AC 50 Hz.</p> <p>²⁾ Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 460 V 3 AC 60 Hz.</p> <p>³⁾ The base-load current I_L is based on a duty cycle of 110% for 60 s or 150% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>⁴⁾ The base-load current I_H is based on a duty cycle of 150% for 60 s or 160% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>⁵⁾ The current values given here are based on the rated output current.</p> <p>⁶⁾ The recommendations for the North American market in AWG or MCM must be taken from the appropriate NEC (National Electrical Code) or CEC (Canadian Electrical Code) standards.</p> | | | | |

12.3 Technical specifications

Table 12- 11 Version A, 380 V – 480 V 3 AC, part 4

| Order number | 6SL3710- | 2GE41-1AAx | 2GE41-4AAx | 2GE41-6AAx |
|--|---|--|---|---|
| Unit rating - for I _L at 50 Hz 400 V ¹⁾ - for I _H at 50 Hz 400 V ¹⁾ - for I _L at 60 Hz 460 V ²⁾ - for I _H at 60 Hz 460 V ²⁾ | kW kW hp hp | 630 500 900 700 | 710 560 1000 900 | 900 710 1250 1000 |
| Output current - Rated current I _N - Base load current I _L ³⁾ - Base load current I _H ⁴⁾ | A A A | 1120 1092 850 | 1380 1340 1054 | 1560 1516 1294 |
| Input current - Rated input current ⁵⁾ - Input current, max. - Current requirements for 24 V DC auxiliary supply | A A A | 1174 1800 2.8 | 1444 2215 2.8 | 1624 2495 3.0 |
| Supply voltages - Line voltage - Line frequency - Electronics power supply | V _{ACrms} Hz V _{DC} | 380 V 3 AC -10% to 480 V 3 AC +10% (-15% < 1 min) 47 to 63 Hz 24 (20.4 - 28.8) | | |
| Power loss | kW | 16.2 | 19.0 | 19.9 |
| Cooling air requirement | m ³ /s | 1.56 | 1.56 | 1.56 |
| Sound pressure level L_{pA} (1 m) at 50/60 Hz | dB(A) | 73/76 | 73/76 | 73/76 |
| Line connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | Per sub-cabinet: 2 x 240 4 x 240 M12 (2 holes) | Per sub-cabinet: 3 x 185 4 x 240 M12 (2 holes) | Per sub-cabinet: 4 x 150 8 x 240 M12 (4 holes) |
| Motor connection - recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | Per sub-cabinet: 2 x 185 4 x 240 M12 (2 holes) | Per sub-cabinet: 2 x 240 4 x 240 M12 (2 holes) | Per sub-cabinet: 2 x 240 4 x 240 M12 (2 holes) |
| Protective conductor connection Fixing screw | | Per sub-cabinet: M12 (2 holes) | Per sub-cabinet: M12 (10 holes) | Per sub-cabinet: M12 (16 holes) |
| Max. motor cable length shielded / unshielded | m | 300 / 450 | 300 / 450 | 300 / 450 |
| Dimensions (standard version) - Width - Height - Depth | mm mm mm | 2400 2000 600 | 2400 2000 600 | 2400 2000 600 |
| Power block frame size | | HX | HX | HX |
| Weight (without options), approx. | kg | 1700 | 1710 | 2130 |

| Order number | 6SL3710- | 2GE41-1AAx | 2GE41-4AAx | 2GE41-6AAx |
|---|----------|---|---|---|
| Recommended protection | | | | |
| - Line protection (with option L26) Rated current frame size to IEC 60269 | A | Per sub-cabinet: 3NA3475 800 4 | Per sub-cabinet: 3NA3475 800 4 | Per sub-cabinet: 3NA3365 2 x 500 3 |
| - Line and semiconductor protection (without option L26) Rated current Frame size to IEC 60269 | A | Per sub-cabinet: 3NE1438-2 800 3 | Per sub-cabinet: 3NE1448-2 850 3 | Per sub-cabinet: 3NE1436-2 2 x 630 3 |
| <p>¹⁾ Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 400 V 3 AC 50 Hz.</p> <p>²⁾ Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 460 V 3 AC 60 Hz.</p> <p>³⁾ The base-load current I_L is based on a duty cycle of 110% for 60 s or 150% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>⁴⁾ The base-load current I_H is based on a duty cycle of 150% for 60 s or 160% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>⁵⁾ The current values given here are based on the rated output current.</p> <p>⁶⁾ The recommendations for the North American market in AWG or MCM must be taken from the appropriate NEC (National Electrical Code) or CEC (Canadian Electrical Code) standards.</p> | | | | |

12.3 Technical specifications

12.3.2 Cabinet unit version C, 380 V - 480 V 3 AC

Table 12- 12 Version C, 380 V – 480 V 3 AC, part 1

| Order number | 6SL3710- | 1GE32-1CAx | 1GE32-6CAx | 1GE33-1CAx |
|--|---|--|-----------------------------------|------------------------------------|
| Unit rating - for I _L at 50 Hz 400 V ¹⁾ - for I _H at 50 Hz 400 V ¹⁾ - for I _L at 60 Hz 460 V ²⁾ - for I _H at 60 Hz 460 V ²⁾ | kW kW hp hp | 110 90 150 125 | 132 110 200 150 | 160 132 250 200 |
| Output current - Rated current I _N - Base load current I _L ³⁾ - Base load current I _H ⁴⁾ | A A A | 210 205 178 | 260 250 233 | 310 302 277 |
| Input current Rated input current ⁵⁾ - Input current, max. - Current requirements for 24 V DC auxiliary supply | A A A | 229 335 1.1 | 284 410 1.1 | 338 495 1.35 |
| Supply voltages - Line voltage - Line frequency - Electronics power supply | V _{ACrms} Hz V _{DC} | 380 V 3 AC -10% to 480 V 3 AC +10% (-15% < 1 min) 47 to 63 Hz 24 (20.4 - 28.8) | | |
| Power loss | kW | 2.9 | 3.8 | 4.4 |
| Cooling air requirement | m ³ /s | 0.17 | 0.23 | 0.36 |
| Sound pressure level L_{pA} (1 m) at 50/60 Hz | dB(A) | 67/68 | 69/73 | 69/73 |
| Line connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 2 x 70 2 x 240 M12 (1 hole) | 2 x 95 2 x 240 M12 (1 hole) | 2 x 120 2 x 240 M12 (1 hole) |
| Motor connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 2 x 50 2 x 150 M12 (1 hole) | 2 x 70 2 x 150 M12 (1 hole) | 2 x 95 2 x 150 M12 (1 hole) |
| Protective conductor connection Fixing screw | | M12 (2 holes) | M12 (2 holes) | M12 (2 holes) |
| Max. motor cable length shielded / unshielded | m | 300 / 450 | 300 / 450 | 300 / 450 |
| Dimensions (standard version) - Width - Height - Depth | mm mm mm | 400 2000 600 | 400 2000 600 | 400 2000 600 |
| Power block frame size | | FX | FX | GX |
| Weight (without options), approx. | kg | 225 | 225 | 300 |

| Order number | 6SL3710- | 1GE32-1CAx | 1GE32-6CAx | 1GE33-1CAx |
|---|----------|-----------------------|-----------------------|-----------------------|
| Recommended protection - Line and semi-cond. protection Rated current frame size to IEC 60269 | A | 3NE1230-2 315 1 | 3NE1331-2 350 2 | 3NE1334-2 500 2 |
| <p>1) Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 400 V 3 AC 50 Hz.</p> <p>2) Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 460 V 3 AC 60 Hz.</p> <p>3) The base-load current I_L is based on a duty cycle of 110% for 60 s or 150% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>4) The base-load current I_H is based on a duty cycle of 150% for 60 s or 160% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>5) The current values given here are based on the rated output current.</p> <p>6) The recommendations for the North American market in AWG or MCM must be taken from the appropriate NEC (National Electrical Code) or CEC (Canadian Electrical Code) standards.</p> | | | | |

12.3 Technical specifications

Table 12- 13 Version C, 380 V – 480 V 3 AC, part 2

| Order number | 6SL3710- | 1GE33-8CAx | 1GE35-0CAx | 1GE36-1CAx |
|--|---|--|------------------------------------|-------------------------------------|
| Unit rating - for I _L at 50 Hz 400 V ¹⁾ - for I _H at 50 Hz 400 V ¹⁾ - for I _L at 60 Hz 460 V ²⁾ - for I _H at 60 Hz 460 V ²⁾ | kW kW hp hp | 200 160 300 250 | 250 200 400 350 | 315 250 500 350 |
| Output current - Rated current I _N - Base load current I _L ³⁾ - Base load current I _H ⁴⁾ | A A A | 380 370 340 | 490 477 438 | 605 590 460 |
| Input current - Rated input current ⁵⁾ - Input current, max. - Current requirements for 24 V DC auxiliary supply | A A A | 395 606 1.35 | 509 781 1.35 | 629 967 1.4 |
| Supply voltages - Line voltage - Line frequency - Electronics power supply | V _{ACrms} Hz V _{DC} | 380 V 3 AC -10% to 480 V 3 AC +10% (-15% < 1 min) 47 to 63 Hz 24 (20.4 - 28.8) | | |
| Power loss | kW | 5.3 | 6.4 | 8.2 |
| Cooling air requirement | m ³ /s | 0.36 | 0.36 | 0.78 |
| Sound pressure level L_{pA} (1 m) at 50/60 Hz | dB(A) | 69/73 | 69/73 | 70/73 |
| Line connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 2 x 120 2 x 240 M12 (1 hole) | 2 x 185 2 x 240 M12 (1 hole) | 2 x 240 4 x 240 M12 (2 holes) |
| Motor connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 2 x 95 2 x 150 M12 (1 hole) | 2 x 150 2 x 240 M12 (1 hole) | 2 x 185 4 x 240 M12 (2 holes) |
| Protective conductor connection Fixing screw | | M12 (2 holes) | M12 (2 holes) | M12 (2 holes) |
| Max. motor cable length shielded / unshielded | m | 300 / 450 | 300 / 450 | 300 / 450 |
| Dimensions (standard version) - Width - Height - Depth | mm mm mm | 400 2000 600 | 400 2000 600 | 600 2000 600 |
| Power block frame size | | GX | GX | HX |
| Weight (without options), approx. | kg | 300 | 300 | 670 |

| Order number | 6SL3710- | 1GE33-8CAx | 1GE35-0CAx | 1GE36-1CAx |
|---|----------|-----------------------|-----------------------|-----------------------|
| Recommended protection - Line and semi-cond. protection Rated current frame size to IEC 60269 | A | 3NE1334-2 500 2 | 3NE1436-2 630 3 | 3NE1438-2 800 3 |
| <p>1) Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 400 V 3 AC 50 Hz.</p> <p>2) Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 460 V 3 AC 60 Hz.</p> <p>3) The base-load current I_L is based on a duty cycle of 110% for 60 s or 150% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>4) The base-load current I_H is based on a duty cycle of 150% for 60 s or 160% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>5) The current values given here are based on the rated output current.</p> <p>6) The recommendations for the North American market in AWG or MCM must be taken from the appropriate NEC (National Electrical Code) or CEC (Canadian Electrical Code) standards.</p> | | | | |

12.3 Technical specifications

Table 12- 14 Version C, 380 V – 480 V 3 AC, part 3

| Order number | 6SL3710- | 1GE37-5CAx | 1GE38-4CAx | 1GE41-0CAx |
|--|---|--|--------------------------------------|-------------------------------------|
| Unit rating - for I _L at 50 Hz 400 V ¹⁾ - for I _H at 50 Hz 400 V ¹⁾ - for I _L at 60 Hz 460 V ²⁾ - for I _H at 60 Hz 460 V ²⁾ | kW kW hp hp | 400 315 600 450 | 450 400 600 500 | 560 450 800 700 |
| Output current - Rated current I _N - Base load current I _L ³⁾ - Base load current I _H ⁴⁾ | A A A | 745 725 570 | 840 820 700 | 985 960 860 |
| Input current - Rated input current ⁵⁾ - Input current, max. - Current requirements for 24 V DC auxiliary supply | A A A | 775 1188 1.4 | 873 1344 1.4 | 1024 1573 1.5 |
| Supply voltages - Line voltage - Line frequency - Electronics power supply | V _{ACrms} Hz V _{DC} | 380 V 3 AC -10% to 480 V 3 AC +10% (-15% < 1 min) 47 to 63 Hz 24 (20.4 - 28.8) | | |
| Power loss | kW | 9.6 | 10.1 | 14.4 |
| Cooling air requirement | m ³ /s | 0.78 | 0.78 | 1.48 |
| Sound pressure level L_{pA} (1 m) at 50/60 Hz | dB(A) | 70/73 | 70/73 | 72/75 |
| Line connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 3 x 185 4 x 240 M12 (2 holes) | 4 x 150 8 x 240 M12 (4 holes) | 4 x 185 8 x 240 M12 (4 holes) |
| Motor connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 2 x 240 4 x 240 M12 (2 holes) | 03 x 185 4 x 240 M12 (2 holes) | 4 x 185 6 x 240 M12 (3 holes) |
| Protective conductor connection Fixing screw | | M12 (8 holes) | M12 (8 holes) | M12 (10 holes) |
| Max. motor cable length shielded / unshielded | m | 300 / 450 | 300 / 450 | 300 / 450 |
| Dimensions (standard version) - Width - Height - Depth | mm mm mm | 600 2000 600 | 600 2000 600 | 1000 2000 600 |
| Power block frame size | | HX | HX | JX |
| Weight (without options), approx. | kg | 670 | 670 | 980 |

| Order number | 6SL3710- | 1GE37-5CAx | 1GE38-4CAx | 1GE41-0CAx |
|---|----------|-----------------------|---------------------------|---------------------------|
| Recommended protection Line and semi-cond. protection Rated current frame size to IEC 60269 | A | 3NE1448-2 850 3 | 3NE1436-2 2 x 630 3 | 3NE1437-2 2 x 710 3 |
| <p>1) Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 400 V 3 AC 50 Hz.</p> <p>2) Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 460 V 3 AC 60 Hz.</p> <p>3) The base-load current I_L is based on a duty cycle of 110% for 60 s or 150% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>4) The base-load current I_H is based on a duty cycle of 150% for 60 s or 160% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>5) The current values given here are based on the rated output current.</p> <p>6) The recommendations for the North American market in AWG or MCM must be taken from the appropriate NEC (National Electrical Code) or CEC (Canadian Electrical Code) standards.</p> | | | | |

12.3.3 Cabinet unit version A, 500 V - 600 V 3 AC

12.3 Technical specifications

Table 12- 15 Version A, 500 V – 600 V 3 AC, part 1

| Order number | 6SL3710- | 1GF31-8AAx | 1GF32-2AAx | 1GF32-6AAx |
|--|---|---|------------------------------------|------------------------------------|
| Unit rating - for I _L at 50 Hz 500 V ¹⁾ - for I _H at 50 Hz 500 V ¹⁾ - for I _L at 60 Hz 575 V ²⁾ - for I _H at 60 Hz 575 V ²⁾ | kW kW hp hp | 110 90 150 150 | 132 110 200 200 | 160 132 250 200 |
| Output current - Rated current I _N - Base load current I _L ³⁾ - Base load current I _H ⁴⁾ | A A A | 175 171 157 | 215 208 192 | 260 250 233 |
| Input current - Rated input current ⁵⁾ - Input current, max. - Current requirements for 24 V DC auxiliary supply | A A A | 191 279 1.35 | 224 341 1.35 | 270 410 1.35 |
| Supply voltages - Line voltage - Line frequency - Electronics power supply | V _{ACrms} Hz V _{DC} | 500 V 3 AC -10 % to 600 V 3 AC +10 % (-15 % < 1 min) 47 to 63 Hz 24 (20.4 - 28.8) | | |
| Power loss | kW | 3.8 | 4.2 | 5.0 |
| Cooling air requirement | m ³ /s | 0.36 | 0.36 | 0.36 |
| Sound pressure level L_{pA} (1 m) at 50/60 Hz | dB(A) | 69/73 | 69/73 | 69/73 |
| Line connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 120 4 x 240 M12 (2 holes) | 2 x 70 4 x 240 M12 (2 holes) | 2 x 95 4 x 240 M12 (2 holes) |
| Motor connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 95 2 x 150 M12 (2 holes) | 120 2 x 150 M12 (2 holes) | 2 x 70 2 x 185 M12 (2 holes) |
| Protective conductor connection Fixing screw | | M12 (2 holes) | M12 (2 holes) | M12 (2 holes) |
| Max. motor cable length shielded / unshielded | m | 300 / 450 | 300 / 450 | 300 / 450 |
| Dimensions (standard version) - Width - Height - Depth | mm mm mm | 800 2000 600 | 800 2000 600 | 800 2000 600 |
| Power block frame size | | GX | GX | GX |
| Weight (without options), approx. | kg | 390 | 390 | 390 |

| Order number | 6SL3710- | 1GF31-8AAx | 1GF32-2AAx | 1GF32-6AAx |
|---|----------|------------|------------|------------|
| Recommended protection | | | | |
| - Line protection (with option L26) | | | | |
| Rated current | A | 3NA3244-6 | 3NA3252-6 | 3NA3354-6 |
| frame size to IEC 60269 | | 250 | 315 | 355 |
| - Line and semiconductor protection (without option L26) | | | | |
| Rated current | A | 3NE1227-2 | 3NE1230-2 | 3NE1331-2 |
| Frame size to IEC 60269 | | 250 | 315 | 350 |
| | | 1 | 1 | 2 |
| <p>¹⁾ Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 500 V 3 AC 50 Hz.</p> <p>²⁾ Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 575 V 3 AC 60 Hz.</p> <p>³⁾ The base-load current I_L is based on a duty cycle of 110% for 60 s or 150% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>⁴⁾ The base-load current I_H is based on a duty cycle of 150% for 60 s or 160% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>⁵⁾ The current values given here are based on the rated output current.</p> <p>⁶⁾ The recommendations for the North American market in AWG or MCM must be taken from the appropriate NEC (National Electrical Code) or CEC (Canadian Electrical Code) standards.</p> | | | | |

12.3 Technical specifications

Table 12- 16 Version A, 500 V – 600 V 3 AC, part 2

| Order number | 6SL3710- | 1GF33-3AAx | 1GF34-1AAx | 1GF34-7AAx |
|--|---|---|-------------------------------------|-------------------------------------|
| Unit rating - for I _L at 50 Hz 500 V ¹⁾ - for I _H at 50 Hz 500 V ¹⁾ - for I _L at 60 Hz 575 V ²⁾ - for I _H at 60 Hz 575 V ²⁾ | kW kW hp hp | 200 160 300 250 | 250 200 400 350 | 315 250 450 450 |
| Output current - Rated current I _N - Base load current I _L ³⁾ - Base load current I _H ⁴⁾ | A A A | 330 320 280 | 410 400 367 | 465 452 416 |
| Input current - Rated input current ⁵⁾ - Input current, max. - Current requirements for 24 V DC auxiliary supply | A A A | 343 525 1.4 | 426 655 1.4 | 483 740 1.4 |
| Supply voltages - Line voltage - Line frequency - Electronics power supply | V _{ACrms} Hz V _{DC} | 500 V 3 AC -10 % to 600 V 3 AC +10 % (-15 % < 1 min) 47 to 63 Hz 24 (20.4 - 28.8) | | |
| Power loss | kW | 6.1 | 8.1 | 7.8 |
| Cooling air requirement | m ³ /s | 0.36 | 0.78 | 0.78 |
| Sound pressure level L_{pA} (1 m) at 50/60 Hz | dB(A) | 69/73 | 72/75 | 72/75 |
| Line connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 2 x 120 4 x 240 M12 (2 holes) | 2 x 185 4 x 240 M12 (2 holes) | 2 x 185 4 x 240 M12 (2 holes) |
| Motor connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 2 x 95 2 x 240 M12 (2 holes) | 2 x 120 4 x 240 M12 (2 holes) | 2 x 150 4 x 240 M12 (2 holes) |
| Protective conductor connection Fixing screw | | M12 (2 holes) | M12 (2 holes) | M12 (2 holes) |
| Max. motor cable length shielded / unshielded | m | 300 / 450 | 300 / 450 | 300 / 450 |
| Dimensions (standard version) - Width - Height - Depth | mm mm mm | 800 2000 600 | 1200 2000 600 | 1200 2000 600 |
| Power block frame size | | GX | HX | HX |
| Weight (without options), approx. | kg | 390 | 860 | 860 |

| Order number | 6SL3710- | 1GF33-3AAx | 1GF34-1AAx | 1GF34-7AAx |
|---|----------|------------|------------|------------|
| Recommended protection | | | | |
| - Line protection (with option L26) | | | | |
| Rated current | A | 3NA3365-6 | 3NA3365-6 | 3NA3352-6 |
| frame size to IEC 60269 | | 500 | 500 | 2 x 315 |
| | | 3 | 3 | 2 |
| - Line and semiconductor protection (without option L26) | | | | |
| Rated current | A | 3NE1334-2 | 3NE1334-2 | 3NE1435-2 |
| Frame size to IEC 60269 | | 500 | 500 | 560 |
| | | 2 | 2 | 3 |
| <p>¹⁾ Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 500 V 3 AC 50 Hz.</p> <p>²⁾ Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 575 V 3 AC 60 Hz.</p> <p>³⁾ The base-load current I_L is based on a duty cycle of 110% for 60 s or 150% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>⁴⁾ The base-load current I_H is based on a duty cycle of 150% for 60 s or 160% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>⁵⁾ The current values given here are based on the rated output current.</p> <p>⁶⁾ The recommendations for the North American market in AWG or MCM must be taken from the appropriate NEC (National Electrical Code) or CEC (Canadian Electrical Code) standards.</p> | | | | |

12.3 Technical specifications

Table 12- 17 Version A, 500 V – 600 V 3 AC, part 3

| Order number | 6SL3710- | 1GF35-8AAx | 1GF37-4AAx | 1GF38-1AAx |
|--|---|---|-------------------------------------|-------------------------------------|
| Unit rating - for I _L at 50 Hz 500 V ¹⁾ - for I _H at 50 Hz 500 V ¹⁾ - for I _L at 60 Hz 575 V ²⁾ - for I _H at 60 Hz 575 V ²⁾ | kW kW hp hp | 400 315 600 500 | 500 450 700 700 | 560 500 800 700 |
| Output current - Rated current I _N - Base load current I _L ³⁾ - Base load current I _H ⁴⁾ | A A A | 575 560 514 | 735 710 657 | 810 790 724 |
| Input current - Rated input current ⁵⁾ - Input current, max. - Current requirements for 24 V DC auxiliary supply | A A A | 598 918 1.4 | 764 1164 1.5 | 842 1295 1.5 |
| Supply voltages - Line voltage - Line frequency - Electronics power supply | V _{ACrms} Hz V _{DC} | 500 V 3 AC -10 % to 600 V 3 AC +10 % (-15 % < 1 min) 47 to 63 Hz 24 (20.4 - 28.8) | | |
| Power loss | kW | 8.7 | 12.7 | 14.1 |
| Cooling air requirement | m ³ /s | 0.78 | 1.48 | 1.48 |
| Sound pressure level L_{pA} (1 m) at 50/60 Hz | dB(A) | 72/75 | 72/75 | 72/75 |
| Line connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 2 x 240 4 x 240 M12 (2 holes) | 3 x 185 8 x 240 M12 (4 holes) | 4 x 150 8 x 240 M12 (4 holes) |
| Motor connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 2 x 185 4 x 240 M12 (2 holes) | 2 x 240 6 x 240 M12 (3 holes) | 3 x 185 6 x 240 M12 (3 holes) |
| Protective conductor connection Fixing screw | | M12 (2 holes) | M12 (18 holes) | M12 (18 holes) |
| Max. motor cable length shielded / unshielded | m | 300 / 450 | 300 / 450 | 300 / 450 |
| Dimensions (standard version) - Width - Height - Depth | mm mm mm | 1200 2000 600 | 1600 2000 600 | 1600 2000 600 |
| Power block frame size | | HX | JX | JX |
| Weight (without options), approx. | kg | 860 | 1320 | 1360 |

| Order number | 6SL3710- | 1GF35-8AAx | 1GF37-4AAx | 1GF38-1AAx |
|---|----------|---------------------------|---------------------------|---------------------------|
| Recommended protection - Line protection (with option L26) Rated current frame size to IEC 60269 | A | 3NA3354-6 2 x 355 3 | 3NA3365-6 2 x 500 3 | 3NA3365-6 2 x 500 3 |
| - Line and semiconductor protection (without option L26) Rated current Frame size to IEC 60269 | A | 3NE1447-2 670 3 | 3NE1448-2 850 3 | 3NE1334-2 2 x 500 2 |
| <p>¹⁾ Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 500 V 3 AC 50 Hz.</p> <p>²⁾ Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 575 V 3 AC 60 Hz.</p> <p>³⁾ The base-load current I_L is based on a duty cycle of 110% for 60 s or 150% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>⁴⁾ The base-load current I_H is based on a duty cycle of 150% for 60 s or 160% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>⁵⁾ The current values given here are based on the rated output current.</p> <p>⁶⁾ The recommendations for the North American market in AWG or MCM must be taken from the appropriate NEC (National Electrical Code) or CEC (Canadian Electrical Code) standards.</p> | | | | |

12.3 Technical specifications

Table 12- 18 Version A, 500 V – 600 V 3 AC, part 4

| Order number | 6SL3710- | 2GF38-6AAx | 2GF41-1AAx | 2GF41-4AAx |
|--|---|---|---|---|
| Unit rating - for I _L at 50 Hz 500 V ¹⁾ - for I _H at 50 Hz 500 V ¹⁾ - for I _L at 60 Hz 575 V ²⁾ - for I _H at 60 Hz 575 V ²⁾ | kW kW hp hp | 630 560 900 800 | 710 630 1000 900 | 1000 800 1250 1000 |
| Output current - Rated current I _N - Base load current I _L ³⁾ - Base load current I _H ⁴⁾ | A A A | 860 836 770 | 1070 1036 950 | 1360 1314 1216 |
| Input current - Rated input current ⁵⁾ - Input current, max. - Current requirements for 24 V DC auxiliary supply | A A A | 904 1388 2.8 | 1116 1708 2.8 | 1424 2186 3.0 |
| Supply voltages - Line voltage - Line frequency - Electronics power supply | V _{ACrms} Hz V _{DC} | 500 V 3 AC -10 % to 600 V 3 AC +10 % (-15 % < 1 min) 47 to 63 Hz 24 (20.4 - 28.8) | | |
| Power loss | kW | 15.4 | 17.2 | 23.8 |
| Cooling air requirement | m ³ /s | 1.56 | 1.56 | 2.96 |
| Sound pressure level L_{pA} (1 m) at 50/60 Hz | dB(A) | 75/78 | 75/78 | 75/78 |
| Line connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | Per sub-cabinet: 2 x 185 4 x 240 M12 (2 holes) | Per sub-cabinet: 2 x 240 4 x 240 M12 (2 holes) | Per sub-cabinet: 3 x 185 8 x 240 M12 (4 holes) |
| Motor connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | Per sub-cabinet: 2 x 150 4 x 240 M12 (2 holes) | Per sub-cabinet: 2 x 185 4 x 240 M12 (2 holes) | Per sub-cabinet: 2 x 240 6 x 240 M12 (3 holes) |
| Protective conductor connection Fixing screw | | Per sub-cabinet: M12 (2 holes) | Per sub-cabinet: M12 (2 holes) | Per sub-cabinet: M12 (18 holes) |
| Max. motor cable length shielded / unshielded | m | 300 / 450 | 300 / 450 | 300 / 450 |
| Dimensions (standard version) - Width - Height - Depth | mm mm mm | 2400 2000 600 | 2400 2000 600 | 3200 2000 600 |
| Power block frame size | | HX | HX | JX |
| Weight (without options), approx. | kg | 1700 | 1700 | 2620 |

| Order number | 6SL3710- | 2GF38-6AAx | 2GF41-1AAx | 2GF41-4AAx |
|---|----------|---|---|---|
| Recommended protection | | | | |
| - Line protection (with option L26) Rated current frame size to IEC 60269 | A | Per sub-cabinet: 3NA3352-6 2 x 315 3 | Per sub-cabinet: 3NA3365-6 2 x 500 3 | Per sub-cabinet: 3NA3365-6 2 x 500 3 |
| - Line and semiconductor protection (without option L26) Rated current Frame size to IEC 60269 | A | Per sub-cabinet: 3NE1435-2 560 3 | Per sub-cabinet: 3NE1447-2 670 3 | Per sub-cabinet: 3NE1448-2 850 3 |
| <p>¹⁾ Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 500 V 3 AC 50 Hz.</p> <p>²⁾ Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 575 V 3 AC 60 Hz.</p> <p>³⁾ The base-load current I_L is based on a duty cycle of 110% for 60 s or 150% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>⁴⁾ The base-load current I_H is based on a duty cycle of 150% for 60 s or 160% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>⁵⁾ The current values given here are based on the rated output current.</p> <p>⁶⁾ The recommendations for the North American market in AWG or MCM must be taken from the appropriate NEC (National Electrical Code) or CEC (Canadian Electrical Code) standards.</p> | | | | |

12.3 Technical specifications

12.3.4 Cabinet unit version C, 500 V - 600 V 3 AC

Table 12- 19 Version C, 500 V – 600 V 3 AC, part 1

| Order number | 6SL3710- | 1GF31-8CAx | 1GF32-2CAx | 1GF32-6CAx |
|--|---|---|-----------------------------------|-----------------------------------|
| Unit rating - for I _L at 50 Hz 500 V ¹⁾ - for I _H at 50 Hz 500 V ¹⁾ - for I _L at 60 Hz 575 V ²⁾ - for I _H at 60 Hz 575 V ²⁾ | kW kW hp hp | 110 90 150 150 | 132 110 200 200 | 160 132 250 200 |
| Output current - Rated current I _N - Base load current I _L ³⁾ - Base load current I _H ⁴⁾ | A A A | 175 171 157 | 215 208 192 | 260 250 233 |
| Input current - Rated input current ⁵⁾ - Input current, max. - Current requirements for 24 V DC auxiliary supply | A A A | 191 279 1.35 | 224 341 1.35 | 270 410 1.35 |
| Supply voltages - Line voltage - Line frequency - Electronics power supply | V _{ACrms} Hz V _{DC} | 500 V 3 AC -10 % to 600 V 3 AC +10 % (-15 % < 1 min) 47 to 63 Hz 24 (20.4 - 28.8) | | |
| Power loss | kW | 3.8 | 4.2 | 5.0 |
| Cooling air requirement | m ³ /s | 0.36 | 0.36 | 0.36 |
| Sound pressure level L_{pA} (1 m) at 50/60 Hz | dB(A) | 69/73 | 69/73 | 69/73 |
| Line connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 120 2 x 240 M12 (1 hole) | 2 x 70 2 x 240 M12 (1 hole) | 2 x 95 2 x 240 M12 (1 hole) |
| Motor connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 95 2 x 150 M12 (1 hole) | 120 2 x 150 M12 (1 hole) | 2 x 70 2 x 185 M12 (1 hole) |
| Protective conductor connection Fixing screw | | M12 (2 holes) | M12 (2 holes) | M12 (2 holes) |
| Max. motor cable length shielded / unshielded | m | 300 / 450 | 300 / 450 | 300 / 450 |
| Dimensions (standard version) - Width - Height - Depth | mm mm mm | 400 2000 600 | 400 2000 600 | 400 2000 600 |
| Power block frame size | | GX | GX | GX |
| Weight (without options), approx. | kg | 300 | 300 | 300 |

| Order number | 6SL3710- | 1GF31-8CAx | 1GF32-2CAx | 1GF32-6CAx |
|---|----------|-----------------------|-----------------------|-----------------------|
| Recommended protection - Line and semi-cond. protection Rated current frame size to IEC 60269 | A | 3NE1227-2 250 1 | 3NE1230-2 315 1 | 3NE1331-2 350 2 |
| <p>1) Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 500 V 3 AC 50 Hz.</p> <p>2) Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 575 V 3 AC 60 Hz.</p> <p>3) The base-load current I_L is based on a duty cycle of 110% for 60 s or 150% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>4) The base-load current I_H is based on a duty cycle of 150% for 60 s or 160% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>5) The current values given here are based on the rated output current.</p> <p>6) The recommendations for the North American market in AWG or MCM must be taken from the appropriate NEC (National Electrical Code) or CEC (Canadian Electrical Code) standards.</p> | | | | |

12.3 Technical specifications

Table 12- 20 Version C, 500 V – 600 V 3 AC, part 2

| Order number | 6SL3710- | 1GF33-3CAx | 1GF34-1CAx | 1GF34-7CAx |
|--|---|---|-------------------------------------|-------------------------------------|
| Unit rating - for I _L at 50 Hz 500 V ¹⁾ - for I _H at 50 Hz 500 V ¹⁾ - for I _L at 60 Hz 575 V ²⁾ - for I _H at 60 Hz 575 V ²⁾ | kW kW hp hp | 200 160 300 250 | 250 200 400 350 | 315 250 450 450 |
| Output current - Rated current I _N - Base load current I _L ³⁾ - Base load current I _H ⁴⁾ | A A A | 330 320 280 | 410 400 367 | 465 452 416 |
| Input current - Rated input current ⁵⁾ - Input current, max. - Current requirements for 24 V DC auxiliary supply | A A A | 343 525 1.4 | 426 655 1.4 | 483 740 1.4 |
| Supply voltages - Line voltage - Line frequency - Electronics power supply | V _{ACrms} Hz V _{DC} | 500 V 3 AC -10 % to 600 V 3 AC +10 % (-15 % < 1 min) 47 to 63 Hz 24 (20.4 - 28.8) | | |
| Power loss | kW | 6.1 | 8.1 | 7.8 |
| Cooling air requirement | m ³ /s | 0.36 | 0.78 | 0.78 |
| Sound pressure level L_{pA} (1 m) at 50/60 Hz | dB(A) | 69/73 | 72/75 | 72/75 |
| Line connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 2 x 120 2 x 240 M12 (1 hole) | 2 x 185 4 x 240 M12 (2 holes) | 2 x 185 4 x 240 M12 (2 holes) |
| Motor connection - Recommended: IEC ⁶⁾ - maximum: IEC - Retainer screw | mm ² mm ² | 2 x 95 2 x 240 M12 (1 hole) | 2 x 120 4 x 240 M12 (2 holes) | 2 x 150 4 x 240 M12 (2 holes) |
| Protective conductor connection Fixing screw | | M12 (2 holes) | M12 (2 holes) | M12 (2 holes) |
| Max. motor cable length shielded / unshielded | m | 300 / 450 | 300 / 450 | 300 / 450 |
| Dimensions (standard version) - Width - Height - Depth | mm mm mm | 400 2000 600 | 600 2000 600 | 600 2000 600 |
| Power block frame size | | GX | HX | HX |
| Weight (without options), approx. | kg | 300 | 670 | 670 |

12.3 Technical specifications

| Order number | 6SL3710- | 1GF33-3CAx | 1GF34-1CAx | 1GF34-7CAx |
|---|----------|-----------------------|-----------------------|-----------------------|
| Recommended protection - Line and semi-cond. protection Rated current frame size to IEC 60269 | A | 3NE1334-2 500 2 | 3NE1334-2 500 2 | 3NE1435-2 560 3 |
| <p>1) Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 500 V 3 AC 50 Hz.</p> <p>2) Rated output of a typical 6-pole standard induction motor based on I_L or I_H at 575 V 3 AC 60 Hz.</p> <p>3) The base-load current I_L is based on a duty cycle of 110% for 60 s or 150% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>4) The base-load current I_H is based on a duty cycle of 150% for 60 s or 160% for 10 s with a duty cycle duration of 300 s (see "Overload capability").</p> <p>5) The current values given here are based on the rated output current.</p> <p>6) The recommendations for the North American market in AWG or MCM must be taken from the appropriate NEC (National Electrical Code) or CEC (Canadian Electrical Code) standards.</p> | | | | |